




Parts Information:
Desk Fan 3-Speed 16" Push-Button 230V
Model No: SDF16W



Item	Part No.	Description
1	SDF16W.01	BOTTOM PAD
2	SDF16W.02	SCREW
3	SDF16W.03	FAN BASE LOWER
4	SDF16W.04	POWER CORD
5	SDF16W.05	POWER CORD COVER
6	SDF16W.06	CLIP
7	SDF16W.07	MOTOR COVER
8	SDF16W.08	MOTOR KNOB
9	SDF16W.09	MOTOR
10	SDF16W.10	MOTOR COVER
11	SDF16W.11	REAR GUARD
12	SDF16W.12	NUT FOR GUARD
14	SWF16WR.05	FAN BLADE

Item	Part No.	Description
15	SDF16W.15	FRONT GUARD
16	SDF16W.16	GRILL GUARD DISC
17	SDF16W.17	POLE
18	SDF16W.18	ARM
19	SDF16W.19	SPRING
20	SDF16W.20	SPRING BALL
21	SDF16W.21	SPRING
22	SDF16W.22	ORIENTATION PAD
23	SDF12W.23	SWITCH
24	SDF16W.24	NUT
25	SDF16W.25	NUT COVER
26	SDF16W.26	FAN BASE UPPER
27	SDF16W.27	BOTTOM BOARD

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk