




Parts Information:
Desk Fan 2-Speed 9" Push-Button 230V
Model No: SDF9W



Item	Part No.	Description
1	SDF9W.01	BOTTOM PAD
2	SDF9W.02	SCREW
3	SDF9W.03	FAN BASE LOWER
4	SDF9W.04	POWER CORD
5	SDF9W.05	POWER CORD COVER
6	SDF9W.06	CLIP
7	SDF9W.07	MOTOR COVER
8	SDF9W.08	MOTOR KNOB
9	SDF9W.09	MOTOR
10	SDF9W.10	MOTOR COVER
11	SDF9W.11	REAR GUARD
12	SDF9W.12	NUT FOR GUARD
14	SDF9W.14	FAN BLADE c/w SPRING CLIP

Item	Part No.	Description
15	SDF9W.15	FRONT GUARD
16	SDF9W.16	GRILL GUARD DISC
17	SDF9W.17	POLE
18	SDF9W.18	ARM
19	SDF9W.19	SPRING
20	SDF9W.20	SPRING BALL
21	SDF9W.21	SPRING
22	SDF9W.22	ORIENTATION PAD
23	SDF9W.23	SWITCH
24	SDF9W.24	NUT
25	SDF9W.25	NUT COVER
26	SDF9W.26	FAN BASE UPPER
27	SDF9W.27	BOTTOM BOARD

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk