


Parts Information:

Sealey Display Stand Model No: SDSX



Item	Part No.	Description
1	SDSX.01	Adjustable Foot
2	SDSX.02	Side Pillar 2300mm
3	SDSX.03	Stand For Pillar 460mm
4-1,	SDSX.04	Back Display Wall Assembly 2230x1004mm
4-2,		
4-3,		
4-4		
5	SDSX.05	Lower Link 1004mm
6	SDSX.06	Upper Link 1004mm
7	SDSX.07	Base Front Plate 1004mm
8	SDSX.08	Bracket For Shelf 350mm
9	SDSX.09	Base Shelf 1004x460mm

Item	Part No.	Description
10	SDSX.10	Shelf 1004x350mm
11	SDSX.11-L	Base Side Plate Cover 460mm
11	SDSX.11-R	Base Side Plate Cover 460mm
12	SDSX.12-L	Pillar Side Cover 2230mm
12	SDSX.12-R	Pillar Side Cover 2230mm
13	SDSX.13	Middle Link
	SDSX.14	Sealey Garden & Leisure Display Sign (NOT SHOWN)
	SDSX.15	Sealey Garden & Leisure Ticket Rail Insert (NOT SHOWN)
	SDSX.16	Sealey Garden & Leisure Filmstrip 998 x 220 (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk

Page 1 of 1 SDSX Issue 2 PL 16/04/18