


Parts Information: Desk/Floor Fan 3-Speed 16" 230V Model No: SFF16



Item	Part No.	Description
1	SFF16.01	Front Cap
2	SFF16.02	Front Body
3	SFF16.03	Screw, Fan Blade
4	SFF16.04	Fan Blade
5	SFF16.05	Screw
6	SFF16.06	Motor
7	SFF16.07	Motor Bracket
8	SFF16.08	Screw
9	SFF16.09	Cover
10	SFF16.10	Screw
11	SFF16.11	Cord Clip
12	SFF16.12	Capacitor

Item	Part No.	Description
13	SFF16.13	Rear Body
14	SFF16.14	Holder, Rotary Switch
15	SFF16.15	Switch, Rotary
16	SFF16.16	Knob, Switch
17	SFF16.17	Cover, Switch
18	SFF16.18	Screw
19	SFF16.19	Cord (c/w Plug)
20	SFF16.20	Base
21	SFF12.V2-22	Rubber Foot
22	SFF16.22	Foot
23	SFF16.23	Screw
24	SFF16.24	Washer

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

Realized sealey.co.uk

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

01284 703534

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

www.sealey.co.uk

01284 757500

SFF16 Issue 3 PL 13/12/21