


Parts Information:

Desk/Floor Fan 3-Speed 20" 230V Model No: SFF20



Item	Part No.	Description
1	SFF20.01	FRONT GRILLE
2	SFF20.02	NUT FOR FAN BLADE
3	SFF20.03	FAN BLADE 20"
4	SFF20.04	SCREW
5	SFF20.05	MOTOR
6	SFF20.06	SIDE ROTARY COVER
7	SFF20.07	SCREW
8	SFF20.08	CAPACITOR COVER
9	SFF20.09	CAPACITOR
10	SFF20.10	SCREW
11	SFF20.11	ROTARY KNOB

Item	Part No.	Description
12	SFF20.12	SWITCH COVER
13	SFF20.13	SWITCH
14	SFF20.14	POWER CORD
15	SFF20.15	REAR GRILLE
16	SFF20.16	BASE
17	SFF20.17	PLASTIC FOOT (PAIR)
18	SFF20.18	SCREW
19	SFF20.19	WASHER
20	SFF20.20	SCREW
21	SFF20.21	FRONT CAP

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk

Page 1 of 1 SFF20 Issue 2 PL 24/10/17