


Parts Information:

Oscillating Spindle/Bobbin Sander 450W Model No: SM1200



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information. IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Parts Information:

Oscillating Spindle/Bobbin Sander 450W Model No: SM1200

Item	Part No.	Description
1	SM1200-01	Hex Nut
2	SM1200-02	Upper Spindle Washer
3	SS5ASS	Sanding Sleeves Assorted 80Grit (Pack of 5) - Please see Catalogue
4*	SM1200-04	Rubber Sanding Drum Set
5**	SM1200-05	Dust Protecting Cover Assembly
6	SM1200-06	Lower Spindle Washer
7	SM1200-07	Sanding Table
8	SM1200-08	Dust Extraction Cover Washer
9	SM1200-09	Dust Extraction Cover
10	FWM5.S	Flat Washer M5
11	SWM5.S	Spring Washer M5
12	SM1300.40	Cross Head Screw M5 x 12mm
13	SM1200-13	Drive Belt, Ribbed (A)
14	SM1200-14	Drive Belt, Ribbed (B)
15	SM1200-15	Drive Belt Wheel
16	FWM4.S	Flat Washer M4
17	SM1200-17	Tension Roller Assembly
18	SM1300.78	Rd Head S/T Screw M4 x 12mm Black. Large Head
19	SM1200-19	Rotation Plate Assembly
20	SM1300.54	Tapping Screw ST4.2 x 23mm
21	FWM6.S	Flat Washer M6
22	SWM6.S	Spring Washer M6
23	SM1200-23	Screw 6 x 16mm
24	B/6001ZZ	Bearing 6001ZZ
25	SM1200-25	Spring Washer
26	SM1200-26	Armature Assembly
27	B/608ZZ	Bearing 608ZZ
28	SM1200-28	Connection Plate
29	SM1200-29	Field Coil Assembly
30	SM1200-30	Rear Cover
31	SM1200-31	Carbon Brush Holder Cover
32	SM1200-32	Carbon Brush Holder
33	SM1200-33	Carbon Brush
34	SM1200-34	Carbon Brush Spring
37	SM1300.46	Tapping Screw ST4.2 x 13mm
39	SM1300.75	Rd Head S/T Screw M4.2 x 110mm

41 SM1200-42 Felt Washer 42 SM1200-43 Rubber Washer 43 SM1200-43 Rubber Washer 44 B/6203ZZ Bearing Support 45 SM1200-45 Bearing Support 46 SM1300.46 Tapping Screw ST4.2 x 13mm 47 SM1200-47 Bearing Sleeve 48 SM1200-48 Pressure Spring 49 SM1200-48 Pressure Spring 49 SM1200-50 Spindle Washer 50 SM1200-50 Spindle Washer 51 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel Spindle 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-69 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 <th>Item</th> <th>Part No.</th> <th>Description</th>	Item	Part No.	Description
43 SM1200-43 Rubber Washer 44 B/6203ZZ Bearing 6203ZZ 45 SM1200-45 Bearing Support 46 SM1300.46 Tapping Screw ST4.2 x 13mm 47 SM1200-47 Bearing Sleeve 48 SM1200-48 Pressure Spring 49 SM1200-49 Spring Washer 50 SM1200-50 Spindle Washer 52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel (A) 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-55 Drive Wheel (B) 57 SM1200-56 Drive Wheel (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60	41	SM1200-41	Bearing Cover (A)
44 B/6203ZZ Bearing 6203ZZ 45 SM1200-45 Bearing Support 46 SM1300.46 Tapping Screw ST4.2 x 13mm 47 SM1200-47 Bearing Sleeve 48 SM1200-48 Pressure Spring 49 SM1200-50 Spring Washer 50 SM1200-50 Spindle Washer 52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel Spindle 54 SM1200-54 Drive Wheel Spindle 55 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-55 Drive Wheel Spindle 57 SM1200-56 Drive Wheel (B) 59 SM1200-55 Drive Wheel (B) 59 SM1200-59 Bearing Support 63 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66	42	SM1200-42	Felt Washer
45 SM1200-45 Bearing Support 46 SM1300.46 Tapping Screw ST4.2 x 13mm 47 SM1200-47 Bearing Sleeve 48 SM1200-48 Pressure Spring 49 SM1200-49 Spring Washer 50 SM1200-50 Spindle Washer 52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel Spindle 54 SM1200-54 Drive Wheel Spindle 55 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-55 Drive Wheel (B) 57 SM1200-56 Drive Wheel (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 <td< td=""><td>43</td><td>SM1200-43</td><td>Rubber Washer</td></td<>	43	SM1200-43	Rubber Washer
46 SM1300.46 Tapping Screw ST4.2 x 13mm 47 SM1200-47 Bearing Sleeve 48 SM1200-48 Pressure Spring 49 SM1200-50 Spring Washer 50 SM1200-50 Spindle Washer 52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel (A) 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-55 Drive Wheel (B) 57 SM1200-56 Drive Wheel (B) 59 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-79 Base 71 SM1200-71 <td>44</td> <td>B/6203ZZ</td> <td>Bearing 6203ZZ</td>	44	B/6203ZZ	Bearing 6203ZZ
47 SM1200-47 Bearing Sleeve 48 SM1200-48 Pressure Spring 49 SM1200-49 Spring Washer 50 SM1200-50 Spindle Washer 52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel Spindle 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-55 Drive Wheel (B) 57 SM1200-56 Drive Wheel Plate (B) 59 SM1200-57 Drive Wheel Plate (B) 69 SM1200-59 Bearing Sueve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB	45	SM1200-45	Bearing Support
48 SM1200-48 Pressure Spring 49 SM1200-49 Spring Washer 50 SM1200-50 Spindle Washer 52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel (A) 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-63 Rubber Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 16mm 78 <	46	SM1300.46	Tapping Screw ST4.2 x 13mm
49 SM1200-49 Spring Washer 50 SM1200-50 Spindle Washer 52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel (A) 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm <td< td=""><td>47</td><td>SM1200-47</td><td>Bearing Sleeve</td></td<>	47	SM1200-47	Bearing Sleeve
50 SM1200-50 Spindle Washer 52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel (A) 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 8	48	SM1200-48	Pressure Spring
52 SM1200-52 Drive Wheel Plate (A) 53 SM1200-53 Drive Wheel (A) 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm	49	SM1200-49	Spring Washer
53 SM1200-53 Drive Wheel (A) 54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-70 Base 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm	50	SM1200-50	Spindle Washer
54 SM1200-54 Drive Wheel Spindle 55 SM1200-55 Woodruff Key 56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black Msc616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-82 Screw 4.2 x 16mm 83	52	SM1200-52	Drive Wheel Plate (A)
55 SM1200-56 Woodruff Key 56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-83 Cable Grip	53	SM1200-53	Drive Wheel (A)
56 SM1200-56 Drive Wheel (B) 57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-83 Cable Grip	54	SM1200-54	Drive Wheel Spindle
57 SM1200-57 Drive Wheel Plate (B) 59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-83 Cable Grip	55	SM1200-55	Woodruff Key
59 SM1200-59 Bearing Sleeve 61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	56	SM1200-56	Drive Wheel (B)
61 SM1200-61 Bearing Support 63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-83 Cable Grip	57	SM1200-57	Drive Wheel Plate (B)
63 SM1200-63 Rubber Washer 64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	59	SM1200-59	Bearing Sleeve
64 SM1200-64 Felt Washer 65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	61	SM1200-61	Bearing Support
65 SM1200-65 Drive Wheel Support Case 66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	63	SM1200-63	Rubber Washer
66 SM1200-66 PCB 67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	64	SM1200-64	Felt Washer
67 SM1300.60 Tapping Screw ST4.2 x 1.9mm 69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	65	SM1200-65	Drive Wheel Support Case
69 SM1200-69 Cable Sleeve 70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	66	SM1200-66	PCB
70 SM1200-70 Base 71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	67	SM1300.60	Tapping Screw ST4.2 x 1.9mm
71 SM1200-71 Switch Assembly 72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	69	SM1200-69	Cable Sleeve
72 MSP512.SB Machine Screw Pan Head Phillips M5 x 12mm Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	70	SM1200-70	Base
Black 75 MSP616.S Machine Screw Pan Head Phillips M6 x 16mm 78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	71	SM1200-71	Switch Assembly
78 MSC616.S Csk Phillips Machine Screw M6 x 16mm 79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	72	MSP512.SB	
79 SM1200-79 Rubber Foot 80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	75	MSP616.S	Machine Screw Pan Head Phillips M6 x 16mm
80 SM1200-80 Screw 4 x 10mm 81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	78	MSC616.S	Csk Phillips Machine Screw M6 x 16mm
81 SM1200-81 Cable Grip 82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	79	SM1200-79	Rubber Foot
82 SM1200-82 Screw 4.2 x 16mm 83 SM1200-83 Cable Grip	80	SM1200-80	Screw 4 x 10mm
83 SM1200-83 Cable Grip	81	SM1200-81	Cable Grip
·	82	SM1200-82	Screw 4.2 x 16mm
84 SM1200-84 Base Plate	83	SM1200-83	Cable Grip
	84	SM1200-84	Base Plate

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland Tel: 01284 757500 • Email: sales@sealey.co.uk • Web: www.sealey.co.uk

Page 2 of 2 SM1200 ISSUE 2 DPL 14/07/25