

SEALEY


Quality MACHINERY

PARTS LIST:

THREE WHEEL BANDSAW/DISC SANDER

Model: **SM1214**

Version No: 1
Issue Date: 280801



Item	Part No.	Description
B01E	SM1214/B01E	Frame
B02	SM1214/B02	Wheel Support
B03	SM1214/B03	Axle Block
B04	SM1214/B04	Pin
B05	SM1214/B05	Bolt
B06	SM1214/B06	Washer
B07	SM1214/B07	Nut
B08	SM1214/B08	Tension Spring
B09	SM1214/B09	Tracking Bolt
B10	SM1214/B10	Tension Bolt
B11	SM1214/B11	Idle Wheel
B12	SM1214/B12	Wheel Tyre
B13	B/6202Z	Bearing
B14	SM1214/B14	Circlip
B15	SM1214/B15	Circlip
B16	SM1214/B16	Drive Wheel
B17E	SM1214/B17E	Rear Cover
B18	SM1214/B18	Screw
B18-1	SM1214/B18-1	Screw
B19	SM1214/B19	Washer
B20E	SM1214/B20E	Front Cover
B21E	SM1214/B21E	Hex. Bolt
B22	SM1214/B22	Washer
B23	SM1214/B23	Circlip
B24	SM1214/B24	Lock Knob
B25	SM1214/B25	Socket Head Bolt
B26	SM1214/B26	Pulley Hub
B27	SM1214/B27	Motor Pulley
B28	SM1214/B28	Motor
B29	SM1214/B29	Bolt
B30	SM1214/B30	Drive Belt
B31	SM1214/B31	Upper Guide Block
B32	SM1214/B32	Thumbscrew
B33	SM1214/B33	Blade Guide
B34	SM1214/B34	Blade Guide
B35	SM1214/B35	Thumbscrew
B36	SM1214/B36	Bearing Shaft
B37	SM1214/B37	Circlip
B38	B/629ZZ	Bearing
B39	SM1214/B39	Lower Guide Block
B40	SM1214/B40	Blade Guide
B41	SM1214/B41	Blade Guide

Item	Part No.	Description
B42	SM1214/B42	Blade Guide Support
B43	SM1214/B43	Blade Guard
B44	SM1214/B44	Screw
B45	SM1214/B45	Table Insert
B46	SM1214/B46	Work Table
B47	SM1214/B47	Nut
B48	SM1214/B48	Tilt Indicator
B49	SM1214/B49	Spring Support Bush
B50	SM1214/B50	Spring
B51	SM1214/B51	Lock Knob
B52	SM1214/B52	Pointer
-	SM1214/B53	Cable Clamp (not shown)
B57	See below	Blade
B58	SM1214/B58	Set Plate
B59	SM1214/B59	Socket Head Bolt
B62	SM1214/B62	Hex. Bolt
B63	SM14/D80G	Sanding Disc, 80G, Ø150mm
B64	SM1214/B64	Spindle Hub
B65	SM1214/B65	Aluminium Disc
B66	SM1214/B66	Bracket Rod
B67	SM1214/B67	Table Bracket
B68	SM1214/B68	Sanding Table
B69	SM1214/B69	Trunnion
B70	SM1214/B70	Pointer
B71	SM1214/B71	Sanding Disc Cover
B72	SM1214/B72	Pivot Mount
B73	SM1214/B73	Lock Knob
B74	SM1214/B74	Lock Knob
B75	SM1214/B75	Set Screw
B76	SM1214/B76	Socket Head Bolt
B78	SM1214/B78	Wheel Guard
B79	SM1214/B79	Lower Guard
B80	SM1214/B80	Screw
B81	SM1214/B81	Switch Box Base
-	SM1214/B82	Scale Ring (not shown)
-	SM1214/S	Switch Complete (not shown)
B83	SM1214/B83	Switch Box
B84	SM1214/B84	Switch Button 1A
B85	SM1214/B85	Switch Button 1B
B86	SM1214/B86	Switch Lock
-	SM1214/B87	Switch Lock Key (not shown)
B88	SM1214/B88	Screw

Item	Part No.	Description
B89	SM1214/B89	Dust Cloak
B90	SM1214/B90	Dust Cloak Cover
B91	SM1214/B91	Screw
B95	SM1214/B95	Wire Support
-	SM1214/B92	Relay (not shown)
-	SM1214/B93	Wire Set (not shown)
-	SM1214/B94	Terminal Block (not shown)
-	SM1214/A-1	Fence Assembly
-	SM1214/A-1-1	Fence
-	SM1214/A-1-2	Lock Knob

The following are not shown:

- **SM1214/A-2** Mitre Gauge Assembly
- SM1214/A-2-1 Mitre Gauge
- SM1214/A-2-4 Pointer
- SM1214/A-2-5 Ruler Complete
- SM1214/A-2-6 Lock Knob
- SM1214/A-2-7 Screw
- SM1214/A-2-8 Washer
- SM1214/A-2-9 Washer
- **SM1214/A-3** Circular Cutting Assembly
- SM1214/A-3-1 Clamp
- SM1214/A-3-2 Hex. Bar
- SM1214/A-3-3 Slide
- SM1214/A-3-4 Intermediate Pin
- SM1214/A-3-5 Centre Pin
- SM1214/A-3-6 Screw
- SM1214/A-3-7 Screw
- **SM1214/A-4** Sanding Belt Assembly
- SM1214/A-4-1 Sanding Belt
- SM1214/A-4-2 Lock Knob
- SM1214/A-4-3 Flat Plate
- SM1214/A-4-4 Rounded Plate

Blades available from your Sealey supplier:

Part No.	Description	
SM1214/B/06	1784 x 9.53mm	6tpi
SM1214/B/10	1784 x 9.53mm	10tpi
SM1214/B/14	1784 x 9.53mm	14tpi
SM1214/B/24	1784 x 9.53mm	24tpi

SEALEY Quality MACHINERY

Sole UK Distributor,
Sealey Group,
Bury St. Edmunds, Suffolk.

01284 757500

01284 703534 E-mail: sales@sealey.co.uk