





Sole UK Distributor,
Sealey Group,
Bury St. Edmunds,
Suffolk.

PARTS FOR
305mm 2-SPEED BANDSAW
Model: **SM64.V2**

PAGE 2 OF 2

Item	Part No.	Description	Item	Part No.	Description	Item	Part No.	Description	Item	Part No.	Description
1	SM64.V2/001	Cover Knob	38	SM64.V2/038	Connected Plate	76	SM64.V2/076	Screw	113	SM64.V2/113	Knob (B)
2	SM64.V2/002	Upper Cover	39	SM64.V2/039	Flat Washer	77	SM64.V2/077	Flat Washer	114	SM64.V2/114	Bracket
3	SM64.V2/003	Washer	40	SM64.V2/040	Hex. Socket Bolt	78	SM64.V2/078	Nut	115	SM64.V2/115	Bolt
4	SM64.V2/004	Spring	41	SM64.V2/041	Screw (A)	79	SM64.V2/079	Upper Left Blade Guard	116	SM64.V2/116	Fence
5	SM64.V2/005	Retaining Ring	42	SM64.V2/042	Sleeve	80	SM64.V2/080	Lower Blade Guard	117	SM64.V2/117	Knob (A)
6	SM64.V2/006	Circlip (Axle)	43	SM64.V2/043	Flat Washer	81	SM64.V2/081	Screw	118	SM64.V2/118	Plate
7	SM64.V2/007	Bearing	44	SM64.V2/044	Lock Nut	82	SM64.V2/082	Flat Washer	119	SM64.V2/119	Bolt
8	SM64.V2/008	Circlip (Axle)	45	SM64.V2/045	Plate	83	SM64.V2/083	Screw	120	SM64.V2/120	Gauge
9	See below	Blade	46	SM64.V2/046	Hex. Socket Bolt	84	SM64.V2/084	Bracket	121	SM64.V2/121	Gauge
10	SM64.V2/010	Upper Wheel	47	SM64.V2/047	Screw (B)	85	SM64.V2/085	Screw	122	SM64.V2/122	Work Table
11	SM64.V2/011	Upper Wheel Axle	48	SM64.V2/048	Pin (B)	86	SM64.V2/086	Eccentric Axle	123	SM64.V2/123	Table Insert
12	SM64.V2/012	Screw	49	SM64.V2/049	Rod (B)	87	SM64.V2/087	Bearing	124	SM64.V2/124	Pin
13	SM64.V2/013	Flat Washer	50	SM64.V2/050	Rod (A)	88	SM64.V2/088	Hex. Socket Bolt	125	SM64.V2/125	Side Guard Board
14	SM64.V2/014	Spring	51	SM64.V2/051	Retaining Ring	89	SM64.V2/089	Pin	126	SM64.V2/126	Knob
15	SM64.V2/015	Nut	52	SM64.V2/052	Pin (A)	90	SM64.V2/090	Axle	127	SM64.V2/127	Bolt
16	SM64.V2/016	Washer	53	SM64.V2/053	Slide Block	91	SM64.V2/091	Hex. Socket Bolt	128	SM64.V2/128	Stand for Work Table
17	SM64.V2/017	Star Washer	54	SM64.V2/054	Axle	92	SM64.V2/092	Bracket	129	SM64.V2/129	Hex. Socket Bolt
18	SM64.V2/018	Screw	55	SM64.V2/055	Screw	93	SM64.V2/093	Bearing	130	SM64.V2/130	Scale Label
19	SM64.V2/019	Plate	56	SM64.V2/056	Shaft Sleeve (B)	94	SM64.V2/094	Circlip (Axle)	131	SM64.V2/131	Rivet
20	SM64.V2/020	Adjusting Plate	57	SM64.V2/057	Shaft	95	SM64.V2/095	Hex. Socket Bolt	132	SM64.V2/132	Knob
21	SM64.V2/021	Spring Pin	58	SM64.V2/058	Shaft Sleeve (A)	96	SM64.V2/096	Pin	133	SM64.V2/133	Bracket
22	SM64.V2/022	Lower Cover	59	SM64.V2/059	Handle	97	SM64.V2/097	Flat Washer	134	SM64.V2/134	Rod
23	SM64.V2/023	Lower Wheel	60	SM64.V2/060	Screw	98	SM64.V2/098	Spring Washer	135	SM64.V2/135	Flat Washer
24	SM64.V2/024	Tyre	61	SM64.V2/061	Bracket	99	SM64.V2/099	Hex. Socket Bolt	136	SM64.V2/136	Screw
25	SM64.V2/025	Lower Wheel Axle	62	SM64.V2/062	Flat Washer	100	SM64.V2/100	Screw	137	SM64.V2/137	Scale Pointer
26	SM64.V2/026	Bracket	63	SM64.V2/063	Spring Washer	101	SM64.V2/101	Upper Left Blade Guard	138	SM64.V2/138	Screw
27	SM64.V2/027	Flat Washer	64	SM64.V2/064	Screw	102	SM64.V2/102	Bolt	-	SM64/ST	Stand Asm. (not shown)
28	SM64.V2/028	Spring Washer	65	SM64.V2/065	Tension Wheel	103	SM64.V2/103	Upper Right Blade Guard	Blades available from your Sealey supplier:		
29	SM64.V2/029	Bolt	66	SM64.V2/066	Spring Knob	104	SM64.V2/104	Bracket	Part No.	Description	
30	SM64.V2/030	Flat Washer	67	SM64.V2/067	Spring	105	SM64.V2/105	Screw	SM64/B06	2234mm x 12.5mm	6tpi
31	SM64.V2/031	Spring Washer	68	SM64.V2/068	Spring Knob	106	SM64.V2/106	Gear	SM64/B10	2234mm x 12.5mm	10tpi
32	SM64.V2/032	Nut	69	SM64.V2/069	Cover	107	SM64.V2/107	Flat Washer	SM64/B14	2234mm x 12.5mm	14tpi
33	SM64.V2/033	Belt	70	SM64.V2/070	Main Body	108	SM64.V2/108	Knob	SM64/B24	2234mm x 12.5mm	24tpi
34	SM64.V2/034	Key	71	SM64.V2/071	Switch	109	SM64.V2/109	Spring			
35	SM64.V2/035	Pulley	72	SM64.V2/072	Strain Relief	110	SM64.V2/110	Flat Washer			
36	SM64.V2/036	Screw	74	SM64.V2/074	Nut	111	SM64.V2/111	Knob			
37	SM64.V2/037	Motor	75	SM64.V2/075	Tracking Knob	112	SM64.V2/112	Knob (C)			

Issue: 1
Date Issued: 200902



01284 757500



01284 703534

Web: www.sealey.co.uk

E-mail: sales@sealey.co.uk