



Item	Part No.	Description
1	START560.01	TAPPING SCREW (M5x14)
2	START240.02	HANDLE COMPLETE (INC: 4 & 6)
3	START560.03	FUSE COVER
5	START560.05	BUSHING
7	START560.07	RD HEAD S/T SCREW M3X16
8	SN8.S	STEEL NUT M8 ZINC DIN934 (SINGLE)
9	START180.F	FUSE 50Amp (SINGLE)
9	START180.F20	FUSE 50Amp Pack of 20
10	START560.08	AMMETER (0-60A) (PRE-OCTOBER 2013)
11	START560.11	FUSE TERMINAL COMPLETE
12	START240.12	ROCKER SWITCH
13	START240.13	POWER SWITCH
14	START240.14	RECTIFIER
15	FWM5.S	FLAT WASHER M5 SINGLE
16	SWM5.S	SPRING WASHER M5 ZINC (SINGLE)
17	SN5.S	STEEL NUT M5 ZINC DIN934 (SINGLE)
18	START240.18	MAIN TRANSFORMER
19	START560.33	WHEEL
20	START560.32	WHEEL RETAINING RING

Item	Part No.	Description
21	START240.21	PANEL SET
22	START240.22	WHEEL AXLE (8x347)
23	START240.23	BOTTOM PANEL
24	START560.26	FOOT
25	MSP512.S	MACHINE SCREW PAN HEAD PHILLIPS M5x12mm
26	START560.28	TERMINAL COMPLETE
27	START240.27	FRONT PANEL
28	START240.28	UPPER PANEL
29	SN10.S	STEEL NUT M10 ZINC DIN934(SINGLE)
30	START240.30	RD HEAD S/T SCREW M4.6 X 13
31	START560.22	PHILLIPS BOLT M5X25
32	START240.32	POWER CABLE
33	START560.27P	POSITIVE CLAMP (RED)
33	START560.27N	NEGATIVE CLAMP (BLACK)
--	START560.35	THERMOSTAT (NOT SHOWN)
--	START240.35	FUSEABLE LINK FOR RECTIFIER (NOT SHOWN)
--	START560.FL	FUSIBLE LINK 100A 75mV (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.