


Parts Information:

Tile Cutter 100mm 230V **Model No: TC100**



Item	Part No.	Description
1	TC100.01	Tile Guide
2	TC100.02	Wing Nut
3	TC100.03	Washer
4	TC100.04	Blade Guard
5	TC100.05	Screw For Wing
6	TC100.06	Guard Support
7	TC100.07	Guard Support Screw
8	SN8.SW	Wing Nut M8 (Single)
9	TC100.09	Washer
10	TC100.10	Blade Dia 100mm Diamond
11	TC100.11	Washer
12	TC100.12	Mitre Support

Item	Part No.	Description
13	TC100.13	Right Cutting Table
14	TC100.14	Screw For Cutting Table
15	TC100.15	Left Cutting Table
16	TC100.16	Mitre Guide
17	TC100.17	Cable Fixer
21	TC100.21	Motor
22	TC100.22	Frame
23	TC100.23	Switch
24	TC100.24	Screw For Motor
25	TC100.25	Rubber Grommet
27	TC100.27	Rubber Feet

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk

Page 1 of 1