



Item	Part No.	Description
1	TIGACDC200-01	Top Handle
2	TIGACDC200-02	Machine Case
3	TIGACDC200-03	Main Control Board
4	TIGACDC200-04	Power Cable
5	TIGACDC200-05	Plastic Panel (Rear)
6	TIGACDC200-06	Power Switch
7	TIGACDC200-07	Connector
8	TIGACDC200-08	Fan Cover
9	TIGACDC200-09	Bottom Panel
10	TIGACDC200-10	Magnetic Valve
11	TIGACDC200-11	Fan
12	TIGACDC200-12	Digital Display PCB

Item	Part No.	Description
13	TIGACDC200-13	Front Panel
14	TIGACDC200-14	Connection Plate
15	TIGACDC200-15	Plastic Panel (Front)
16	TIGACDC200-16	Potentiometer Knob
17	TIGACDC200-17	Socket
18	TIGACDC200-18	Output Socket Panel
19	TIGACDC200-19	Euro Connector
20	TIGACDC200-20	Gas Connector
--	TIGACDC200-21	Tig Torch (Not Shown)
--	TIGACDC200-22	Earth Clamp (Not Shown)
--	TIGACDC200-23	Electrode Holder (Not Shown)
--	TIGACDC200-24	Foot Pedal (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.