



**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Parts Information:  
**Air Operated Fuel Drainer**  
**Model No: TP200**

Item	Part No.	Description
1	TP200.01	HOSE 1/2" x 1m
2	TP200.02	HOSE 3/8" x 1m
3	TP200.03	HOSE 5/16" x 1m
4	TP200.04	OIL FILTER
5	TP200.05	EXTENSION HOSE
6	TP200.06	RELIEF VALVE CAP
7	TP200.07	TANK STRAP
8	TP200.08	CONTAINER
9	TP200.09	WHEEL,CASTOR (75x7x32x106)
10	TP200.10	TANK LID
11	TP200.11	AIR INTAKE ASS'Y
--	TP200.11-1	AIR INTAKE BRACKET (3PCS) (NOT SHOWN)
--	TP200.11-2	BODY FOR AIR INTAKE (NOT SHOWN)
--	TP200.11-3	HOSE CONNECTOR (NOT SHOWN)
--	TP200.11-4	RED KNOB SHAFT (NOT SHOWN)
12	TP200.12	AIR REGULATOR COMPLETE
12-1	TP200.12-1	GAUGE 35psi 50mm OD REAR FITTING
12-2	TP200.12-2	GAUGE COVER
--	TP200.12-3	REGULATOR RING (NOT SHOWN)
--	TP200.12-4	HOSE CONNECTOR FOR AIR REGULATOR (NOT SHOWN)
--	TP200.12-5	CONNECTING BLOCK (NOT SHOWN)
--	TP200.12-6	REGULATOR BODY (NOT SHOWN)
--	TP200.12-7	VALVE FOR AIR REGULATOR (NOT SHOWN)
13	TP200.13	PUMP
--	TP200.13A	PUMP BRACKET (NOT SHOWN)
14	TP200.14	HOSE (c/w HOSE CONNECTORS)18mm x 2000mm
15	TP200.15	WHEEL,FIXED (206x13x41)
16-1	TP200.16-1	ADAPTOR H19 x M10 x 41.5L
16-2	TP200.16-2	ADAPTOR H19 x M14 x 41.5L
16-3	TP200.16-3	ADAPTOR H19 x M12 x 41.5L
16-4	TP200.16-4	ADAPTOR H19 x 6.5mm x 40.5L
16-5	TP200.16-5	ADAPTOR H19 x 8.5mm x 40.2L

Item	Part No.	Description
16-6	TP200.16-6	ADAPTOR H19 x 10.5mm x 40.2L
17	TP200.17	EARTH CABLE (GREEN)
18	TP200.18	EARTH CABLE (YELLOW)
19	TP200.19	HOSE
--	TP200.19-1	MAIN HOSE ADAPTOR (F) (NOT SHOWN)
--	TP200.19-2	MAIN HOSE CONNECTOR (NOT SHOWN)
--	TP200.19-3	MAIN HOSE CONNECTOR (NOT SHOWN)
20	TP200.20	HOSE 10mm x 16mm x 550mm
21	TP200.21	HOSE 4mm x 8mm x 1000mm
22	TP200.22	WIRE HOSE
23	TP200.23	PU HOSE 9mm x 13mm x 680mm
24	TP200.24	AIR FILTER SEAT
25	TP200.25	LEVEL TUBE
26	TP200.26	ELBOW
27	TP200.27	PAD FOR ADAPTER SEAT
28	TP200.28	ADAPTER SEAT
29	TP200.29	MAIN HOSE ADAPTOR
--	TP200.30	OVERFLOW VALVE (NOT SHOWN)
--	TP200.31	ELBOW (NOT SHOWN)
--	TP200.32	RED KNOB (NOT SHOWN)
--	TP200.33	GREEN KNOB (NOT SHOWN)
--	TP200.34	FRAME ASSEMBLY (NOT SHOWN)
--	TP200.35	PLASTIC ELBOW FOR TANK (NOT SHOWN)
--	TP200.36	PLASTIC TUBE (BLACK) (NOT SHOWN)
--	TP200.37	SCREW (NOT SHOWN)
--	TP200.38	HOSE CLIP (NOT SHOWN)
--	TP200.39	PLASTIC TUBE CLAMP (NOT SHOWN)
--	TP200.40	BOLT FOR TOP FRAME (NOT SHOWN)
--	TP200.41	HANDLE END CAP (NOT SHOWN)
--	TP200.13-OLD	PUMP (OLD) (NOT SHOWN)
--	TP200.42	BRACKET (NOT SHOWN)
--	TP200S.24	AIR FILTER SEAT (NOT SHOWN)
--	TP200.V3-05A	TANK LID c/w NUT (NOT SHOWN)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**Sealey Group**, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk