



Item	Part No.	Description
1	TP68-V2-01	Pump Head
2	TP68-V2-02	Discharge Spout Seal
3	TP68-V2-03	Discharge Spout
4	TP68-V2-04	Discharge Spout Coupling Nut
5	TP68-V2-05	Piston Rod Nut
6	TP68-V2-06	Piston Rod Seal
7	TP68-V2-07	Pump Handle
8	TP68-V2-08	Pump Handle Grip
9	TP68-V2-09	Pump Handle Lever
10	TP68-V2-10	Rivet (A)
11	TP68-V2-11	Rivet (B)
12	TP68-V2-12	Pump Handle Lever Pin
13	TP68-V2-13	Split Pin
14	TP68-V2-14	Piston Rod
15	TP68-V2-15	C-Ring

Item	Part No.	Description
16	TP68-V2-16	Valve Spring
17	TP68-V2-17	Valve Plate
18	TP68-V2-18	Valve Base
19	TP68-V2-19	Valve Nut
20	TP68-V2-20	Container
21	TP68-V2-21	Foot Valve Seal
22	TP68-V2-22	Base Plate Rivet
23	TP68-V2-23	Base Plate (A)
24	TP68-V2-24	Base Plate (B)
25	TP68-V2-25	Base
26	TP68-V2-26	Telescopic Tube
27	TP68-V2-27	Telescopic Tube Seal
28	TP68-V2-28	Telescopic Tube
29	TP68-V2-29	Container Gasket

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.