



WIRING DIAGRAM T35A			v1.0 04/2017
Item	Qty.	Desc.	Ref.
1	1	3 Core Cable with Plug 240V UK (T35A)	WP-T31/021
	1	3 Core Cable with Plug 115V UK (T35AL)	WP-T35L/022
2	1	Circuit Board with Leads 240V (T35A)	WP-T35/029
	1	Circuit Board with Leads 115V (T35AL)	WP-T35L/029
3	1	Motor with Leads 240V UK (T35A)	WP-T35/014
	1	Motor with Leads 115V UK (T35AL)	WP-T35L/014
4	1	Auto Start Socket 240V UK (T35A)	WP-T35A/008
	1	Auto Start Socket 115V UK (T35AL)	WP-T35AL/008
5	1	Shaker Solenoid Pump with M4x10mm Screws	WP-T35/017
6	1	Switch	WP-T35/006
7	1	Indicator Light	WP-T35/004
8	1	Pressure Switch	WP-T35/012



Trend Machinery & Cutting Tools Ltd.
 Odhams Trading Estate St Albans Road
 Watford WD24 7TR England
 Tel: 0044(0)1923 249911
 technical@trendm.co.uk
 www.trend-uk.com

© Copyright Trend 2017. No part of this publication may be reproduced, stored or transmitted in any form without prior permission. Our policy of continuous improvement means that specifications may change without notice. Trend Machinery and Cutting Tools cannot be held liable for any material rendered unusable or any form of consequential loss. E&OE. ® All trademarks acknowledged.



DIAGW/T35A V1.0