

Thank you for purchasing a Sealey Product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- WARNING!** Ensure Health & Safety, local authority and general workshop practice regulations are adhered to when using this equipment.
- ✓ Familiarise yourself with the applications, limitations and potential hazards of this spring reducer.
- ✓ Maintain the spring reducer in good condition. Replace or repair damaged parts. Use genuine parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- WARNING!** Wear approved safety eye protection (standard spectacles are not adequate).
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Remove ill fitting clothes. Remove ties, watches, rings and other loose jewellery. Contain or tie back long hair.
- ✓ Wear appropriate protective clothing.
- ✓ Keep children and unauthorised persons away from the working area.
- ✓ Ensure jaws are correctly engaged on spring before commencing compression.
- ▲ **DANGER!** Stop compressing the spring before it becomes coil bound.
- X DO NOT leave compressed spring unattended.
- X DO NOT operate spring reducer if parts are damaged or missing as this may cause failure and/or personal injury.
- X DO NOT use the spring reducer for a task it was not designed to perform.
- X DO NOT allow untrained persons to use the spring reducer.
- X DO NOT operate spring reducer if you are tired, or under the influence of alcohol, drugs or intoxicating medication.
- ✓ When not in use clean and store the spring reducer in a safe, dry, childproof location.
- WARNING!** The warnings, cautions and instructions discussed in this manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.



2. DESCRIPTION & SPECIFICATION

Heavy-duty Chrome Vanadium construction. Long reach arms compress higher proportion of new coil spring. Allows even and safe compression of spring prior to installation of regular coil spring compressor.

Drive:1/2" Sq

Max. Reach350mm