

INSTRUCTIONS FOR:

# AIR SUCTION DENT PULLER MODEL: RE101

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/ OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

### 1. SAFETY INSTRUCTIONS

- WARNING! Ensure Health & Safety, local authority and general workshop practice regulations are adhered to when using this
- **WARNING!** Disconnect from air supply before changing suction cups, servicing or performing any maintenance. Maintain the puller in good condition (use an authorised service agent).
- Replace or repair damaged parts. Use genuine parts only. Unauthorised parts may be dangerous and will invalidate the warranty. Use in a suitable work area. Keep area free from unrelated materials and ensure that there is adequate lighting. Before each use check condition of tool. If any component is worn or
- damaged replace immediately.
- WARNING! Always wear approved eye (or face) and hand protection
- when operating the puller. Remove ill fitting clothing. Remove ties, watches, rings, other loose
- jewellery and contain and/or tie back long hair.
  Wear appropriate protective clothing and keep hands and body clear of working
- parts. Maintain correct balance and footing. **DO NOT** over reach, ensure the floor is not slippery, wear non-slip shoes.
- Keep children and unauthorised persons away from the working area.
- Ensure workpiece is secure before operating the puller.
- **WARNING!** Ensure correct air pressure is maintained and not exceeded. Max air pressure = 140psi.  $\Box$
- Keep air hose away from heat, oil and sharp edges. Check air hose for wear before each use and ensure that all connections are secure.
- DO NOT use the puller for a task it is not designed to perform.
- DO NOT operate the puller if any parts are damaged or missing as this may cause failure and/or personal injury.
- **DO NOT** carry the puller by the hose, or yank the hose from the air supply. **DO NOT** place air line attachments close to your face and do not point at other
- people or animals.
- DO NOT direct air from the air line at yourself or others.

  DO NOT operate puller when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- When not in use disconnect from air supply and store in a safe, dry, childproof location.

# 2. DESCRIPTION

Air activated suction pad keeps firm hold of panel while slide hammer is used to ease out dents and depressions without damage to the paint surface. Ideal for initial panel reshaping. Supplied with large and small suction pads.

## 3. OPERATION

- Assemble the hose, valve and coupler onto the slide hammer as displayed in the parts diagram on the following page. Connect assembled unit to an air compressor. Set the supply regulator between 70psi Min. and 140psi Max.
- With the valve in the off position, place the suction cup over the dent.
- When in place open the air valve, the suction cup will form a vacuum firmly attaching it to the body panel.
- Use the slide hammer to pull the dent out. Do not apply to much force to the slide hammer.
- When you have finished turn off the air valve to remove the puller from the body panel.
- Disconnect from air supply, remove the suction cup from the puller and store in a safe, dry, childproof location.

# **MAINTENANCE**

- Check condition of air hose and suction cups regularly, if damaged replace using genuine parts only.
- Keep tool in a clean serviceable condition, use a damp cloth to clean.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.


**IMPORTANT:** No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our catalogue and latest promotions call us on 01284 757525 and leave your full name, address and postcode.



Sole UK Distributor Sealey Group, Bury St. Edmunds, Suffolk.



01284 703534



www.sealey.co.uk sales@sealey.co.uk



Issue No: 2 - 22/12/08