

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- WARNING!** Ensure Health and Safety, local authority and general workshop practice regulations are adhered to when using tools.
- DO NOT** use tools if damaged.
- ✓ Maintain tools in good and clean condition for best and safest performance.
- ✓ Ensure that a vehicle which has been jacked up is adequately supported with axle stands.
- ✓ Wear approved eye protection. A full range of personal safety equipment is available from your Sealey dealer.
- ✓ Wear suitable clothing to avoid snagging. **DO NOT** wear jewellery and tie back long hair.
- DO NOT** attempt to start engine or move vehicle whilst in gear with timing devices fitted.
- ✓ Always display warning notification on steering wheel when timing engine components.
- ✓ Account for all tools, locking bolts, pins and parts being used and do not leave them in or near the engine.
- WARNING!** Incorrect camshaft timing can result in contact between valve head and piston crown causing damage to the engine.
- ▲ **IMPORTANT:** Always refer to the vehicle manufacturer's service instructions, or a proprietary manual, to establish the current procedure and data.



2. INTRODUCTION

Comprehensive kit for timing 2.0/2.2 and 2.4 Duratorq chain driven diesel engines. Also Includes sprocket retaining plate and access cover removal plate tools, for injection pump removal/installation. Supplied in carry-case.

Item	Description	OEM No
1	Access Cover Removal Plate	21 238
2	Sprocket Retaining Plate	303 1151
3	Flywheel Locking Pin	21 251
4	Flywheel Locking Pin	21 234
5	Sprocket Retaining Plate Locating Pins	
6	Camshaft and Fuel Pump Sprocket Locking Pins 6mm	
7	Tensioner Locking Pin	

3. APPLICATIONS

FORD

Mondeo 2.0/2.2 TDdi/TDCi (01 - 07)
Transit 2.0/2.2/2.4 TDdi/TDCi (00 - 08)

JAGUAR


X-Type 2.0/2.2 D (03 - 08)

LDV

Convoy 2.4 TD/Tdi (02 - 06)

ENGINE CODES

ABFA, D3FA, F3FA, D5BA, D6BA, FMBA, FMBB, F1FA, HJBA, HJBB, HJBC, HJBE, N7BA, N7BB, SDBA, QJBA, QJBB, QJBC, QJBD, D2FA, D4FA, D0FA, F4FA, FXFA, H9FB, JXFA, PHFA, ZSD424.



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.