

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.


IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.


1. SAFETY INSTRUCTIONS

1.1. ELECTRICAL SAFETY

WARNING! It is the responsibility of the owner and the operator to read, understand and comply with the following: You must check all electrical products, before use, to ensure that they are safe. You must inspect power cables, plugs, sockets and any other connectors for wear or damage. You must ensure that the risk of electric shock is minimised by the installation of appropriate safety devices. A Residual Current Circuit Breaker (RCCB) should be incorporated in the main distribution board. We also recommend that a Residual Current Device (RCD) is used. It is particularly important to use an RCD with portable products that are plugged into a supply which is not protected by an RCCB. If in any doubt consult a qualified electrician. You may obtain a Residual Current Device by contacting your Sealey dealer. **You must** also read and understand the following instructions concerning electrical safety.

- 1.1.1. The **Electricity at Work Act 1989** requires all portable electrical appliances, if used on business premises, to be tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.
- 1.1.2. The **Health & Safety at Work Act 1974** makes owners of electrical appliances responsible for the safe condition of those appliances and the safety of the appliance operators. **If in any doubt about electrical safety, contact a qualified electrician.**
- 1.1.3. Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply. See 1.1.1. and 1.1.2. and use a Portable Appliance Tester.
- 1.1.4. Ensure that cables are always protected against short circuit and overload.
- 1.1.5. Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that none is loose.
- 1.1.6. **Important:** Ensure that the voltage marked on the appliance matches the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating at right.
- 1.1.7. **DO NOT** pull or carry the appliance by the power cable.
- 1.1.8. **DO NOT** pull the plug from the socket by the cable.
- 1.1.9. **DO NOT** use worn or damaged cables, plugs or connectors. Immediately have any faulty item repaired or replaced by a qualified electrician. When an ASTA/BS approved UK 3 pin plug is damaged, cut the cable just above the plug and **dispose of the plug safely.** Fit a new plug according to the following instructions (UK only).

- a) **Connect the GREEN/YELLOW earth wire to the earth terminal 'E'.**
- b) **Connect the BROWN live wire to the live terminal 'L'.**
- c) **Connect the BLUE neutral wire to the neutral terminal 'N'.**
- d) **After wiring, check that there are no bare wires, that all wires have been correctly connected, that the cable outer insulation extends beyond the cable restraint and that the restraint is tight.** Double insulated products, which are always marked with this symbol , are fitted with live (brown) and neutral (blue) wires only. To rewire, connect the wires as indicated above. **DO NOT** connect either wire to the earth terminal.



- 1.1.10. Products which require more than 13 amps are supplied without a plug. In this case you must contact a qualified electrician to ensure that a suitably rated supply is available. We recommend that you discuss the installation of an industrial round pin plug and socket with your electrician.
- 1.1.11. If an extension reel is used it should be fully unwound before connection. A reel with an RCD fitted is preferred since any appliance plugged into it will be protected. The cable core section is important and should be at least 1.5mm², but to be absolutely sure that the capacity of the reel is suitable for this product and for others which may be used in the other output sockets, we recommend the use of 2.5mm² section cable. If extension reel is to be used outdoors, ensure it is marked for outdoor use.

1.2. GENERAL SAFETY INSTRUCTIONS

- WARNING!** Compressor must only be serviced by an authorised agent.
- ✓ Familiarise yourself with the application and limitations of the compressor.
- ✓ Ensure the compressor is in good order and condition before use. If in any doubt do not use the unit and contact an electrician / service agent.
- ✓ Before moving, or maintaining the compressor, ensure it is unplugged from the mains supply and that the air brush is disconnected.
- ✓ Do not attach anything other than an air brush to the compressor.
- ✓ Ensure the safe working pressure of any air brush used, exceeds the units output pressure.
- ✓ Ensure the area selected for spraying is provided with suitable ventilation.
- ✓ Ensure the compressor is turned off before disconnecting the air brush.
- ✓ To move the compressor use the handle only.
- ✓ Use the compressor in a well ventilated area and ensure it is placed on a firm surface.
- ✓ Keep tools and other items away from the compressor when it is in use, and keep area clean and clear of unnecessary items.
- ✓ Ensure the air brush supply hose is not tangled, twisted, or pinched.
- ✓ Keep children and unauthorised persons away from the working area.
- X **DO NOT** disassemble compressor for any reason. The unit must be checked and serviced by an approved service agent.
- X **DO NOT** use the compressor outdoors, or in damp, or wet locations.
- X **DO NOT** operate within the vicinity of flammable liquids, gases or solids.
- X **DO NOT** touch compressor cylinder head as it may be hot and will remain so for some time after shutdown.
- X **DO NOT** attempt to move the compressor by pulling the air brush supply hose. Only move the compressor by its handle.
- X **DO NOT** use this product to perform a task for which it has not been designed.
- ▲ **DANGER! DO NOT** direct the output jet of air towards people or animals.
- ✓ When not in use, store the compressor carefully in a safe, dry, childproof location.
- ✓ Switch off the compressor when the air brush is not being used.
- ✓ Wear approved eye protection and a suitable respirator when painting.

- ❑ **WARNING! If an electrical fuse blows, ensure it is replaced with an identical fuse type and rating.**
- x **DO NOT** eat or smoke whilst spraying.
- x **DO NOT** spray near naked flames.
- x **DO NOT** leave the compressor running unattended.
- x **DO NOT** operate the compressor whilst under the influence of drugs, alcohol or other intoxicating medication.
- x **DO NOT** carry the compressor while operating the air brush.
- x **DO NOT** cover the compressor or restrict air flow around the machine whilst operating.
- x **DO NOT** allow anyone to operate the compressor unless they have received full instructions.

2. SPECIFICATION

Quiet running piston pump compressor, powered by a 125Watt electric motor with an air filter regulator and pressure gauge. Features a 3ltr reservoir for building up air prior to use. Supplied in a metal casing for added protection. Fitted with anti-vibration feet, two air brush holders and carry handle. Requires no lubrication and the air supply from the unit is oil free.


2.1. SPECIFICATION	MODEL NO. AB9001
Motor power	125W
Input	230V - 1A
Free Air Delivery:	0.8cfm
Air pressure.....	50psi
Air outlet size	1/8" BSP

3. PREPARATION

- 3.1. Remove compressor from packaging and inspect for any damage. If anything is found to be missing or damaged contact your supplier.
- 3.2. Confirm that the mains voltage corresponds with the voltage shown on the compressor specification.
- 3.3. The compressor should be operated in a position that allows good air circulation around the unit.

4. OPERATION

- ❑ **WARNING! Ensure that you have read, understood and apply Section 1 safety instructions.**
- 4.1. Situate the compressor in a convenient position for the air brush work to be undertaken. Ensure that it is resting on a stable and level surface that will not be affected by the minor vibration of the unit. Do not rest the compressor on sheets of paper or card etc. Ensure the rubber feet are in direct contact with the work surface.
- 4.2. Do not operate the compressor in an enclosed space and ensure that there is adequate air space around the unit.
- 4.3. Attach the air brush hose to the 1/8" BSP air outlet.
- 4.4. Plug the mains lead into a convenient socket but do not switch on until you have fully prepared the medium to be sprayed, the air brush and the item/surface to be sprayed.
- 4.5. Switch on the unit. The compressor will provide a constant air flow to the air brush. The compressor motor will cut-in and out automatically to maintain the required pressure as determined by the user setting on the regulator.
- 4.6. Refer to the air brush instructions for the correct operating pressure. To adjust the pressure, first pull up the regulator knob to unlock it. To increase the pressure, turn the knob clockwise. To decrease the pressure, turn the knob anti-clockwise. Monitor the result on the pressure gauge. When correct pressure has been obtained, push down the regulator knob to lock it.
- 4.7. Refer to the manufacturers instructions with your air brush for the correct spraying technique. Do not leave the compressor running for any length of time with the air brush attached but not being used. If there is a pause in your work switch the compressor off.
- 4.8. If the operating note of the compressor changes, there may be a blockage within the air brush or the air hose may be pinched. The unit should be switched off immediately and the source of the blockage investigated and eliminated.
- 4.9. When the task is complete use the compressor to blow a suitable cleaning solvent through your air brush.
- 4.10. Switch the unit off. Operate the air brush to relieve any



pressure left in the hose. Disconnect the air brush from the compressor.

- 4.11. During and immediately after operation, the finned pump head may be hot and should not be touched. If the unit must be moved, lift it by the handle only. Allow the unit to cool before storing it.
- 4.12. Should there appear to be any loss of efficiency when spraying, ensure first that the air brush is scrupulously clean and functioning properly. If the air brush is satisfactory then refer to the trouble shooting guide for the compressor.

5. MAINTENANCE & TROUBLESHOOTING

Before carrying out any maintenance, switch compressor off, unplug it from the mains electricity supply, depressurise the tank and allow unit to fully cool down.

- WARNING! Never drain or attempt to remove the filter bowl if the compressor is pressurised.**
- 5.1. Keep the compressor clean and free of dust. **DO NOT** use cleaning agents. Wipe the compressor using a slightly dampened cloth and blow it over with compressed air if available.
- 5.2. Ensure that the ventilation openings are clear. Do not allow any extraneous material to enter the unit via any of the ventilation openings.
- 5.3. Routinely drain any moisture from the regulator filter bowl by carefully pressing the spring loaded valve at the bottom of the bowl. Periodically remove the filter bowl and clean in a mild detergent solution. **DO NOT** use solvents, thinners or alcohol to clean the filter bowl.
- 5.4. To prevent corrosion to the tank interior, drain it on a regular basis by opening the drainage tap at the bottom of the tank to release any moisture that may have accumulated. After draining ensure the drainage tap is fully closed.
- 5.5. The troubleshooting guide below is intended to give you an indication of what type of fault may have developed with your compressor over a long period of service. The chart is not intended as a guide on how to repair the fault yourself. In all cases we recommend that the compressor be returned to an authorised service agent for rectification.

FAULT	CAUSE	REMEDY
Low air flow.	<ul style="list-style-type: none"> • Air valve plate or air valve is damaged. • Diaphragm damaged. • The head screws are too loose. • Air hose leaking. 	<ul style="list-style-type: none"> • Change the defective air valve plate or air valve. • Change diaphragm. • Tighten the screws equally. • Check seals or renew hose.
Noisy operation.	<ul style="list-style-type: none"> • The head screws are too tight. • Bearing fault. 	<ul style="list-style-type: none"> • Loosen the screws and then tighten them equally. Do not overtighten. • Contact authorised service agent.
Humming noise but does not work.	<ul style="list-style-type: none"> • The head screws are too tight. • Armature fault. 	<ul style="list-style-type: none"> • Loosen the screws and then tighten them equally. Do not overtighten. • Contact authorised service agent.
The compressor does not stop and the safety valve is tripped.	<ul style="list-style-type: none"> • Irregular functioning of compressor or broken pressure switch. 	<ul style="list-style-type: none"> • Switch off compressor and contact authorised service agent.

Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or phone 01284 757500.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR



01284 757500



www.sealey.co.uk



01284 703534



sales@sealey.co.uk