


SEALEY

PORTABLE CAR LIFT 2.25 TONNE 750W/230V

MODEL NO: **CLM2250**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



1. SAFETY

- ✓ Read all warnings, safety instructions and other instructions. Failure to follow all the instructions and safety instructions can result in a risk of personal injury and/or material damage.
- ✓ The lift has to be used only referring to the type of vehicle support specified by the manufacturer.
- ✓ The manufacturer assumes no responsibility for personal injury or damage to property arising from the handling, use or maintenance of the product in any way other than that described in these instructions.
- ✓ Special training has to be given to the operator and the persons who are permitted to stand under the vehicle during lifting and lowering. Only to be used by operators who have been trained to use it and those who are fully conversant with this manual.
- ✓ Persons are only permitted to stand under a moving load in extreme circumstances where movements of the load should be kept as short as possible.
- ❑ **WARNING!** indicates a dangerous or potentially dangerous situation that could lead to fatal or serious personal injury if the instructions are not followed.
- IMPORTANT!** indicates instructions that must be followed in order to prevent damage to property.
- ✓ Familiarise yourself with the controls on the product and how to use them. Persons who are not trained or familiar, with these instructions must not use the product.
- ✓ Incorrect use can result in the risk of fatal or serious personal injury and/or material damage.
- ✓ This product is a portable vehicle lift. Use the product only for its intended purpose.
- ✓ Check the product for cracks in weld joints as well as damaged, loose, worn or missing parts each time before use.
- ✓ Keep all body parts away from the product during use.
- ✓ Never modify the product in any way.
- ✓ In the event of oil spillage ensure an oil spill kit is to hand. Consult Sealey website for Materials Safety Data Sheet for characteristics of fluids included with the product.
- ✓ Firefighting procedure/equipment should be in accordance with the Materials Safety Data Sheet.
- ✓ Only use lifting points recommended by the vehicle manufacturer.
- ✓ After installation the name plate shall remain readily visible.
- ✓ After installation at the user's site check that the vehicle lift and the associated safety and protective devices are correctly installed and function in a proper manner.
- ✓ Always check the weight of the vehicle before lifting. Never exceed the maximum permitted load for the product.
- ✓ Overloading damages the products and entails a risk of serious personal injury.
- ✓ Never adjust the safety valve.
- ✓ Inspect the product carefully at least once a year. Replace any damaged or worn cables and hoses. Check that the safety and warning labels on the product are intact and legible. Replace any labels that are illegible or have gone missing.
- ✗ **DO NOT** use the product until any worn or damaged parts have been replaced.
- ✗ Never attempt to lift loads that are not centred or are poorly balanced. Incorrect loading can damage the product and entails a risk of serious personal injury.
- ✓ Take steps to ensure that the load cannot move or tip over while being raised or lowered. If the product is being used beside a road, traffic can cause the vehicle to move.
- ✓ Make sure that nobody is inside the vehicle and apply the parking brake.
- ✓ Secure the load that is to be lifted with wedges or similar, so that it cannot slide or move.
- ✓ Never climb into a raised or supported vehicle and do not start the engine.
- ✗ **DO NOT** touch hot parts – risk of getting burned.
- ✓ Wear suitable personal protective equipment, such as safety glasses, safety helmet, gloves, etc.
- ✓ The surface the lift is used on, must be dry, flat and able to support a load of 34.4bar.
- ✓ Route the power cord and the hydraulic hoses so that they cannot be trodden on or driven over, so that there is no risk of tripping over them, or of them being put under strain.
- ✗ **DO NOT** wear loose-fitting clothing, jewellery, watches, etc., that can get caught in moving parts or conduct electricity.
- ✓ Evacuate the area immediately if the load is threatening to collapse the vehicle lift.
- ✓ **Check that both safety lock bars are applied before anyone goes in the vicinity of the raised load.**
- ✓ Never open the filler plug on the electric pump when the product is in use.
- ✓ Contact your stockist for technical assistance or repairs. The warranty ceases to apply if the product has been modified in any way, damaged as a result of an accident, negligence or incorrect use, or has been repaired by unauthorised personnel.
- ✓ Always keep the product clean.
- ✓ Store the product fully lowered when not in use.
- ✗ **DO NOT** use hydraulic equipment at temperatures above 65°C. High temperatures weaken the hose material and cause seals to soften, which entails a risk of hydraulic fluid leakage and/or other damage to property.

- ✓ Make sure that no parts are damaged, missing or worn.
- ✓ Check for other factors that could affect the operation of the power tool. Check that the lifting blocks are placed on the plates on the lifting frames. Never use the product if it is damaged or worn, or if it is not functioning normally.
- ✗ **DO NOT** use the product before damaged or worn parts have been replaced.
Take it to an authorised service centre for inspection and possible repair.
- ✓ Check that the work area is free from objects that could affect the raising/lowering of the vehicle. Also check above the product.
Remove any obstructions. Check that there are no people or animals in the work area.
- ✓ Familiarise yourself with the controls on the product and how to use them.
- ✓ Persons who are not familiar with these instructions must not use the product. Nobody other than the user may be in the work area.
- ✓ Ensure that everyone who is going to be in the vicinity of the product is aware of it and takes suitable precautions.
- ✗ **DO NOT** interrupt lifting until one of the locking positions has been reached.
- ✗ **DO NOT** interrupt lowering until the product has been completely lowered.
- ✗ **DO NOT** allow children to use the product.
- ✗ Never use the product if you are tired or under the influence of drugs, alcohol or medication.
- ✓ Never exceed the maximum permitted load for the product. Make sure that nobody is inside the vehicle that is to be lifted. Check that the vehicle is well balanced at both ends. Only use the lifting points specified by the vehicle manufacturer. Never lift only one side, one corner or one end of the vehicle.
- ✓ Lower the raised vehicle in the nearest position to the ground level if the maximum permissible wind speed is exceeded and at the end of working time.
- ✓ Never pull the cable on the remote control or power cord to move the power unit, this can damage the cable.
- ✓ Never pull the hydraulic hoses to move the lifting frames - this can damage the hoses.
- ✓ Make sure to check the product at least once a year. Replace damaged or worn electric cables, hydraulic hoses, markings or warnings.

2. INTRODUCTION

A transportable lifting system which makes total vehicle lifting, for maintenance or detailing, much more convenient. Each Strut weighs less than 40kg, and is on wheels for easy positioning. Automatic safety lock bars, with dual locking positions. A low clearance height of just 72mm, making it ideal for custom, sports and race vehicles.


3. SPECIFICATION

Model No:CLM2250
 Capacity: 2.25 tonnes
 Weight: 104.4kg
 Sound: <70dBA
 Max. allowed wind speed during use: <60mph/96.5kph
 Fuse Rating: 13amp
 Lock Spacing: 237, 77 & 48mm
 Lock Positions: 311, 388 and 436mm
 Plug Type: 3-Pin

Minimum Height 72mm
 Maximim Lift Height: 445mm
 Platform Length: 1553mm
 Platform Width: 280mm

4. CONTENTS





fig.1



1. Filler plug for hydraulic fluid
2. Hydraulic fluid reservoir
3. Long hydraulic hoses with couplers (X2)
4. Lifting frames (X2)
5. Safety lock bar (X2)
6. Short hydraulic hoses with couplers (X2) (not shown)
7. Rubber lifting blocks 55mm (X4) and 75mm (X4)
8. Remote control
9. Hydraulic power unit
10. Positioning handle
11. Seal plug for hydraulic reservoir

5. ASSEMBLY

- 5.1. On delivery there is no hydraulic fluid in the hydraulic fluid reservoir on the hydraulic power unit. Fill with hydraulic fluid before using the product.
- 5.2. The short hydraulic hoses must be routed under the bottom of the lifting frames, never over the lifting frames.
- 5.3. Unscrew the filler plug (1) and fill with 1.8 litres of hydraulic fluid (ISO 32 or ISO 46) in the hydraulic fluid reservoir (2). Screw the plug on.
- 5.4. Connect the Female couplers on the long hose (3) to the male couplers on the hydraulic power unit (9). FIG. 2



- 5.5. Route the short hose (6) under the bottom of the lifting frames (4), never over the lifting frames. FIG. 3
- 5.6. Connect the male couplers on the long hoses to the female couplers on the short hose. FIG. 4
- 5.7. Connect the power unit to the power supply.
- 5.8. The lift system is now ready to use. FIG. 5
- 5.9. Press the U button (up) on the remote control (8) to lift and the D button (Down) to lower. FIG. 6

6. PREPARATION: BLEEDING

- 6.1. Air may accumulate within the hydraulic system after assembly. It will cause the jack frame to shake during raising or lowering.
- 6.2. Raise and lower the lift a few times to bleed the air from the system. Once it raises and lowers without shaking, it is ready to use.

7. OPERATION

- 7.1. Read all the safety instructions and other instructions.
 - ✗ **DO NOT** exceed the maximum permitted load.
- 7.2. If the vehicle that is to be lifted is not correctly positioned, there is a risk of it falling, which could cause serious personal injury and/or damage to property.
- 7.3. Check the product for cracks in weld joints as well as damaged, loose, worn or missing parts each time before use.
 - ✗ **DO NOT** use the product before replacing any worn or damaged parts.
- 7.4. Each time before lifting, check:
 - that the lifting frames are correctly positioned under the vehicle and as parallel as possible
 - that nobody is within the risk area
 - that the lifting frames' safety lock bars are turned outwards
 - and that there are not obstacles around or above the vehicle.
- 7.5. Familiarise yourself with the product and its controls by raising and lowering it a few times without a load.
 - ✗ **DO NOT** lower the vehicle if wheels or tyres have been removed. There must be space between the ground and the load that is to be lifted, in order to raise the lifting frames slightly before lifting the load.
 - The product cannot lift a full load from a fully lowered position.**
- 7.6. For optimum load stability, always place the two lifting frames as parallel with each other as the vehicle's lifting points permit.
- 7.7. Never attempt to drive the vehicle up onto the lift, as this will damage the lifting frames.
- 7.8. Never lift a vehicle directly on the lifting frames: always use lifting blocks.
- 7.9. Never leave the product unattended if it is not fully lowered or locked in the lower or upper locking position. Scissor lifts are designed to only hold loads with lock bar applied in the locking positions.
- 7.10. Only use lifting blocks of the same height, do not mix low and high lifting blocks.

7.11.



- ### 7.11.1.

7.12.

- ### 7.12.1.



7.13.

- ### 7.13.1.

7.13.2.

Park the vehicle in the desired location and align the lifting frames between the wheels along the vehicle's sides.

7.13.3.

Put the lifting frames beside each other.

7.14.

- 7.14.1.

IMPORTANT: The lifting frames must be parallel under the vehicle.

fig.9





fig.10




7.15. SAFETY LOCKBARS

- 7.15.1. On each lifting frame there is a lock bar that is used to lock the frame in the required position.
* **DO NOT** leave the product unattended if it is not fully lowered or locked in one of the three locked positions.
- 7.15.2. Always check before use, that the lock bar move easily and remain in their tracks.
- 7.15.3. The product will not work correctly if the lock bars become stuck in their upper positions or are not located in their tracks.

7.16. LIFTING

- 7.16.1. Press and hold the U button on the remote control. The lifting frames are raised.
- 7.16.2. Release the U button just before the lifting block comes into contact with the vehicle's lifting points. The lifting frames stop moving.
- 7.16.3. Check that the lifting blocks are correctly aligned in relation to the vehicle's lifting points.
- 7.16.4. Adjust the lifting blocks, if necessary. The vehicle may need to be lowered slightly in order for the lifting blocks to be able to be moved.
- 7.16.5. Press the U button on the remote control again to continue lifting.
□ **WARNING! DO NOT** stop lifting until the lifting frames have passed the lower locking position.
- 7.16.6. Release the U button to stop lifting immediately after the lower locking position, even if you are going to continue lifting to the upper locking position.
- 7.16.7. Check that the lifting blocks are located at the vehicle's lifting points. If the lifting blocks are correctly positioned, continue lifting. If the lifting blocks are not correctly positioned, press the D button on the remote control to lower the vehicle. Make the necessary adjustments.
- 7.16.8. Check that the vehicle is correctly balanced. If it is, continue lifting. If the vehicle is not correctly balanced, press the D button on the remote control to lower the vehicle. Make the necessary adjustments.
- 7.16.9. Lift the vehicle a little way past the desired locking position (lower or upper).
- 7.16.10. Release the U button and press the D button to lower the vehicle to the locking position. The lowering of the lifting frames is interrupted by locking.
- 7.16.11. Check visually that both lifting frames have been locked at the same locking position.
 - A. Lock bar
 - B. Turning block
 - C. Lock block
 - D. Locked position

fig.11




- **WARNING!**
Before starting work on the vehicle or leaving the area, check visually that both the lifting frames are locked in the same locking position and that all the lifting blocks are in contact with the vehicle's lifting points. Work on the vehicle can be performed when both the lifting frames are locked in the same locking position and all the lifting blocks are in contact with the vehicle's lifting points.

7.17. LOWERING THE FRAMES FROM THE LOCKING POSITION


- **WARNING!** When lowering car lift jack frames, make sure the lock bar and the turning blocks stay in their tracks. If they get knocked sideways, for example, they can get stuck on the rail of the track, which could result in the car lift not lowering correctly.
- 7.17.1. Press and hold U button until the lock bar is clear of the lock block.

- 7.17.2. Lift the lock bar on both car lift jack frames so that the turning block is on top of the lock block on both frames. You can use a tool to lift the lock bar.
- 7.17.3. Press down on the remote control. Make sure the lock bars clear the lock block on both car lift jack frames on their way down. Release the down button if either side does not clear the lock block.
- 7.17.4. Continue pressing down button until both car lift jack frames are lowered to the ground.
NOTE:
- 7.17.5. Press down button for a few seconds after the frames are on the ground. This ensures that as much hydraulic fluid as possible returns to the fluid reservoir.
- 7.17.6. Remove the car lift jack frames from underneath the vehicle, use the jack frame handles.
- 7.17.7. Move the vehicle. **DO NOT** drive the vehicle over the car lift jack frames or the hydraulic hoses.



8. MAINTENANCE

- ❑ **WARNING!** Remove from the mains power supply and relieve the hydraulic pressure prior to maintenance and/or cleaning.
- 8.1. A general evaluation of the residual life-time of the product is to be done at latest after 10 years of use, by a qualified technician, preferably authorized by the manufacturer.
- 8.2. **CLEANING**
- 8.2.1. Clean all parts regularly for optimum functionality and service life.
- 8.2.2. Use suitable personal protective equipment when working with the hydraulic system.
- 8.2.3. Avoid skin contact with hydraulic fluid. Follow the manufacturer's safety instructions.
- 8.3. **TRANSPORTATION**
- 8.3.1. **Transportation with hydraulic oil by car or truck:** replace the filler plug (1) on the fluid reservoir by the seal plug (11). The filler plug can not seal the fluid in the reservoir, it will cause the hydraulic oil to slop out from the reservoir during transportation.
- 8.3.2. If the unit needs to be transported via a logistics company empty the fluid in the reservoir beforehand.
- 8.3.3. Remember before use to remove the seal plug (11) and replace it with the filler plug (1).
- ✱ **DO NOT** use the seal plug (11) when using the power unit, it will damage the fluid reservoir.
- 8.3.4. If the unit is to be moved release the long hydraulic hoses from the power unit, move the pump separately from the lifting frame and hoses.
- 8.4. **STORAGE**
- 8.4.1. Store in fully lowered position when not in use.
- 8.5. **REPAIR**
- 8.5.1. Professional repair only. Contact Sealey for Technical Assistance.
- 8.5.2. Warranty will be invalidated if the product is modified in any way, damaged as a result of an accident, negligence or incorrect use, or if it has been repaired by unauthorised personnel.
- 8.6. **SAFETY CHECKS**
- 8.6.1. Check all bolted joints regularly, and tighten them if necessary.
- 8.6.2. Check the product for cracks in weld joints as well as damaged, loose, worn or missing parts each time before use. **DO NOT** use the product until any worn or damaged parts have been replaced.
- 8.6.3. Check that the Safety lock bars are in good condition and working properly. Do not use the product if the Safety lock bars are damaged or worn.
- 8.6.4. Check the lifting blocks and replace them if they are damaged or worn.
- 8.6.5. **MONTHLY:**
Lubricate all joints and check for wear. If necessary lubricate with white lithium grease or equivalent using a grease gun, refer to grease points on fig.13.



- 8.6.6. Check the hydraulic fluid level, and top up if necessary.
- 8.6.7. Check that the safety and warning labels on the product are intact and legible. Replace as necessary.

9. TROUBLESHOOTING

- 9.1. This troubleshooting guide can be used to identify the causes of common problems and will provide suggestions as to how they can be rectified. Contact Sealey if you experience a problem that is not included in this troubleshooting guide.

☐ **WARNING! DO NOT** use the lift until any worn or damaged parts have been replaced. Any repairs must be carried out by an authorised service centre or other qualified personnel.

Problem	Solution
The lifting frames cannot be raised or lowered.	Check that the hydraulic hoses are not bent, clenched or leaking.
	Check the level of the hydraulic fluid.
	Check that the power unit has the right power supply.
	Bleed the cylinders.
Lifting frames cannot be lowered.	Check that the lifting frames are loaded. If not, place a load on them.
	The product is designed to work with a load on the lifting frames.
The electric power unit produces no pressure	Repair the power unit.
The lifting frames have become stuck at maximum height with no load.	The lifting frames must be loaded in order to lower from maximum height.
The lifting frames cannot be raised from a fully lowered position.	There must be space between the ground and the load that is to be lifted, in order to raise the lifting frames slightly before lifting the load. The product cannot lift a full load from a fully lowered position.
Contaminated hydraulic fluid	Replace the contaminated hydraulic fluid with new fluid of the same type.
Abnormal noise during use.	Lubricate the joints with white lithium grease.
The lifting frames sink slowly Without any buttons being pressed.	Check that the lifting frames are locked in one of the locking positions. Otherwise, hydraulic fluid is slowly leaking, causing the lifting frames to sink. Do not leave the product unattended if it is not fully lowered or locked in one of the three locked positions.
The couplers are difficult to connect.	Pressure in the hydraulic system. Relieve the pressure by pressing and holding the D button for a few seconds after the lifting frames have been fully lowered, in order to return as much hydraulic fluid as possible to the fluid reservoir. Contact Sealey if the pressure is so high that it is not possible to connect the couplers.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way.
Contact your local solid waste authority for recycling information.



REGISTER YOUR PURCHASE HERE



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk