
# baridi

Baridi 60L Beer & Drinks Fridge with LED Light, Black and Glass Door



# Model: DH62.V2

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

# Important Information

Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.



Indoor use Warni only flamm

instructions

Warning: flammable material

## • ELECTRICAL SAFETY

- WARNING! It is the user's responsibility to check the following:
- Check all electrical equipment and appliances to ensure that they are safe before using. Inspect power supply leads, plugs and all electrical
  connections for wear and damage. Dellonda recommend that an RCD (Residual Current Device) is used with all electrical products. You may
  obtain an RCD by contacting your local domestic stockist. If the product is used in the course of business duties, it must be maintained in a
  safe condition and routinely PAT (Portable Appliance Test) tested.
- · Electrical safety information: It is important that the following information is read and understood.
- · Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- · Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that they are secure.
- The appliance shall be disconnected from its power source during service and when replacing parts.
- Important: Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse see fuse rating in these instructions.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- DO NOT pull or carry the appliance by the power cable.
- **DO NOT** pull the plug from the socket by the cable.
- **DO NOT** use worn or damaged cables, plugs or connectors.
- Ensure that any faulty item is repaired or replaced immediately by a qualified electrician.
- Dellonda recommend that repairs are carried out by a qualified electrician.

### GENERAL SAFETY

- WARNING! IMPORTANT SAFETY INSTRUCTIONS
- WARNING! To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions:
- Before using the appliance, please read this user manual to ensure that you gain the maximum benefit from it.
- This refrigerant appliance is intended to be used at ambient temperatures ranging from 16°C to 32°C.
- This refrigeration appliance is not intended to be used as a built-in appliance.
- · This refrigeration appliance is not suitable for freezing foodstuffs.
- WARNING!: DO NOT damage the refrigerant circuit.
- WARNING!:
- 1) This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of
  experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for
  their safety.
- 2) Children should be supervised to ensure that they DO NOT play with the appliance.
- 3) This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack
  of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the
  hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 4) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard
- 5) To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
- 6) When positioning the appliance, ensure the supply cord is not trapped or damaged.
- 7) DO NOT locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- 8) Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- 9) DO NOT use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- 10) DO NOT damage the refrigerant circuit.
- 11) DO NOT use electrical appliances inside the drink storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- 12) DO NOT store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- · WARNING: DO NOT use mechanical devices or other means to accelerate the defrosting process.
- 13) This appliance is intended to be used in household and similar applications such as
- staff kitchen areas in shops, offices and other working environments;
- · farm houses and by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- · catering and similar non-retail applications.
- 14) Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.
- 15) To avoid contamination of drink, please respect the following instructions:
- · Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- - Regularly clean surfaces that can come in contact with drink and accessible drainage systems.
- - Clean water tanks if they have not been used for 48h; flush the water system connected to a water supply if water has not been drawn for 5 days.
- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.
- · NOTE: This appliance contains flammable refrigerant R600a and foaming agent cyclopentane.
- · Please avoid contact fire when you transport and use it.

- · Professional repair and servicing only.
- · Please send to your local appointed disposal station when you discard it.
- Save these instructions-
- During use, service and disposal pay attention to the symbol 'Risk of fire' located in the rear of the appliance. There are flammable materials in the refrigerant pipes and the compressor. Keep away from any sources of fire during use and disposal.

INTRODUCTION

 Using direct compressor cooling technology to give a temperature range between 3-18°C. The built-in thermostat can control the temperature to your preference. 60L Size means plenty of room for beer, wine and soft drinks with space for up to 74, 330ml cans. Two removable metal shelves and wire rack. Also including an LED light and built-in security lock to keep your drinks where you left them. Dimensions (W x D x H): 430 x 450 x 640mm. Annual energy consumption 75 KWh/a.

# SPECIFICATION


- Model no: ..... DH62.V2
- Capacity: .....Net Capacity 53L
   Energy Efficiency Class: .....E

- Power Cable Length:.....1.7m
- Dimensions (WxDxH): ....430x450x638mm
- QC Electrical Class:....Class 1
- QC Plug Type:.....3-Pin BS

- Lamp Power:.....1W

- Volume: ..... 57L

- PARTS AND FEATURES
- 1: Upper Hinge
- 2: Door Gasket
- 3: Door Handle
- 4: Shelves
- 5: Foot
- 6: Temperature Control




### INSTALLATION

- The unit is designed to be free-standing. Ventilation Space a minimum space of 10cm is required for the rear, top and sides of the fridge and 5cm under the base. This will maximise the efficiency, performance and life of the fridge and also ensure that there is sufficient space for the hinge to operate effectively. **DO NOT** locate the unit in a damp or moist location.
- DO NOT locate the unit in direct sunlight.
- WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.
- WARNING: DO NOT locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- Ensure that the floor surface is strong and stable enough to support the unit when it is fully loaded.
- · Level the unit when in location by using the adjustable levelling feet in each corner.
- Once in position allow the unit to rest for an hour before turning it on.
- · Allow the unit 2 3 hours to reach set temperature after switching on before placing any items in the compartment.

#### OPERATION

- The temperature control dial is accessed at the rear of the unit in the lower right corner.
- To turn the unit on, rotate control knob from the O (off) position (fig.2).
- Rotate control knob to the required value . A setting of '5' will create maximum cooling effect (approx. 3°C) and '1' will set working internal temperature at approximately 10°C.
- · When the set temperature is reached, the compressor will stop working.
- On first use, set the temperature to maximum e.g. '5'. and adjust to suit once this is reached.
- Use the rocker switch close to the control knob to turn on the internal light.



#### MAINTENANCE

- · Remove the power plug from the supply when performing cleaning or maintenance.
- To replace a faulty internal LED, a replacement is available (part no. DH10277) and is integrated into a PCB. It is recommended that PCB replacement is only carried out by a qualified electrician.
- DO NOT use abrasive or chemical cleaning materials on any surface of the unit.
- · Wipe interior and exterior surfaces with a damp cloth and dry thoroughly with a clean dry cloth.
- · For more soiled surfaces use a neutral detergent, wipe down with a clean damp cloth and dry thoroughly with a clean dry cloth.

•	T	R	0	U	B	L	E	S	ŀ	1	0	0	T	1	N	10	ć

Symptom	Solution
Unit does not operate.	Not plugged in.
	Fuse/circuit breaker failure.
Turns on and off frequently.	Room temperature higher than normal.
Poor cooling.	Door opened too often.
	Door not properly closed.
	Temperature control incorrectly set.
	Door gasket not sealing.
	Not enough space around unit.
Vibrations	Check to assure unit is level.
Noisy unit	Contraction/expansion of panels.
	Unit not level.
	Check fan operation.
	Check heat pump.
Door will not close properly	Unit not level.
	Gasket distorted.
	Internals out of position.

# Environment Protection and Waste Protection and Electrical Equipment Regulations (WEEE)

Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of it's useful life, please dispose of it in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. Under the Waste Batteries and Accumulators Regulations 2009, Dellonda would like to inform the user that this product contains one or more batteries. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.



🕻 01284 757575 🛛 💌 support@dellonda.co.uk 🖉 www.dellonda.co.uk