
baridi

Baridi 40L Drinks Mini Fridge with LED Light, Black and Glass Door



Model No. DH98

Thank you for purchasing a Baridi product from the Dellonda range. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

Important Information

Please read these instructions carefully and note any safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.





Refer to instructions

Indoor use only

ELECTRICAL SAFETY

- WARNING! It is the user's responsibility to check the following:
- Check all electrical equipment and appliances to ensure that they are safe before using.
- Inspect power supply leads, plugs and all electrical connections for wear and damage.
- Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- DO NOT use worn or damaged cables, plugs or connectors.
- Ensure that any faulty item is repaired or is replaced immediately by a qualified electrician.
- If the cable or plug is damaged during use, switch off the electricity supply and remove from use.
- Ensure that repairs are carried out by a qualified electrician.
- Dellonda recommend that an RCD (Residual Current Device) is used with all electrical products
- Important: Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the
- · correct fuse.
- **DO NOT pull** or carry the appliance by the power cable.
- DO NOT pull the plug from the socket by the cable.

GENERAL SAFETY

- WARNING! IMPORTANT SAFETY INSTRUCTIONS
- WARNING! To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions:
- Before using the appliance, please read this user manual to ensure that you gain the maximum benefit from it.

· WARNING:

- 1) This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 2) Children should be supervised to ensure that they do not play with the appliance.
- 3) This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 4) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 5) To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
- 6) When positioning the appliance, ensure the supply cord is not trapped or damaged.
- 7) DO NOT locate multiple portable socketoutlets or portable power supplies at the rear of the appliance.
- 8) Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

- 9) DO NOT use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- 10) DO NOT damage the refrigerant circuit.
- 11) DO NOT use electrical appliances inside the drink storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- 12) DO NOT store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- 13) This appliance is intended to be used in household and similar applications such as
- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;
- · bed and breakfast type environments;
- · catering and similar non-retail applications.
- 14) Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.
- 15) To avoid contamination of drink, please respect the following instructions:
- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Clean regularly surfaces that can come in contact with drink and accessible drainage systems.
- Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days.
- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.
- Note: This appliance contains flammable refrigerant R600a and foaming agent cyclopentane.
- Please avoid contact fire when you transport and use it.
- · Professional repair and servicing only.
- Please send to your local appointed disposal station when you discard it.
- · -Save these instructions-
- During use, service and disposal pay attention to the symbol 'Risk of fire' (see below) located in the rear of the appliance. There are flammable materials in the refrigerant pipes and the compressor. Keep away from any

sources of fire during use and disposal.



INTRODUCTION

 Premier 40 litre capacity mini fridge. Uses direct compressor cooling technology to give a temperature range of 3-18°C. Built-in thermostat to control temperature to user's preference. Design features two strong removable wire shelves, internal LED light and built-in security lock. Energy Efficiency Class: C. Net (Useable) Capacity = 33L.

SPECIFICATION

 Mod 	el no:	DH98
 Actu 	al Product Width:	405mm
 Capa 	acity:	Net Capacity 33L
 Ener 	gy Efficiency Class:	C
 Freq 	uency:	50Hz
 Nois 	se level:	42dB
 Pow 	er Cable Length:	1.7m
• Dime	ensions (WxDxH):	402x430x550mm
• QC -	Electrical Class:	Class 1
• QC -	Plug Type:	3-Pin BS
 Rate 	d Current:	0.6A
 Refr 	igerant:	R600a
 Lam 	p Power:	1W
		3 -18°C
 Volta 	age:	230V
	me:	


INSTALLATION

- The unit is designed to be free-standing.
 Ventilation Space a minimum space of 10cm is required for the rear, top and sides of the fridge and 5cm under the base. This will maximise the efficiency, performance and life of the fridge and also ensure that there is sufficient space for the hinge to operate effectively. DO NOT locate the unit in a damp or moist location.
- DO NOT locate the unit in direct sunlight.
- Ensure that the floor surface is strong and stable enough to support the unit when it is fully loaded.
- Level the unit when in location by using the adjustable levelling feet in each corner.
- Once in position allow the unit to rest for an hour before turning it on.
- Allow the unit 2 3 hours to reach set temperature after switching on before placing

any items in the compartment.


PARTS AND FEATURES

- · 1: Upper Hinge
- · 2: Door Gasket
- · 3: Door Handle
- · 4: Shelves
- 5: Foot
- · 6: Temperature Control



OPERATION

- The temperature control dial is accessed at the rear of the unit in the lower right corner.
- To turn the unit on, rotate control knob from the O (off) position.
- Rotate control knob to the required value.
 A setting of '5' will create maximum cooling effect (approx. 3°C) and '1' will set working internal temperature at approximately 10°C.
- When the set temperature is reached, the compressor will stop working.
- On first use, set the temperature to maximum e.g. '5'. and adjust to suit once this is reached.
- Before switching power off, set control to 0.
- Use the rocker switch close to the control knob to turn on the unit's internal light.



MAINTENANCE

- Remove the power plug from the supply when performing cleaning or maintenance.
- **DO NOT** use abrasive or chemical cleaning materials on any surface of the unit.
- Wipe interior and exterior surfaces with a damp cloth and dry thoroughly with a clean dry cloth.
- For more soiled surfaces use a neutral detergent, wipe down with a clean damp cloth and dry thoroughly with a clean dry cloth.

Troubleshooting

Symptom	Solution
Unit does not operate.	Not plugged in. Fuse/circuit breaker failure.
Turns on and off frequently. Poor cooling.	Room temperature higher than normal. Door opened too often. Door not properly closed. Temperature control incorrectly set. Door gasket not sealing. Not enough space around unit.
Vibrations	Check to assure unit is level.
Noisy unit	Contraction/expansion of panels. Unit not level. Check fan operation. Check heat pump.
Door will not close properly	Unit not level. Gasket distorted. Internals out of position.



Environment Protection, Waste Electrical and Waste Electronic Equipment Regulations (WEEE)



Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of its useful life, please dispose of in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.

Dellonda Limited, Sole UK Distributor of Baridi

Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



