

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Read instructions before use



Wear eye protection



Wear ear protection



Wear protective gloves



Wear a mask

### 1. INTRODUCTION

In general, flap discs are a good choice for most metalworking applications where a smooth finish is desired. Grinding discs are a better choice for applications where heavy-duty material removal is required.

### 2. SAFETY

- ❑ **WARNING! If used incorrectly, this product can cause damage or injury to the operator. Ensure all instructions are read and understood before using this product. Cutting wheels should be used for cutting, and grinding wheels for grinding.**
- ✓ Always wear safety glasses, ear protection, gloves and dust mask when using cutting or grinding wheels.
- ✓ Ensure there is a safety guard in place before operating the machine.
- ✓ Ensure the work area is well-ventilated.
- ✓ Use the correct type of wheel for the job you are doing.
- ✓ Keep your hands away from the wheel.
- ✓ Ensure the tool and disc are compatible, and suitable for the task at hand by following all markings.
- ✓ Check the spindle speed of the machine is no higher than the operating speed marked on the wheel.
- ✓ Turn off the power before changing the wheel.
- ✓ Disconnect the power cord from the outlet before making any adjustments to the tool.
- ✓ Inspect the wheel carefully before use. Make sure it is not cracked, chipped, or damaged in any way.
- ✗ **DO NOT** use cutting or grinding wheels if they are cracked, chipped, or damaged in any way.
- ✗ **DO NOT** overload the wheel.
- ✗ **DO NOT** force the wheel to cut or grind.
- ✗ **DO NOT** use the wheel if it is not spinning freely.

### 3. INSTRUCTIONS

- 3.1. Attach the wheel to the angle grinder as per the instructions. Make sure the wheel is properly seated and tightened.
- 3.2. Turn on the angle grinder and allow the wheel to come up to speed.
- 3.3. Start cutting or grinding slowly and gradually increase speed as needed.
- 3.4. Apply even pressure to the wheel. **DO NOT** force the wheel to cut or grind.
- 3.5. Keep your hands away from the wheel.
- 3.6. When you are finished, turn off the angle grinder and allow the wheel to come to a complete stop.
- 3.7. Disconnect the power cord from the outlet before removing the wheel from the angle grinder.

### 4. MAINTENANCE

- ✓ Keep the wheel sharp for best results.
- ✓ Replace the wheel when it is worn out or damaged.
- ✓ Store the wheel in a dry, cool place.



#### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 36 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk