

EXTRA-SLIM SOLAR FLOODLIGHT WITH WALL BRACKET

MODEL NO: LED16S.V2, LED20S, LED30S

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

- ✓ Maintain the light in good condition.
- Ensure the light is installed correctly in accordance with these instructions.
- Only install the light on a vertical surface.
- **x DO NOT** fix the light on any horizontal surface i.e. ceiling, or overhang.
- ✓ Install away from flammable or combustible materials.
- **× DO NOT** direct the light into a persons eyes.
- **× DO NOT** install the light where it is likely to be knocked or hit.
- **DO NOT** install in bathrooms, shower rooms, sauna or such locations.
- DO NOT install near an exhaust outlet. e.g. Boiler flue, dryer outlet etc, or mirrored surfaces.
- DO NOT put the light in an area that is well lit at night, e.g., near a street light. This may stop the sensor from determining when it is night time and will stop the light from operating.
 The light must be securely fixed to the mounting surface. The screws and wall plugs
- supplied are suitable for masonry only.
- ✓ Mount the light level and horizontal to the ground.
- \checkmark Turn the light off if it is not to be used for long periods.
- Locate the light away from obstructions that block the light from reaching the solar panel such as overhanging tree branches, fences or buildings.

Note: If you have solar-powered LED lights, it's essential to charge them up completeley

before using them. Most solar lights need about 8 to 12 hours of direct sunlight for the initial charge.

2. INTRODUCTION

Extra-Slim Solar floodlights with Wall Bracket. Features both daylight (CDS) and motion (PIR) sensors to switch on automatically. Motion sensors can detect up to 6m. 30 second timer upon sensing motion.

3. SPECIFICATION

LED16S.V2	LED20S	LED30S
3.7V 2.6Ah	3.7V 3Ah	2 x 3.7V 2.6Ah
IP54	IP54	IP54
16W SMD	20W SMD	30W SMD
1600lm	2000lm	3000lm
0.275kg	0.38kg	0.71kg
Yes	Yes	Yes
16W	20W	30W
	3.7V 2.6Ah IP54 16W SMD 1600lm 0.275kg Yes	3.7V 2.6Ah 3.7V 3Ah IP54 IP54 16W SMD 20W SMD 1600lm 2000lm 0.275kg 0.38kg Yes Yes

4. ASSEMBLY

4.1. Unpack the product and check contents. Should there be any damaged or missing parts contact your supplier immediately.

4.2. Give careful consideration to the position of solar-powered LED lights to ensure maximum direct sunlight.

4.3. With care remove the wall bracket from the light assembly by unscrewing the retaining thumb screws (fig 1).

4.4. Locate the thumb screws, solar panel and light in a secure location.


4.5. Place the wall bracket at your desired location and spot mark through the slots onto the fixing surface (fig 2).

4.6. Secure wall bracket with appropriate fixings, wall plugs, to suit mounting surface.

4.7. Reassemble the light assembly (fig 3).


WARNING! If working at height take adequate safety precautions to prevent injury from falling.





5. OPERATION


- 5.1. Adjust the solar panel upwards to maximise the amount of direct sunlight collected (fig 4).
- 5.2. Rotate the light downwards to obtain maximum coverage (figs 4 & 5).
- 5.3. Push the power button to switch on the light (fig 6).
- WARNING! To avoid unwanted activation ensure that the light is not positioned so it detects unwanted objects such as road traffic or people using nearby footpaths.
- 5.4. Green light illumination indicates that the floodlight is charging.



6. MAINTENANCE

- 6.1. Wipe clean with soft dry cloth.
- **× DO NOT** use solvents.

NOTE: The light is a fully sealed unit with no serviceable parts on the LED16S, however the LED20S, LED30S (fig.7) have 18650 lithium batteries that are charged from the solar panel. A single battery in the LED20S, and two in the LED30S. Simply unscrew the battery cap (anticlockwise) and replace when required. Battery orientation is marked on the rear of the lamp, adjacent to the battery access cap.







ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.





WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR