

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



**IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.**

### 1. SAFETY INSTRUCTIONS

- ✓ Familiarise yourself with the application and the limitations and potential hazards of the stand.
- ✓ Maintain the stand in good condition, use authorised replacement parts only.
- ✓ Locate the stand in a suitable, clean work area.
- ☐ **WARNING!** Use the stand on level and solid ground only, preferably concrete.
- ✗ **DO NOT** overload the stand.
- ✗ **DO NOT** climb on the stand.
- ✗ **DO NOT** use the stand for any purpose, other than that for which it is designed.
- ✗ **DO NOT** use the stand if any parts are damaged or missing as this may cause failure and/or personal injury.
- ✓ Keep the work area clean, uncluttered and ensure that there is adequate lighting.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ Keep the stand clean for best and safest performance and when not in use, store in a safe, dry, childproof location.


### 2. INTRODUCTION

Suitable for supporting large panels from commercial vehicles. Features fully adjustable arms to fit many styles of bonnets, wings, doors, bumpers and tailgates. Each level can rotate 360° as required. Fitted with two fixed Ø180mm wheels and two braked Ø125mm castors for easy manoeuvrability.

### 3. ASSEMBLY INSTRUCTIONS

- 3.1. Check the contents against Fig.1 and the parts list to confirm that all are present, and to familiarise yourself with the parts. Refer to Fig.1. for assembly whilst following the steps below.
- 3.2. Mount the two oblique tubes (7 & 13) to the lower vertical tube (11), fitting the middle vertical tube (16) inside the lower vertical tube, align all holes, and use two bolts (5), four washers (4) and two nuts (6) to secure.
- 3.3. Attach the long axle tube (3) to the long oblique tube (7) using two bolts (5), four washers (4) and two nuts (6).
- 3.4. Attach the short axle tube (15) to the short oblique tube (13) using two bolts (5), four washers (4) and two nuts (6).
- 3.5. Attach the swivel wheels (14) to the short axle tube (15) using four washers (4) and two nuts (6).
- 3.6. Attach the wheels (1) to the long axle tube (3) by sliding them on and retaining them using the two 'R' pins (2).
- 3.7. Attach the top vertical tube (17) to the middle vertical tube (16) by screwing them together.
- 3.8. Attach the two brackets (9 & 22) to the oblique tubes, using two bolts (8) and two wing nuts (10).
- 3.9. Slide the four adaptors (18) down over the top tube and secure in place using the threaded fixing knobs (12).
- 3.10. Assemble the remaining cross tubes (20), and short and long hooks (19 & 21) as per picture (fit in your desired positions). Also see Fig.2 overleaf for final assembly.

| Part No. | Description          | Quantity |
|----------|----------------------|----------|
| 1        | Wheel                | 2        |
| 2        | 'R' Pin              | 2        |
| 3        | Axle Tube (Long)     | 1        |
| 4        | Washer               | 16       |
| 5        | Bolt                 | 6        |
| 6        | Nut                  | 8        |
| 7        | Oblique Tube (Long)  | 1        |
| 8        | Bolt                 | 2        |
| 9        | Bracket (Right)      | 1        |
| 10       | Wing Nut             | 2        |
| 11       | Lower Vertical Tube  | 1        |
| 12       | Threaded Fixing Knob | 13       |
| 13       | Oblique Tube (Short) | 1        |
| 14       | Swivel Wheel         | 2        |
| 15       | Axle Tube (Short)    | 1        |
| 16       | Middle Vertical Tube | 1        |
| 17       | Top Vertical Tube    | 1        |
| 18       | Adaptors             | 4        |
| 19       | Hook (Long)          | 2        |
| 20       | Cross Tube           | 2        |
| 21       | Hook (Short)         | 4        |
| 22       | Bracket (Left)       | 1        |



## 4. OPERATION

- 4.1. Loosen the knobs and adjust the position of the cross tubes as required.
- 4.2. If required, secure the help of a second person, and lift the vehicle panel into position, find a suitable feature to rest it on the cross tubes.
- 4.3. If further security is required, use chains or similar to attach to a suitable feature on the panel and stretch the chain to the brackets on the oblique tubes and secure. Do not let go of the panel until you are sure that it is properly secured.
- 4.4. Retighten the knobs on the cross tubes to lock them.
- 4.5. Check that the panel is stable before moving the stand.
- 4.6. When the stand is in the processing area, lock the castor wheels.

**Fig.2**



**Parts support is available for this product.**  
To obtain a parts listing and/or diagram, please log on to [www.sealey.co.uk](http://www.sealey.co.uk),  
email [sales@sealey.co.uk](mailto:sales@sealey.co.uk) or phone 01284 757500.

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of this product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

**SEALEY** **Power**  
**PRODUCTS**

Sole UK Distributor, Sealey Group,  
Kempson Way, Suffolk Business Park,  
Bury St. Edmunds, Suffolk,  
IP32 7AR

☎ 01284 757500

☎ 01284 703534



[www.sealey.co.uk](http://www.sealey.co.uk)



[sales@sealey.co.uk](mailto:sales@sealey.co.uk)