

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.




**IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY, AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.**


## 1. SAFETY INSTRUCTIONS

### 1.1. ELECTRICAL SAFETY

**WARNING!** It is the responsibility of the owner and the operator to read, understand and comply with the following:

You must check all electrical products, before use, to ensure that they are safe. You must inspect power cables, plugs, sockets and any other connectors for wear or damage. You must ensure that the risk of electric shock is minimised by the installation of appropriate safety devices. A Residual Current Circuit Breaker (RCCB) should be incorporated in the main distribution board. We also recommend that a Residual Current Device (RCD) is used. It is particularly important to use an RCD with portable products that are plugged into a supply which is not protected by an RCCB. If in any doubt consult a qualified electrician. You may obtain a Residual Current Device by contacting your Sealey dealer. **You must** also read and understand the following instructions concerning electrical safety.

- 1.1.1. The **Electricity at Work Act 1989** requires that all portable electrical appliances, if used on business premises, are tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.
- 1.1.2. The **Health & Safety at Work Act 1974** makes owners of electrical appliances responsible for the safe condition of those appliances and the safety of the appliance operators. **If in any doubt about electrical safety, contact a qualified electrician.**
- 1.1.3. Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply. See 1.1.1. and 1.1.2. and use a Portable Appliance Tester.
- 1.1.4. Ensure that cables are always protected against short circuit and overload.
- 1.1.5. Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that none is loose.
- 1.1.6. **Important:** Ensure that the voltage marked on the appliance matches the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating at right.
- 1.1.7. **DO NOT** pull or carry the appliance by the power cable.
- 1.1.8. **DO NOT** pull the plug from the socket by the cable.
- 1.1.9. **DO NOT** use worn or damaged cables, plugs or connectors. Immediately have any faulty item repaired or replaced by a qualified electrician. When a BS 1363/A UK 3 pin plug is damaged, cut the cable just above the plug and **dispose of the plug safely.** Fit a new plug according to the following instructions (UK only).
  - a) Connect the **GREEN/YELLOW** earth wire to the earth terminal 'E'.
  - b) Connect the **BROWN** live wire to the live terminal 'L'.
  - c) Connect the **BLUE** neutral wire to the neutral terminal 'N'.
  - d) **After wiring, check that there are no bare wires, that all wires have been correctly connected, that the cable outer insulation extends beyond the cable restraint and that the restraint is tight.**Double insulated products, which are always marked with this symbol , are fitted with live (brown) and neutral (blue) wires only. To rewire, connect the wires as indicated above - **DO NOT** connect either wire to the earth terminal.
- 1.1.10. Products which require more than 13 amps are supplied without a plug. In this case you must contact a qualified electrician to ensure that a suitably rated supply is available. We recommend that you discuss the installation of an industrial round pin plug and socket with your electrician.
- 1.1.11. If an extension reel is used it should be fully unwound before connection. A reel with an RCD fitted is preferred since any appliance plugged into it will be protected. The cable core section is important and should be at least 1.5mm<sup>2</sup>, but to be absolutely sure that the capacity of the reel is suitable for this product and for others which may be used in the other output sockets, we recommend the use of 2.5mm<sup>2</sup> section cable.



### 1.2. GENERAL SAFETY


- ✓ Disconnect the cleaner from the power supply before servicing, changing accessories, or performing any maintenance.
- ✓ Use only genuine parts and accessories. *Unauthorised parts and accessories may be dangerous and will invalidate your warranty.*
- ✓ Maintain the cleaner in good condition. Use authorised agent for servicing. Keep machine clean, but **DO NOT use solvents.**
- ✓ For dry vacuuming ensure the cartridge filter is firmly in place before operating the cleaner.
- ✗ **DO NOT** operate the unit without the cartridge filter in place (except when wet vacuuming). **Using the cleaner without a cartridge filter will cause machine faults and will invalidate your warranty.**
- ✓ Wear protective clothing and gloves.
- ✗ **DO NOT** allow children or untrained persons to operate the cleaner.
- ✗ **DO NOT** place attachments close to your face (especially eyes, ears, etc). Do not point the hose end at other persons or animals.
- ▲ **DANGER! DO NOT vacuum hot or glowing ash, cigarette ends, inflammable, explosive, corrosive or other dangerous substances.**
- ✗ **DO NOT** leave machine running unattended. Turn power supply OFF, and **DO NOT** leave the vicinity until motor has come to a complete stop.
- ✗ **DO NOT** operate the cleaner while under the influence of drugs, alcohol or impairing medication, or if you are tired.
- ✗ **DO NOT** use the cleaner in the rain or in very damp conditions.
- ✗ **DO NOT** use the cleaner for a task it is not designed to perform.
- ✓ When not in use, store the cleaner in a safe, dry, childproof location.

## 2. CONTENTS AND SPECIFICATION

- 2.1. **Carton content**
- 2.2. Carefully unpack the carton.
- 2.3. Locate the two side clasps (fig. 1.6) which hold the top section (fig.1.1) in place.
- 2.4. Undo the clasps, remove the top section and take out the items in the container.
- 2.5. Check and identify each component as listed below. If anything is missing or damaged please contact your supplier immediately.


2.2.1.	Specifications
Motor	230V 1250W.
Container	20ltr.
Filter - Dry	Cartridge Filter
Filter - Wet	Foam.
Item	Description
1	Handle.
2	ON/OFF switch.
3	Top section.
4	Filter basket.
5	Safety float valve.
6	Clasp.
7	Container.
8	Vacuum hose connection.
9	Castors.
10	Flexible vacuum hose.
11	Two piece vacuum tube.
12	Blow connection.
13	Large vacuum nozzle.
15	Foamed plastic filter.
16	Crevice nozzle.
17	Cartridge filter (Supplied as standard)

fig. 1




## 3. ASSEMBLY

- 3.1. Ensure the mains plug is disconnected.
  - 3.2. Undo clasps.
  - 3.3. Lift off the top section assembly.
  - 3.4. Remove contents from inside the container.
  - 3.5. Turn the container upside down and insert the casters ensuring they are pushed all the way in.
  - 3.6a. For wet vacuum cleaning fit the supplied foamed plastic filter.
  - 3.6b. For dry vacuum cleaning fit the cartridge filter supplied.
- NOTE:** Do not operate the cleaner without a cartridge filter fitted as this will damage the machine and invalidate your warranty.
- 3.7. Replace the top section onto the container.
  - 3.8. Align the top section with the clasps and snap into place, by applying pressure at the mid point of the clasps.
  - 3.9. Insert the large end of the hose into the front inlet of the container and lock in place by turning clockwise a quarter turn.
  - 3.10. Choose the desired nozzle/extension tube(s) and push it onto the suction tube.



## 4. DRY VACUUM CLEANING


- WARNING!** Ensure you read, understand and apply Section 1 'Safety Instructions'.  
**Reminder: DO NOT vacuum hazardous substances. Use of an incorrect cartridge filter will invalidate your warranty.**
- 4.1. Ensure the machine is unplugged from the power supply.
  - 4.2. Remove the top section and fit the cartridge filter as shown in diagram 3.
  - 4.3. Reposition the head onto the drum body, and clip in place.
  - 4.4. Insert the larger end of the flexible hose into the front inlet on the container and lock in place. Push the required attachment onto the free end of the hose.
  - 4.5. Plug in the power supply.
  - 4.6. Switch the motor on (position 'I').
  - 4.7. When you have completed vacuuming, press the switch to 'Off' (position 'O'), and unplug from power supply.  
Regularly check the condition of the cartridge filter.
- x DO NOT** use the cartridge filter for wet or sharp materials.



## 5. WET VACUUM CLEANING

**WARNING!** Ensure you read, understand and apply Section 1 'Safety Instructions'. Reminder: Remove plug from power supply before opening unit. DO NOT vacuum solvents, explosives, inflammable and/or hazardous liquids such as petrol, oil, spirits, paint, thinners, acids etc.

- 5.1. Ensure the machine is unplugged from the power supply. Make sure the tank is clean and free from dust and dirt.
- 5.2. Remove the cartridge filter and fit a foam filter over the filter basket, replace the top section onto the container.
- 5.3. To the same flexible hose as used in dry cleaning fit the desired nozzle.
- 5.4. Ensure the switch is 'Off' (position '0') before plugging into the power supply.
- 5.5. Press the switch to 'On' (position 'I').
- 5.6. After use, empty the tank and dry.




To vacuum large quantities of liquid, from a sink or tank etc., do not immerse the nozzle completely in the liquid, leave a gap at the top of the nozzle opening to allow an air inflow. The machine is fitted with a float valve which stops the suction action when the tank has reached its maximum capacity. The user will notice an increase in motor speed. When this happens, turn off the machine, disconnect from power supply, remove the head from the container and empty the liquid into a suitable receptacle or drain. To continue vacuuming, refit the head and proceed. After wet vacuuming, turn the machine off and remove plug from power supply. Empty the container and clean/dry the inside and outside before storage.

**Remember!** After wet vacuuming the foam filter must be removed and a cartridge filter must be fitted before dry vacuuming again.

## 6. BLOWING

- 6.1 Push the large end of the flexible hose into the blow connection in the top section.
- 6.2 Ensure the power switch is turned off and plug in the power supply.
- 6.3 Switch on the power (position 'I').
- 6.4 The unit will now blow through the hose and can be used to clear obstructions within the pipe.



**WARNING!** If after a few seconds the hose is still blocked turn off the unit and clear the hose manually.



## 7. MAINTENANCE

### 7.1 GENERAL MAINTENANCE.

- 7.1.1 Ensure the machine is unplugged from the power supply.
- 7.1.2 Disconnect the hose from the container.
- 7.1.3 Undo the clasps and remove motor head from the container.
- 7.1.4 Clear out any dirt or debris from the container and hose.
- 7.1.5 Clean the foam filter by washing it in a mild soapy solution.
- 7.1.6 Check that the telescopic suction tube operates smoothly, and check the power cable to make sure it has not received any damage.

### 7.2 CARTRIDGE FILTER MAINTENANCE.

- 7.2.1 Handle the filter carefully when cleaning or installing.
- 7.2.2 Carefully remove the cartridge filter (A) and inspect it for damage. A filter that has small holes or tears in it will not perform efficiently and should be replaced.
- 7.2.3 To clean a dry filter, tap it inside a waste bin. (B)
- 7.2.4 Do not use the filter if it becomes wet as the filter will clog quickly and be very difficult to clean. (The cartridge filter is designed for dry vacuuming only.) Should the filter be inadvertently wetted it should be rinsed from the inside (B) and allowed to air dry for 24 hours.
- 7.2.5 To fit a new/cleaned filter slide it over the filter basket (C) and push it fully home (D)



## 8. TROUBLESHOOTING

Cleaner will not operate.	No power supply. Faulty power cable, switch or motor. Container full of liquid.	Check supply. Check and repair or replace faulty item. Empty container.
Dust comes from the motor cover.	Cartridge filter missing or damaged.	Fit or replace cartridge filter.
Reduced efficiency and increased motor speed/vibration.	Container full. Filter clogged. Nozzle, hose or container inlet blocked.	Empty container. Replace or clean filter (See maintenance) Check nozzle, hose and container inlet for blockage.

## 9. CONSUMABLES

Cartridge Filter (Must be used for dry vacuuming) .....PC200CF

**IMPORTANT! IF THE MACHINE IS USED WITHOUT A CARTRIDGE FILTER FITTED THE MOTOR WILL BURN OUT EVENTUALLY AND YOUR GUARANTEE WILL BE INVALIDATED. ALWAYS KEEP A SPARE CARTRIDGE FILTER HANDY.**

Foam Filter (pack of 10) .....PC200FF10

Dust Bags (Optional, pack of 5) .....PC200PB5



## 10. DECLARATION OF CONFORMITY

### Declaration of Conformity

We, the sole importers into the UK, declare that the product listed below is in conformity with the following standards and directives.

**Wet & Dry Vacuum Cleaner**  
**Model: PC200.V2**

98/37/ EC Machinery Directive  
73/23/EEC Low Voltage Directive  
89/336/EEC EMC Directive  
93/68/EEC CE Marking Directive



The construction file for this product is held by the Manufacturer and may be inspected, by a national authority, on request to Jack Sealey Ltd.

Signed by Mark Sweetman  5th December 2005

For Jack Sealey Ltd. Sole importer into the UK of Sealey Power Products.

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of this equipment.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

**SEALEY**

**POWER  
PRODUCTS**

Sole UK Distributor,  
Sealey Group,  
Bury St. Edmunds, Suffolk.

01284 757500

01284 703534

e-mail sales@sealey.co.uk

www.sealey.co.uk