



# OIL FILLED RADIATOR 2500W/230V

## 11 ELEMENT WITH TIMER

MODEL NO: **RD2500T**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Electrical shock hazard



Hot surfaces



Do not cover




Keep in dry area protect from rain


This product is only suitable for well insulated areas or occasional use.

## 1. SAFETY

### 1.1. ELECTRICAL SAFETY

- ❑ **WARNING!** It is the responsibility of the owner and the operator to read, understand and comply with the following:  
You must check all electrical products, before use, to ensure that they are safe. You must inspect power cables, plugs, sockets and any other connectors for wear or damage. You must ensure that the risk of electric shock is minimised by the installation of appropriate safety devices. A Residual Current Circuit Breaker (RCCB) should be incorporated in the main distribution board. We also recommend that a Residual Current Device (RCD) is used. It is particularly important to use an RCD with portable products that are plugged into a supply which is not protected by an RCCB. If in any doubt consult a qualified electrician. You may obtain a Residual Current Device by contacting your Sealey dealer.  
You must also read and understand the following instructions concerning electrical safety.  
**The Electricity at Work Act 1989** requires all portable electrical appliances, if used on business premises, to be tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.  
**The Health & Safety at Work Act 1974** makes owners of electrical appliances responsible for the safe condition of those appliances and the safety of the appliance operators. If in any doubt about electrical safety, contact a qualified electrician.
- ✓ Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- ✓ Ensure that cables are always protected against short circuit and overload.
- ✓ Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that none is loose.
- ✓ Ensure that the voltage marked on the appliance matches the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating at right.
- ✗ **DO NOT** pull or carry the appliance by the power cable.
- ✗ **DO NOT** pull the plug from the socket by the cable.
- ✗ **DO NOT** use worn or damaged cables, plugs or connectors. Immediately have any faulty item repaired or replaced by a qualified electrician. When an ASTA/BS approved UK 3 pin plug is damaged, cut the cable just above the plug and dispose of the plug safely. Fit a new plug according to the following instructions (UK only).
  - a) Connect the GREEN/YELLOW earth wire to the earth terminal 'E'.
  - b) Connect the BROWN live wire to the live terminal 'L'.
  - c) Connect the BLUE neutral wire to the neutral terminal 'N'.
  - d) After wiring, check that there are no bare wires, that all wires have been correctly connected, that the cable outer insulation extends beyond the cable restraint and that the restraint is tight.



Double insulated products, which are always marked with this symbol , are fitted with live (brown) and neutral (blue) wires only. To rewire, connect the wires as indicated above - **DO NOT** connect either wire to the earth terminal.

- ✓ Products which require more than 13 amps are supplied without a plug. In this case you must contact a qualified electrician to ensure that a suitably rated supply is available. We recommend that you discuss the installation of an industrial round pin plug and socket with your electrician.
  - ✓ If an extension reel is used it should be fully unwound before connection. A reel with an RCD fitted is preferred since any appliance plugged into it will be protected. The cable core section is important and should be at least 1.5mm<sup>2</sup>, but to be absolutely sure that the capacity of the reel is suitable for this product and for others which may be used in the other output sockets, we recommend the use of 2.5mm<sup>2</sup> section cable.
  - ✗ **DO NOT** move the heater whilst it is ON, always disconnect from the supply and allow to cool first.
- ### 1.2. GENERAL SAFETY
- ❑ **WARNING!** Disconnect the heater from the mains power, before servicing or performing any maintenance, which must only be carried out by an authorised service agent. Report any oil leakage immediately to an authorised service agent.
  - ✓ Replace or repair damaged parts. Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
  - ✓ Ensure that the heater is used in an area larger than 4m<sup>3</sup>. Allow a few centimetres of clearance from any surface, and ensure there is good overhead clearance for heat circulation.
  - ✓ Only use the heater in an upright position.
  - ❑ **WARNING! DO NOT** tamper with the wiring, heating element or oil. The system is a sealed unit. The breaking of any seal may be dangerous, will damage the heater and will invalidate the warranty.

- ✗ **DO NOT** use the heater for anything other than its intended purpose. It is designed for providing heat in enclosed areas, no smaller than 4m<sup>2</sup>, such as offices, homes, workshops etc. It is not suitable for drying clothes or laundry.
- ✗ **DO NOT** place the heater close to a bath, wash basin, shower, swimming pool or any other water-filled area or wet surface. **DO NOT** get the heater wet or use in areas of high condensation.
- ✗ **DO NOT** place the heater up against any surface such as a wall, door, furniture etc.
- ✗ **DO NOT** place the heater immediately below any electrical outlet.
- ✗ **DO NOT** allow the power lead to touch the radiator surface.
- ✗ **DO NOT** cover the radiator or use it to dry laundry.
- ✗ **DO NOT** switch the heater on whilst the electrical lead is wrapped on the storage bracket.
- ✗ **DO NOT** store the electrical lead until the radiator is cold.
- ✗ **DO NOT** attempt to repair a damaged heater, contact an authorised service agent.
- ✗ **DO NOT** stand on the heater.
- ✗ **DO NOT** touch the heating elements when the heater is on as it becomes very hot.
- ✓ Operators must read this manual or receive adequate training before using the heater.
- ✓ Children should be supervised at all times when the heater is in use.
- ✓ Ensure that the heater is correctly turned off when not in use and store in a safe, dry area, out of reach of children.



fig.1

**NOTE:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

## 2. INTRODUCTION

Oil-filled radiator suitable for office, home, showroom and workshop use. Manufactured to rigorous safety standards and fitted with a 13Amp BS approved plug. Features full thermostatic heat control that cuts power to the heater elements when pre-set temperature is attained and tilt safety switch. Elements designed to maximise area of the heated surface in order to transfer more heat to the atmosphere. Features built-in 24 hour timer allowing the user to programme the time and duration the heater is operated. Fitted with castors for added mobility.

## 3. SPECIFICATION

Model No:.....RD2500T  
 Power:.....2500W  
 Supply:.....230V  
 Timer:.....Yes  
 Size (W x D x H):.....480 x 240 x 624mm  
 Weight:.....12.5kg

## 4. ASSEMBLY

- 4.1. Invert the radiator after removal from packaging, oil should be heard flowing internally under gravity, this is expected and not a problem.
- 4.2. Attach the castor wheels by passing the stud through the underside of the wheel plate and securing with the supplied nut. Mount the castor wheel plate between the first and second element of each end of the radiator. Tighten the wing nuts on the metal "U" bolts; return the radiator to the upright position; oil should be heard flowing internally under gravity and your heater is ready to use when the flowing ceases fig.2.
- 4.3. Check the unit is the correct way up by observing carrier handle apertures are at the top and the cable tidy is at the bottom, also the thermostat "LOW" and "HIGH" instruction is further confirmation.  
**SAFETY FEATURE-** The tilt safety switch will isolate supply if accidentally tipped over or if assembled upside down.




fig.2

## 5. OPERATION

- 5.1. Heating settings fig.3
  - 5.1.1. Unwrap the mains lead and plug it into the power supply.
  - 5.1.2. Turn the thermostat control to the highest setting.
  - 5.1.3. Choose the required heat output by selecting the appropriate switch, this switch will illuminate when pressed.
  - 5.1.4. Low setting:.....Select switch with the Roman Numeral "I".  
 Medium setting:.....Select switch with the Roman Numeral "II". Set switch with "I" to off.  
 High setting:.....Select both switches "I" and "II".
  - 5.1.5. Once the required room temperature has been achieved, turn the thermostat down until the light on the selected heat setting switch goes out. The heater will then keep the surrounding air at the set temperature by switching on and off at intervals. You may reset the thermostat at any time.
  - 5.1.6. To switch the unit off, turn the heat selecting switches off and unplug from the mains. Allow the unit to cool before handling or storage.




fig.3

- 5.1.7. The heater is fitted with a safety tilt switch and a thermostatic safety cut-out which will automatically turn the heater off should it be placed in circumstances that cause overheating or malfunction. Should this happen, switch the heater off and disconnect it from the mains. Allow the heater to cool before handling. Do not use the heater again until the cause has been identified and remedied. If necessary return the heater to your Sealey stockist for servicing.
- 5.1.8. When used for the first time, it is suggested that you set the heater to maximum power for a few minutes in a well ventilated room to eliminate the newness smell, typical of this type of heater.
- 5.2. Timer settings fig.4
  - 5.2.1. Set the 24 hour perimeter clock to the approximate actual time adjacent to the triangle symbol.
  - 5.2.2. The switch in the slot, "I" symbol = on all the time, clock symbol = timed switching, "0" symbol = off all the time.
  - 5.2.3. Each blue "flag" on the dial face represents 15 minutes approximately. Inner positions are bypassed, outer positions switch the heater "on" then "off" at the approximate time settings made by the operator.




fig.4

## 6. MAINTENANCE

- ❑ **WARNING!** Disconnect the heater from the mains power, before servicing or performing any maintenance, which must only be carried out by an authorised service agent with the exception of the following.
  - 6.1. Dust the radiator (when cold) with a dry cloth.
  - 6.2. **DO NOT** use a strong abrasive to clean the radiator.
  - 6.3. When storing the heater, use the original shipping box and store in a safe, dry location.
    - Note:** Report any oil leakage immediately to an authorised service agent.

### ENVIRONMENT PROTECTION



Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

### WEEE REGULATIONS



Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk