


Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.




**IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS, AND CAUTIONS. USE THIS PRODUCT CORRECTLY, AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY.**

### 1. SAFETY INSTRUCTIONS

#### 1.1 ELECTRICAL SAFETY

- ☐ **WARNING!** It is the responsibility of the owner and the operator to read, understand and comply with the following:
  - You must check all electrical products, before use, to ensure that they are safe. You must inspect power cables, plugs, sockets and any other connectors for wear or damage. You must ensure that the risk of electric shock is minimised by the installation of appropriate safety devices. A Residual Current Circuit Breaker (RCCB) should be incorporated in the main distribution board. We also recommend that a Residual Current Device (RCD) is used. It is particularly important to use an RCD with portable products that are plugged into a supply which is not protected by an RCCB. If in any doubt consult a qualified electrician. You may obtain a Residual Current Device by contacting your Sealey dealer.
  - You must also read and understand the following instructions concerning electrical safety.
- 1.1.1 The Electricity at Work Act 1989 requires that all portable electrical appliances, if used on business premises, are tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.
- 1.1.2 The Health & Safety at Work Act 1974 makes owners of electrical appliances responsible for the safe condition of those appliances and the safety of the appliance operators. If in any doubt about electrical safety, contact a qualified electrician.
- 1.1.3 Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply. See 1.1.1 and 1.1.2 and use a Portable Appliance Tester.
- 1.1.4 Ensure that cables are always protected against short circuit and overload.
- 1.1.5 Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that none is loose.
- 1.1.6 Important: Ensure that the voltage marked on the appliance matches the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating at right.
- 1.1.7 **DO NOT** pull or carry the appliance by the power cable.
- 1.1.8 **DO NOT** pull the plug from the socket by the cable.
- 1.1.9 **DO NOT** use worn or damaged cables, plugs or connectors. Immediately have any faulty item repaired or replaced by a qualified electrician. When a BS 1363/A UK 3 pin plug is damaged, cut the cable just above the plug and dispose of the plug safely. Fit a new plug according to the following instructions (UK only).
  - a) Connect the GREEN/YELLOW earth wire to the earth terminal 'E'.
  - b) Connect the BROWN live wire to the live terminal 'L'.
  - c) Connect the BLUE neutral wire to the neutral terminal 'N'.
  - d) After wiring, check that there are no bare wires, that all wires have been correctly connected, that the cable outer insulation extends beyond the cable restraint and that the restraint is tight. Double insulated products, which are always marked with this symbol , are fitted with live (brown) and neutral (blue) wires only. To rewire, connect the wires as indicated above - **DO NOT** connect either wire to the earth terminal.
- 1.1.10 If an extension reel is used it should be fully unwound before connection. A reel with an RCD fitted is preferred since any appliance plugged into it will be protected. The cable core section is important and should be at least 1.5mm<sup>2</sup>, but to be absolutely sure that the capacity of the reel is suitable for this product and for others which may be used in the other output sockets, we recommend the use of 2.5mm<sup>2</sup> section cable.



#### 1.2 GENERAL SAFETY

- ✓ Disconnect the heater from the mains power when not in use, and before servicing or performing any maintenance.
- ✓ Use the heater in dry areas only. Do not use in wet or high condensation locations such as bathrooms, showers, or pools.
- ☐ **WARNING!** If a heater falls into water, immediately switch off at the mains and disconnect from the mains power supply. **DO NOT** touch the heater until the mains power supply has been disconnected.
- ✓ Always disconnect the heater from the power supply when moving it from one location to another.
- ✓ Keep the heater clean and maintain in good condition (use an authorised service agent).
- ✓ Use recommended parts only (non genuine parts may be dangerous, and will invalidate your warranty).
- x **DO NOT** stand the heater where it may be knocked over or off a surface, or where the lead may cause a person to trip.
- x **DO NOT** use an extension cord unless it has been approved by an electrical authority.
- x **DO NOT** insert any objects through the heater guard.
- x **DO NOT** allow children to operate the heater.
- x **DO NOT** immerse the heater in water or any other liquid.
- x **DO NOT** use the heater outdoors.
- ✓ When not in use store in a safe, dry, childproof location.
- x **DO NOT** cover the heater.




## 2. INTRODUCTION & SPECIFICATION

Slim-line design suitable for floor or desktop operation - ideal when space is at a premium. Push-button heat controls with fan-only option. Switched oscillating mode to improve hot or cold air distribution. Thermal and tip-over cut-out switches for improved safety.

Power: .....1000/2000W      Dimensions: .....600 x 230 x 230mm  
Supply: .....230V – 13A      Weight: .....3.4kg

## 3. ASSEMBLY



- Your Tower Fan heater is supplied fully assembled with the exception of the base which comes in two halves. Please follow the assembly instructions carefully.

### 3.1 ASSEMBLY

- 3.1.1 Feed the mains cable through the large section of the base and slot the smaller section on, via the clips located on the adjoining edges (fig 1).
- 3.1.2 Secure the heater assembly to the base by means of the screws supplied, the screw holes are located on the underside of the base.
- 3.1.3 Secure the loose cable into the cable clamp located at the rear of the underside of the base.

## 4. OPERATION

- **WARNING! DO NOT** operate the heater without the base attached. Do not operate the heater lying on its side.
- ✓ Place the fan in the area where it is to be used using the recessed carrying handle at the back of the unit and plug it into the mains supply.

### 4.3 OPERATION


4.3.1 To operate simply push the power button down into the "ON" position and select the heat setting you require.

4.3.2 There are three settings for the heater:

- 1) Cold air - both heat buttons in the OFF (UP) position
- 2) Warm air - first heat button depressed (I).
- 3) Hot air - both heat buttons depressed (I + II).

### 4.4 OSCILLATION

4.4.1 During use the heater can be made to turn from side to side. To commence oscillation push the oscillation (OSCI) button down. To stop oscillation push the button again to return to its "OFF" position (up).



## 5. MAINTENANCE

### 5.1 REPAIRS

5.1.1 If any problems are experienced with the unit, take it to an authorised service centre for repair or maintenance. Do not attempt to service the unit yourself. This can only be done by an authorised service agent.

### 5.2 CLEANING

5.2.1 If the unit requires external cleaning make sure it is switched off and unplugged from the mains supply. Use a soft tissue or cloth for general cleaning. To remove more persistent dirt or grime, wipe down with a soft cloth and warm soapy water. Do not use solvents or abrasive materials to clean the unit.

**Declaration of Conformity** We, the sole importer into the UK, declare that the product listed here is in conformity with the following standards and directives.

**TOWER FAN HEATER**  
Model: STH2000  
73/23/EEC Low Voltage Directive  
89/336/EEC EMC Directive



The construction file for this product is held by the Manufacturer and may be inspected, by a national authority, upon request to Jack Sealey Ltd.

Signed by Mark Sweetman

14th June 2005

For Jack Sealey Ltd.  
Sole importer into the UK  
of Sealey Power Products.

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of this equipment. **WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim. **INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

**SEALEY POWER PRODUCTS**

Sole UK Distributor, Sealey Group, Bury St. Edmunds, Suffolk.



01284 757500



01284 703534



www.sealey.co.uk



sales@sealey.co.uk