

# PROGRAMMABLE AUTOMOTIVE SCOPE METER TA220

**User's Manual**

S2800\_E200611\_R00



**Programmable  
Automotive Scope**

# Contents


<b>1. Easy Manual .....</b>	<b>1-1</b>
1.1. Turning on and off.....	1-1
1.2. Division, Trigger and Function key.....	1-2
1.3. Input Terminals .....	1-2
1.4. Command, Arrow, Backlight and Help key.....	1-2
1.5. Primary Menu Map .....	1-3
1.6. Positioning the waveform on the screen .....	1-3
1.7. Division key map.....	1-4
1.8. Changing Vertical (A/div or B/div) division .....	1-4
1.9. Changing Horizontal division .....	1-5
1.10. Trigger key map.....	1-5
1.11. Trigger level control .....	1-6
1.12. Function key map .....	1-6
1.13. Sensor tests.....	1-7
1.14. Actuator tests.....	1-7
1.15. Ignition & Electrical .....	1-8
<b>2. Test Examples .....</b>	<b>2-9</b>
2.1. Battery Voltage test.....	2-9
2.2. O2 Sensor (Oxygen Sensor) .....	2-11
<b>3. Introduction .....</b>	<b>3-1</b>
3.1. Main Features.....	3-1
3.2. Unpacking the Test Tool Kit.....	3-1
3.3. Specification .....	3-2
3.3.1. General Specifications .....	3-2
3.3.2. Technical Specification.....	3-3
<b>4. Product Description.....</b>	<b>4-1</b>
4.1. LCD Area .....	4-2
4.2. Keys Area .....	4-3
4.3. Terminal Area.....	4-8
<b>5. Using the METER .....</b>	<b>5-1</b>
5.1. Safely Using the Test Tool.....	5-1
5.1.1. Attention.....	5-1
5.1.2. Safety Precautions.....	5-1
5.1.3. Powering the METER .....	5-1
5.1.4. Changing Backlight.....	5-1
5.1.5. Making Selections in a Menu .....	5-2
5.1.6. Displaying only CHA .....	5-2
5.1.7. Freezing the screen .....	5-3
5.1.8. Changing the Graphic Representation.....	5-4

5.1.9.	Acquiring the Waveform.....	5-4
<b>6.</b>	<b>Triggering on a Waveform.....</b>	<b>6-1</b>
6.1.	Setting Trigger level (on NORmal trigger mode).....	6-1
6.2.	Making a single acquisition.....	6-1
6.3.	Setting Trigger mode (Tmode).....	6-2
6.4.	Setting AUTO Trigger Level.....	6-2
6.5.	Setting Normal Trigger mode.....	6-3
6.6.	Setting Trigger Slope.....	6-3
<b>7.</b>	<b>Storing and Recalling Screens.....</b>	<b>7-1</b>
7.1.	Storing Screen.....	7-1
7.2.	Recalling Screen.....	7-2
<b>8.</b>	<b>Using RS232 Software.....</b>	<b>8-1</b>
<b>9.</b>	<b>Maintaining the test tool.....</b>	<b>9-1</b>
<b>10.</b>	<b>Automotive test setup.....</b>	<b>10-1</b>
10.1.	SENSOR function test.....	10-1
10.1.1.	ABS sensor.....	10-2
10.1.2.	O2 Sensor.....	10-2
10.1.3.	ECT Sensor.....	10-3
10.1.4.	Fuel Temp.....	10-3
10.1.5.	IAT Sensor.....	10-4
10.1.6.	Knock Sensor.....	10-4
10.1.7.	TP Sensor.....	10-5
10.1.8.	CKP MAG.....	10-5
10.1.9.	CKP LoRes.....	10-6
10.1.10.	CKP HiRes.....	10-6
10.1.11.	CMP MAG.....	10-7
10.1.12.	CMP LoRes.....	10-7
10.1.13.	CMP HiRes.....	10-8
10.1.14.	VSS MAG.....	10-8
10.1.15.	VSS Digital.....	10-9
10.1.16.	MAP Analog.....	10-9
10.1.17.	MAP Digital.....	10-10
10.1.18.	MAF Analog.....	10-10
10.1.19.	MAF HF Digital.....	10-11
10.1.20.	MAF LF Digital.....	10-11
10.1.21.	EGR PFE.....	10-12
10.1.22.	EGR DPFE.....	10-12
10.2.	ACTUATOR Function Test.....	10-13
10.2.1.	Injector C/LIM.....	10-14
10.2.2.	Injector N/LMT.....	10-14
10.2.3.	Injector Positive Negative Positive.....	10-15
10.2.4.	Mixture Solenoid.....	10-15
10.2.5.	EGR Control Sol.....	10-16
10.2.6.	ISC Step Motor.....	10-16
10.2.7.	ISC Motor.....	10-17
10.2.8.	ISC SOL.....	10-17
10.2.9.	Trans Sol.....	10-18




10.2.10.	Turbo Boost Sol .....	10-18
10.2.11.	Glow Plug Amp .....	10-19
10.3.	IGNITION & ELECTRICAL Function Test .....	10-20
10.3.1.	PIP .....	10-21
10.3.2.	SPOUT .....	10-21
10.3.3.	DI Primary .....	10-22
10.3.4.	DI Secondary .....	10-22
10.3.5.	EI Primary .....	10-23
10.3.6.	EI Secondary .....	10-23
10.3.7.	Power Circuit .....	10-24
10.3.8.	VREF Circuit .....	10-24
10.3.9.	Ground Circuit.....	10-25
10.3.10.	Alt Output.....	10-25
10.3.11.	Alternator Field VR.....	10-26
10.3.12.	Alternator Diode.....	10-26
10.4.	Automotive test setup table.....	10-27
<b>11.</b>	<b>Appendices.....</b>	<b>11-1</b>
11.1.	Troubleshooting guide .....	11-1

# 1. Easy Manual




Front View

## 1.1. Turning on and off



Pressing this button for 1 to 2 seconds will turn the unit on.  
Pressing this button again will turn the power off.

## 1.2. Division, Trigger and Function key



### Division key:

Adjusts vertical division or Horizontal division.


### Trigger key:

Adjusts Trigger level.  
Selects Single shot mode.  
Selects trigger setup.

### Function key:

Selects Scope Setup.  
Selects Automotive scope setup.  
Selects general setup

## 1.3. Input Terminals



### Channel A:

You can always use the red channel A for all single input measurements possible with the meter.

### Channel B:

For measurements on two different signals you can use the channel B together with the Channel A.


### Common:

You can use the black common as single ground for low frequency measurements and for ACV, DCV, Ohm, Continuity and RPM measurements

### External trigger:

The EXT.TRIG input accepts external trigger signals.

## 1.4. Command, Arrow, Backlight and Help key



### Command keys:

These four keys are command buttons.  
They are labeled F1-F4. These keys will have various functions.

### Four arrow keys:

These keys serve as the primary means of navigating the instrument's menus and operating displays.

### Display back light:

Press this button to turn on the backlight. To turn the back light off, press this button again.

### Help key:

General information for the test tool is available.

## 1.5. Primary Menu Map

A ◀▶ B ◀▶ Mem Hold

### Default Menu

DIV

A/div B/div H/div Exit

### Division Menu

TRIG

Tlvl Singl Tmode Exit

### Trigger Menu

FUNC

Scope AScop SetUp Exit


Set Up


Sens Actu Ig&El Exit


Ignition & Electrical  
AUTOMOTIVE (ACTUATOR)  
AUTOMOTIVE (SENSOR)  
SCOPE SETUP


### Function Menu


## 1.6. Positioning the waveform on the screen




Pressing  moves the waveform up.

Pressing  moves the waveform down.

Pressing  moves the waveform left.

Pressing  moves the waveform right.

## 1.7. Division key map




Pressing calls up the default division menu.

Press to control the Channel B Vertical Division.

Press to change the Horizontal Division.

Press to exit.

## 1.8. Changing Vertical (A/div or B/div) division




Pressing button increases CHA vertical division (A/div).

Pressing button decreases CHA vertical division (A/div).

Pressing or key will change Div from MANUAL to AUTO (A).

## 1.9. Changing Horizontal division




Pressing button increases Horizontal division (H/div).

Pressing button decreases Horizontal division (H/div).

Pressing or key will change Div from MANUAL to AUTO(A).  
 Pressing key will change Div from AUTO to MANUAL(M).

## 1.10. Trigger key map




Press key to display the TRIGGER default menu.


Press key for Single shot mode.


Press key for TRIGGER SETUP.

Press to exit.


## 1.11. Trigger level control





Pressing  button increases the Trigger level.


Pressing  button decreases the Trigger level.


## 1.12. Function key map



Press  key to display the FUNCTION default menu.


Press  key for SCOPE SETUP.

Press  key for AUTOMOTIVE SCOPE SETUP.

Press  for general SETUP.


Press  to exit.

## 1.13. Sensor tests



- ① Press **F1** key to display automotive sensor tests.
- ② Press **F2** key for more sensor tests.
- ③ Press **F1** key for previous sensor tests.
- ④ Press **F4** to exit.


## 1.14. Actuator tests



- ① Press **F2** key for Actuator tests.
- ② Press **F4** to exit.



## 1.15. Ignition & Electrical




- ① Press  key for Ignition & Electrical tests.
- ② Press  to exit.

## 2. Test Examples


### 2.1. Battery Voltage test




Battery location and test



Press **I/O** for about 2 sec. to turn on the meter.  
 Insert the black lead in the COM input sockets.  
 Insert the red lead in the CHA input sockets.



Connect the black probe to the negative (-) circuit or to ground.  
 Connect the red probe to the circuit coming from the power source.




Check the measurement voltage.

**Note**


If the meter reads negative, the battery has been reverse charged (has reversed polarity) and should be replaced, or the meter has been connected incorrectly.

Battery voltage (V)	State of charge
12.6 or higher	100% charged
12.4	75% charged
12.2	50% charged
12.0	25% charged
11.9 or lower	Discharged

## 2.2. O2 Sensor (Oxygen Sensor)




O2 Sensor location and test



Press **I/O** for 3 seconds to turn on the meter.


Insert the black lead in the COM input sockets.

Insert the red lead in the CHA input sockets.




Press **FUNC**.


Press **F2** (ASCOP).




Press **F1** (Sens)




Automotive (SENSOR) is displayed as left.



Select O2sensor by using  button.


Press **F3** (Set) button.

Press **F4** button to return to the default menu.




Default menu is displayed as left.

Press **F3** (MEM) button to display the memory menu as below.




Memory menu is displayed as left.




Pressing **F3** (R/WFM) button displays the General O2 Sensor waveform as left.

Press **F4** button to return to the default menu.




O2 sensor waveform is displayed in the default menu.



Connect the black test lead to engine chassis.

Connect the red test lead to O2sensor output.



Compare measurement waveform with general O2 Sensor waveform.

**Note**

- 1) Refer to Easy manual for changing the Vertical division or Horizontal division.
- 2) Refer to Easy manual for triggering on a waveform.

**Note**

The oxygen sensor output voltage is used to control the fuel system air/fuel ratio. The output of the sensor varies depending on the oxygen level sensed in the engine exhaust gases and the operation of the closed loop fuel system.

# 3. Introduction

## 3.1. Main Features

This Programmable Automotive Scope Meter offers enhanced features that similar type test instruments on the market today don't have. All the functions are designed to be very convenient to use. You can quickly get used to working with this METER and the great many functions integrated inside. This instrument features:

No	Features
1	<b>RS-232C</b> interface for transferring measurement data and waveform.
2	<b>45 short reference</b> waveform memory:
3	<b>Dual Channel</b> and Auto Calibration.
4	<b>Automatically setting</b> for horizontal and vertical division.
5	<b>Sampling Time:</b> Single CH: 50MHz, Dual CH: 25MHz
6	DC to 1MHz oscilloscope band width
7	Built-in auto ranging <b>True-RMS</b> digital MultiMeter.
8	Test for checking component signals on sensor, actuators, ignition and electrical.
9	Real time Update and Auto range.
10	Data holds and run mode.
11	Back light display and Low battery indication.
12	Display Type: Super-Twist 132 x 128 pixels.
13	Designed to comply with safety standard for UL3111, CSA C22.2 No.1010-1

## 3.2. Unpacking the Test Tool Kit

The following items are included in your test tool kit.

### ■ STANDARD

#	Description <Cont.>
1	Industrial Scope Meter Test Tool <1>
2	Holster <1>
3	Ni-MH Battery Pack (installed) <1>
4	AC Power & Rechargeable Adaptor <1>
5	Test Leads <2>
6	Users Manual (this book) <1>
7	RS-232 Cable <1>
8	Scope Meter Software for Windows <1>
9	Carrying case <1>

### ■ OPTION

#	Description <Cont.>
1	Inductive Pick-up <1>
2	Capacitive Pick-up <1>

### Note:

When new, the rechargeable Ni-MH battery pack is not fully charged. The accessories may be changed to improve the product quality without notifying the customers.



## 3.3. Specification

### 3.3.1. General Specifications

- 1) Operational Temperature:  
0°C to +50°C (+32°F to +122°F) at a relative humidity 75% or less
- 2) Storage Temperature:  
-20°C to +60°C with a relative humidity of 75% less
- 3) Temperature Coefficient:  
0.1 x (Specified Accuracy) per °C for temperature <18°C to >28°C
- 4) Max. Voltage between any Input and Ground: DC or AC 600Vrms
- 5) Basic DC Accuracy: 0.3%
- 6) Band width: 1MHz
- 7) Meter AC Band width: 20kHz
- 8) Power Supply: Ni-MH Battery 4.8V (1.2V x 4 cell)
- 9) Battery Life Time:  
4 Hours without Backlight on,  
3 Hours with Backlight on.
- 10) Battery Charge Time: About 3 Hours
- 11) Battery Charge:  
Class-2 transformer,  
Input: 120V AC 60Hz (or 240V AC 60Hz)  
Output: 9V DC 1A
- 12) Display Type: Super-Twist 132 x 128 pixels
- 13) Equipment Dimensions:  
90 mm (width) x 195 mm (depth) x 40 mm (height)
- 14) Equipment Weight: 1.0 lbs. (480g) approx. without Holster

### 3.3.2. Technical Specification

#### 1) Oscilloscope Function

##### (1) Horizontal

Sample Rate	50 MS/s (Single CH mode), 25 MS/s (Dual CH mode)
Record Length	512 single shot mode, 256 in all modes
Sample / Division	25
Modes	Single shot, Roll, Normal
Accuracy	0.01%
Sweep Rate	1uS to 5S in 1, 2, 5 sequence

##### (2) Vertical

Bandwidth	1MHz
Resolution	8 Bit
Channels	Dual
Coupling	AC, DC
Input impedance	1 M $\Omega$
Accuracy	3% $\pm$ 1Pixel
Max. Input Volts	DC or AC 600Vrms
Volt / Division	0.5V to 500V in 1, 2, 5 sequence and 500V to 50kV for Ignition Secondary

##### (3) Triggering

Type	CHA, CHB, External
Coupling	AC, DC
Slope	Rising ( $\uparrow$ ) or Falling ( $\downarrow$ ) edge
Internal Trigger Sensitivity	2 / 20 Division

##### (4) Waveform Memory

Waveform Memory	8 Shots
REF Wave From Memory	45 Shots

## 2) Digital MultiMeter Function

### DC V

Scope V/Div	DMM Range	Resolution	Accuracy	Impedance
0.5, 1, 2	5V	0.001V	±(0.3%+3)	1 MΩ
5, 10, 20	50V	0.01V		
50, 100, 200	500V	0.1V	±(0.5%+5)	
500	1000V	1V		

### AC V

Scope V/Div	DMM Range	Resol.	Accuracy (Hz)			Imped.
			50~450	0.45k~5k	5k~20k	
0.5, 1, 2	3V	0.001V	±(0.75%+5)	±(2%+5)	±(2.5%+5)	1 MΩ
5, 10, 20	30V	0.01V				
50, 100, 200	300V	0.1V				
500	750V	1V		N/A		

### OHM

Range	Resolution	Accuracy	Over Load Protection
5 kΩ	0.001 kΩ	±(0.5%+5)	600V DC or AC rms
50 kΩ	0.01 kΩ		
500 kΩ	0.1 kΩ		
5 MΩ	0.001 MΩ	±(0.75%+10)	

### Continuity Buzzer


Test Voltage	Threshold	Over Load Protection
1.7V	100 digits	600V DC or AC rms

### RPM

Function	Range	Resolution	Accuracy
RPM	120 - 12,000	1RPM	± 2RPM
% Duty	1% - 98%		
Dwell	3.6° - 352.8°		
Pulse Width	2 uS - 450 mS (Pulse Width > 2 uS)		
Frequency	2Hz - 1MHz		

# 4. Product Description


In this chapter, the LCD, front panel buttons, controls and terminal are described.







[Front View]

## 4.1. LCD Area

The screen is divided into five areas: Indicator area, Reading area, Waveform area, Setting area and Menu area. Refer to Figure below.



### 1) Indicator

- **HOLD**: Freezes display in the LCD
- **REMOTE**: RS232 Output indicator
- **BACK LIGHT**(): Back light indicator
- **BUZZER**(): Buzzer indicator
- **Charging LINE**(): Charging Battery indicator
- **BATTERY**(): Low battery indicator

### 2) Primary Numerical Field (DMM Function)

Displays the numerical readings. Because only input A is on, you will see the input A readings only.

### 3) Trigger selection

- Channel A, B and External

3-1) Trigger level indicator

3-2) Trigger Cursor

### 4) Trigger Slope

- Rising or Falling edge


### 5) Trigger mode: Normal or AUTO

### 6) Automotive Function

- Sensor
- Actuator
- Ignition
- Electrical

- 7) Memory Address
  - 0 to 7
- 8) Live Scope Display (Channel A)
  - Displays real time waveforms and freezes held captures.
- 9) Channel B or Reference Display
- 10) Channel A Vertical Division
- 11) Channel B Vertical Division
- 12) Horizontal Division (Time base)
- 13) Command Menu Field

## 4.2. Keys Area



### [Keys Area]


- 14) F1 F2 F3 F4 Command Menu keys

All Keys are command buttons. They are labeled F1~F4. These keys will have various functions.

Default (Command Menu)



15)



Arrow keys

Use the black arrow keys to highlight the item.

	The cursor to be changed is moved to up with this button. Pushing the button will increase the value or position.
	The cursor to be changed is moved to down with this button. Pushing the button will decrease the value or position.
	The cursor to be changed is moved to left with this button. Pressing this button changes Vertical division or horizontal division from MANUAL to AUTO.
	The cursor to be changed is moved to right with this button. Pressing this button changes Vertical division or horizontal division from MANUAL to AUTO.

16)

**DIV**

Division key

Set Channel A, B and Horizontal Division

**DIV**

A/div	B/div	H/div	Exit
F1	F2	F3	F4

17)

**TRIG**

Trigger key


Set Trigger level, Single mode and Setup

**TRIG**


TM	Singl	Tmode	Exit
F1	F2	F3	F4

**F3**

TRIGGER SETUP			
SOURCE: <input checked="" type="checkbox"/> CHA <input type="checkbox"/> CHB <input type="checkbox"/> EXT	SLOPE: <input type="checkbox"/> f <input checked="" type="checkbox"/> t		
TRIGGER MODE: <input type="checkbox"/> AUTO <input checked="" type="checkbox"/> NOR			
	Set    Exit		
F1	F2	F3	F4

18)  Back light key

Activates Back Light for the LCD  
Toggles backlight ON and OFF.

19)  Help key

Aids the technician in correct operation and efficient use of the meter.

20)  Power switch

Turns the instrument ON or OFF.





21)  Function Key

Set Scope, Auto Scope and Setup of the METER

---

## FUNC

Scope	AScop	SetUp	Exit
-------	-------	-------	------





   

---

## ▪ Scope Setup

### FUNC→F1 (Scope)

SCOPE SETUP			
INPUT A:		INPUT B:	
<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON
<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF
MEASUREMENTS A:			
<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY
<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL
<input type="checkbox"/> OHM			
SCOPE MODE:			
<input checked="" type="checkbox"/> NORMAL	<input type="checkbox"/> ROLL MODE		
		Set	Exit

---



## ▪ Automotive Scope Sensor

**FUNC→F2 (Automotive Scope)**

Sens	Actu	Ig&EI	Exit
		F1	F2
		F3	F4

**FUNC→F2 (Automotive Scope)→F1 (Sensor)**

AUTOMOTIVE (SENSOR)			
<input type="checkbox"/> ABS Sensor			
<input type="checkbox"/> O2 Sensor			
<input type="checkbox"/> ECT Sensor			
<input type="checkbox"/> FUEL TEMP			
<input type="checkbox"/> IAT Sensor			
<input type="checkbox"/> Knock Sensor			
<input type="checkbox"/> TPS Sensor			
<input type="checkbox"/> CKP Mag			
<input type="checkbox"/> CKP LoRes			
<input type="checkbox"/> CKP HiRes			
<input type="checkbox"/> CMP Mag			
<input type="checkbox"/> CMP LoRes			▼
Prev		Set	Exit
		F1	F2
		F3	F4

**FUNC→F2 (Automotive Scope)→F1 (Sensor)→F2 (More)**

AUTOMOTIVE (SENSOR)			
<input type="checkbox"/> CMP HiRes			
▲			
<input type="checkbox"/> VSS Mag			
<input type="checkbox"/> VSS Digital			
<input type="checkbox"/> MAP Analog			
<input type="checkbox"/> MAP Digital			
<input type="checkbox"/> MAF Analog			
<input type="checkbox"/> MAF HF Digital			
<input type="checkbox"/> MAF LF Digital			
<input type="checkbox"/> EGR PFE Sensor			
<input type="checkbox"/> EGR DPFE Sensor			
Prev		Set	Exit
		F1	F2
		F3	F4

## ▪ Automotive Scope Actuator

**FUNC→F2 (Automotive Scope)**

Sens	Actu	Ig&EI	Exit
		<b>F1</b>	<b>F2</b>
		<b>F3</b>	<b>F4</b>

**FUNC→F2 (Automotive Scope)→F2 (Actuator)**

AUTOMOTIVE (ACTUATOR)			
<input type="checkbox"/>	Injector C/LIM		
<input type="checkbox"/>	Injector N/LM		
<input type="checkbox"/>	Injector PN		
<input type="checkbox"/>	Mixture Control Solenoid		
<input type="checkbox"/>	EGR Control Sol.		
<input type="checkbox"/>	ISC Step Motor		
<input type="checkbox"/>	ISC Motor		
<input type="checkbox"/>	IAC SOL		
<input type="checkbox"/>	Trans Sol		
<input type="checkbox"/>	Turbo Boost Sol.		
<input type="checkbox"/>	Glow Plug Amps.		
		Set	Exit
		<b>F1</b>	<b>F2</b>
		<b>F3</b>	<b>F4</b>

## ▪ Automotive Scope Ignition & Electrical

① **FUNC→F2 (Automotive Scope)**


Sens	Actu	Ig&EI	Exit
		<b>F1</b>	<b>F2</b>
		<b>F3</b>	<b>F4</b>

② **FUNC→F2 (Automotive Scope)→F3 (Ignition & Electrical)**


AUTOMOTIVE (Ignition & Electrical)			
<input type="checkbox"/>	PIP		
<input type="checkbox"/>	SPOUT		
<input type="checkbox"/>	DI Primary		
<input type="checkbox"/>	DI Secondary		
<input type="checkbox"/>	EI Primary		
<input type="checkbox"/>	EI Secondary		
<input type="checkbox"/>	Power Circuit		
<input type="checkbox"/>	VREF Circuit		
<input type="checkbox"/>	Ground Circuit		
<input type="checkbox"/>	Alt Output		
<input type="checkbox"/>	Alt Field VR		
<input type="checkbox"/>	Alt Diode Check		
		Set	Exit
		<b>F1</b>	<b>F2</b>
		<b>F3</b>	<b>F4</b>

## ▪ Setup of the Meter

① FUNC→F3 (Set Up)



## 4.3. Terminal Area



[Terminal Area]

### 22) Terminals description

Look at the bottom of the METER. The METER provides 4 input jacks.

① CHA: Channel A

You can always use the red channel A for all single input measurements possible with the Meter.

② COM: Common

You can use the black COMMON as single ground for DCV, ACV, Ohm, Continuity, frequency and RPM measurements.

③ CHB: Channel B

For measurements on two different signals you can use the channel B together with the red channel A.

④ EXT. TRIG

External trigger.

# 5. Using the METER

## 5.1. Safely Using the Test Tool

### 5.1.1. Attention

Carefully read the following safety information before using the test tool.









### 5.1.2. Safety Precautions

Specific warning and caution statements, where they apply, will be found throughout the manual. A Caution identifies conditions and actions that may damage the test tool. A Warning identifies conditions and actions that pose hazard(s) to the user.

Symbols used on the test tool and in this manual are explained in the next table.


#### **Warning**

To avoid electrical shock, use only specific power supply, Model (Power Adapter used as a Battery Charger).

	See explanation in manual
	Dangerous Voltage
	Double Insulation (Protection Class)
	Earth (Ground)
	Either AC or DC
	DC – Direct Current
	AC – Alternating Current
	Fuse

### 5.1.3. Powering the METER

Follow the procedure to power the Meter from a standard ac outlet.

	Power Adaptor is inserted in to AC outlet.
	Power Adaptor → the Meter.
	Turn the Meter on by pressing this button for about 3 seconds.


The meter powers up in its last setup configurations.

### 5.1.4. Changing Backlight

After power-up, the screen has a high bright display.

To save battery power, the screen has an economic brightness display when operated on the battery pack (no power adapter connected).

To change the brightness of the display, do the following:

	Brighten the backlight.
	Dim the backlight again.






The high brightness increases when you connect the power adapter.

#### **Note**

Using dimmed display lengthens maximum battery power operation time by about one hour.

### 5.1.5. Making Selections in a Menu






Subsequently follow steps ① to ⑤ to open a menu and to choose an item.

	<p>Open the FUNCTION menu.</p> <table border="1" data-bbox="496 353 1034 389"> <tr> <td>Scope</td> <td>AScop</td> <td>SetUp</td> <td>Exit</td> </tr> </table>	Scope	AScop	SetUp	Exit																																								
Scope	AScop	SetUp	Exit																																										
	<p>Open the <b>Scope Setup</b> menu.</p> <table border="1" data-bbox="496 454 1034 869"> <thead> <tr> <th colspan="4">SCOPE SETUP</th> </tr> </thead> <tbody> <tr> <td colspan="2">INPUT A:</td> <td colspan="2">INPUT B:</td> </tr> <tr> <td><input checked="" type="checkbox"/> DC</td> <td><input checked="" type="checkbox"/> ON</td> <td><input checked="" type="checkbox"/> DC</td> <td><input checked="" type="checkbox"/> ON</td> </tr> <tr> <td><input type="checkbox"/> AC</td> <td><input type="checkbox"/> OFF</td> <td><input type="checkbox"/> AC</td> <td><input type="checkbox"/> OFF</td> </tr> <tr> <td colspan="4">MEASUREMENTS A:</td> </tr> <tr> <td><input checked="" type="checkbox"/> DCV</td> <td><input type="checkbox"/> BZ</td> <td><input type="checkbox"/> RPM</td> <td><input type="checkbox"/> DTY</td> </tr> <tr> <td><input type="checkbox"/> ACV</td> <td><input type="checkbox"/> Hz</td> <td><input type="checkbox"/> P/W</td> <td><input type="checkbox"/> DWL</td> </tr> <tr> <td><input type="checkbox"/> OHM</td> <td colspan="3"></td> </tr> <tr> <td colspan="4">SCOPE MODE:</td> </tr> <tr> <td colspan="2"><input checked="" type="checkbox"/> NORMAL</td> <td colspan="2"><input type="checkbox"/> ROLL MODE</td> </tr> <tr> <td colspan="2"></td> <td>Set</td> <td>Exit</td> </tr> </tbody> </table>	SCOPE SETUP				INPUT A:		INPUT B:		<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF	MEASUREMENTS A:				<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY	<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL	<input type="checkbox"/> OHM				SCOPE MODE:				<input checked="" type="checkbox"/> NORMAL		<input type="checkbox"/> ROLL MODE				Set	Exit
SCOPE SETUP																																													
INPUT A:		INPUT B:																																											
<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON																																										
<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF																																										
MEASUREMENTS A:																																													
<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY																																										
<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL																																										
<input type="checkbox"/> OHM																																													
SCOPE MODE:																																													
<input checked="" type="checkbox"/> NORMAL		<input type="checkbox"/> ROLL MODE																																											
		Set	Exit																																										
	<p>Use the arrow keys to highlight the item.</p>																																												
	<p>Select the proper item.</p>																																												
	<p>Exit.</p>																																												

Key:  →  →  →  → 

### 5.1.6. Displaying only CHA






Subsequently follow steps ① to ⑤ to open a menu and to choose an item.

	<p>Open the FUNCTION menu.</p> <table border="1" data-bbox="496 1305 1034 1341"> <tr> <td>Scope</td> <td>AScop</td> <td>SetUp</td> <td>Exit</td> </tr> </table>	Scope	AScop	SetUp	Exit																																								
Scope	AScop	SetUp	Exit																																										
	<p>Open the <b>Scope Setup</b> menu.</p> <table border="1" data-bbox="496 1406 1034 1821"> <thead> <tr> <th colspan="4">SCOPE SETUP</th> </tr> </thead> <tbody> <tr> <td colspan="2">INPUT A:</td> <td colspan="2">INPUT B:</td> </tr> <tr> <td><input checked="" type="checkbox"/> DC</td> <td><input checked="" type="checkbox"/> ON</td> <td><input checked="" type="checkbox"/> DC</td> <td><input checked="" type="checkbox"/> ON</td> </tr> <tr> <td><input type="checkbox"/> AC</td> <td><input type="checkbox"/> OFF</td> <td><input type="checkbox"/> AC</td> <td><input type="checkbox"/> OFF</td> </tr> <tr> <td colspan="4">MEASUREMENTS A:</td> </tr> <tr> <td><input checked="" type="checkbox"/> DCV</td> <td><input type="checkbox"/> BZ</td> <td><input type="checkbox"/> RPM</td> <td><input type="checkbox"/> DTY</td> </tr> <tr> <td><input type="checkbox"/> ACV</td> <td><input type="checkbox"/> Hz</td> <td><input type="checkbox"/> P/W</td> <td><input type="checkbox"/> DWL</td> </tr> <tr> <td><input type="checkbox"/> OHM</td> <td colspan="3"></td> </tr> <tr> <td colspan="4">SCOPE MODE:</td> </tr> <tr> <td colspan="2"><input checked="" type="checkbox"/> NORMAL</td> <td colspan="2"><input type="checkbox"/> ROLL MODE</td> </tr> <tr> <td colspan="2"></td> <td>Set</td> <td>Exit</td> </tr> </tbody> </table>	SCOPE SETUP				INPUT A:		INPUT B:		<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF	MEASUREMENTS A:				<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY	<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL	<input type="checkbox"/> OHM				SCOPE MODE:				<input checked="" type="checkbox"/> NORMAL		<input type="checkbox"/> ROLL MODE				Set	Exit
SCOPE SETUP																																													
INPUT A:		INPUT B:																																											
<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON																																										
<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF																																										
MEASUREMENTS A:																																													
<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY																																										
<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL																																										
<input type="checkbox"/> OHM																																													
SCOPE MODE:																																													
<input checked="" type="checkbox"/> NORMAL		<input type="checkbox"/> ROLL MODE																																											
		Set	Exit																																										
	<p>Highlight OFF of INPUT B to turn off the CHB.</p>																																												
	<p>Select current SCOPE SETUP.</p>																																												
	<p>Exit.</p>																																												






Now, you will see only CHA on the screen.

Key:  →  →  →  → 

1) To choose a **Frequency** measurement for **CHA**, do the following:





















	Plug the <b>black</b> test lead into the <b>COM</b> input jack.																																												
	Plug the <b>red</b> test lead into the <b>CHA</b> input jack.																																												
	Open the <b>FUNCTION</b> menu. <table border="1" style="width: 100%;"> <tr> <td>Scope</td> <td>AScop</td> <td>SetUp</td> <td>Exit</td> </tr> </table>	Scope	AScop	SetUp	Exit																																								
Scope	AScop	SetUp	Exit																																										
	Open the Scope Setup menu. <table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th colspan="4">SCOPE SETUP</th> </tr> <tr> <th colspan="2">INPUT A:</th> <th colspan="2">INPUT B:</th> </tr> </thead> <tbody> <tr> <td><input checked="" type="checkbox"/> DC</td> <td><input checked="" type="checkbox"/> ON</td> <td><input checked="" type="checkbox"/> DC</td> <td><input checked="" type="checkbox"/> ON</td> </tr> <tr> <td><input type="checkbox"/> AC</td> <td><input type="checkbox"/> OFF</td> <td><input type="checkbox"/> AC</td> <td><input type="checkbox"/> OFF</td> </tr> <tr> <th colspan="4">MEASUREMENTS A:</th> </tr> <tr> <td><input checked="" type="checkbox"/> DCV</td> <td><input type="checkbox"/> BZ</td> <td><input type="checkbox"/> RPM</td> <td><input type="checkbox"/> DTY</td> </tr> <tr> <td><input type="checkbox"/> ACV</td> <td><input type="checkbox"/> Hz</td> <td><input type="checkbox"/> P/W</td> <td><input type="checkbox"/> DWL</td> </tr> <tr> <td><input type="checkbox"/> OHM</td> <td colspan="3"></td> </tr> <tr> <th colspan="4">SCOPE MODE:</th> </tr> <tr> <td colspan="2"><input checked="" type="checkbox"/> NORMAL</td> <td colspan="2"><input type="checkbox"/> ROLL MODE</td> </tr> <tr> <td></td> <td></td> <td>Set</td> <td>Exit</td> </tr> </tbody> </table>	SCOPE SETUP				INPUT A:		INPUT B:		<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF	MEASUREMENTS A:				<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY	<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL	<input type="checkbox"/> OHM				SCOPE MODE:				<input checked="" type="checkbox"/> NORMAL		<input type="checkbox"/> ROLL MODE				Set	Exit
SCOPE SETUP																																													
INPUT A:		INPUT B:																																											
<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON																																										
<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF																																										
MEASUREMENTS A:																																													
<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY																																										
<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL																																										
<input type="checkbox"/> OHM																																													
SCOPE MODE:																																													
<input checked="" type="checkbox"/> NORMAL		<input type="checkbox"/> ROLL MODE																																											
		Set	Exit																																										
	Highlight <b>Hz</b> ( <input type="checkbox"/> Hz )																																												
	Select <b>Hz</b> ( <input checked="" type="checkbox"/> Hz )																																												
	Exit.																																												

Observe that **Hz** is now the main reading.

Key:  →  →  →  → 






### 5.1.7. Freezing the screen

You can freeze the screen (all readings and waveforms) at any time.

	<b>Default</b> (Command Menu) Display: <table border="1" style="width: 100%;"> <tr> <td>A </td> <td>B </td> <td>Mem</td> <td>Hold</td> </tr> </table>	A 	B 	Mem	Hold
A 	B 	Mem	Hold		
	<b>Freeze</b> the screen. Highlighted <b>Hold</b> appears at the bottom of the Command Menu area. <table border="1" style="width: 100%;"> <tr> <td>A </td> <td>B </td> <td>Mem</td> <td style="background-color: #cccccc;">Hold</td> </tr> </table>	A 	B 	Mem	Hold
A 	B 	Mem	Hold		
	Resume your measurement <table border="1" style="width: 100%;"> <tr> <td>A </td> <td>B </td> <td>Mem</td> <td>Hold</td> </tr> </table>	A 	B 	Mem	Hold
A 	B 	Mem	Hold		






## 5.1.8. Changing the Graphic Representation

### 1) Changing the vertical division

	Open the Command Menu. A/div   B/div   H/div   Exit
	Change the vertical division. (CH A or CH B)
	Increase the vertical division Div is changed to manual mode.
	Decrease the vertical division. Div is changed to manual mode.
	Change Div from Manual mode to AUTO mode.



Available settings are from 0.5 V/div to 500 V/div in normal mode.

### 2) Changing the Time Base




	Open the Command Menu. A/div   B/div   H/div   Exit
	Change the Horizontal division. A/div   B/div   H/div   Exit
	Increase the number of periods. Div is changed to manual mode.
	Decrease the number of periods. Div is changed to manual mode.
	Change Div from Manual mode to AUTO mode.






Available settings are from 1 uS/div to 5 uS/div in normal mode.

## 5.1.9. Acquiring the Waveform

	Open the <b>FUNCTION</b> menu. Scope   AScope   SetUp   Exit																																												
	Open the <b>Scope Setup</b> menu. <table border="1" data-bbox="501 1435 1034 1854"> <thead> <tr> <th colspan="4">SCOPE SETUP</th> </tr> </thead> <tbody> <tr> <td colspan="2">INPUT A:</td> <td colspan="2">INPUT B:</td> </tr> <tr> <td><input checked="" type="checkbox"/> DC</td> <td><input checked="" type="checkbox"/> ON</td> <td><input checked="" type="checkbox"/> DC</td> <td><input checked="" type="checkbox"/> ON</td> </tr> <tr> <td><input type="checkbox"/> AC</td> <td><input type="checkbox"/> OFF</td> <td><input type="checkbox"/> AC</td> <td><input type="checkbox"/> OFF</td> </tr> <tr> <td colspan="4">MEASUREMENTS A:</td> </tr> <tr> <td><input checked="" type="checkbox"/> DCV</td> <td><input type="checkbox"/> BZ</td> <td><input type="checkbox"/> RPM</td> <td><input type="checkbox"/> DTY</td> </tr> <tr> <td><input type="checkbox"/> ACV</td> <td><input type="checkbox"/> Hz</td> <td><input type="checkbox"/> P/W</td> <td><input type="checkbox"/> DWL</td> </tr> <tr> <td><input type="checkbox"/> OHM</td> <td colspan="3"></td> </tr> <tr> <td colspan="4">SCOPE MODE:</td> </tr> <tr> <td><input checked="" type="checkbox"/> NORMAL</td> <td colspan="3"><input type="checkbox"/> ROLL MODE</td> </tr> <tr> <td></td> <td></td> <td>Set</td> <td>Exit</td> </tr> </tbody> </table>	SCOPE SETUP				INPUT A:		INPUT B:		<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF	MEASUREMENTS A:				<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY	<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL	<input type="checkbox"/> OHM				SCOPE MODE:				<input checked="" type="checkbox"/> NORMAL	<input type="checkbox"/> ROLL MODE					Set	Exit
SCOPE SETUP																																													
INPUT A:		INPUT B:																																											
<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON	<input checked="" type="checkbox"/> DC	<input checked="" type="checkbox"/> ON																																										
<input type="checkbox"/> AC	<input type="checkbox"/> OFF	<input type="checkbox"/> AC	<input type="checkbox"/> OFF																																										
MEASUREMENTS A:																																													
<input checked="" type="checkbox"/> DCV	<input type="checkbox"/> BZ	<input type="checkbox"/> RPM	<input type="checkbox"/> DTY																																										
<input type="checkbox"/> ACV	<input type="checkbox"/> Hz	<input type="checkbox"/> P/W	<input type="checkbox"/> DWL																																										
<input type="checkbox"/> OHM																																													
SCOPE MODE:																																													
<input checked="" type="checkbox"/> NORMAL	<input type="checkbox"/> ROLL MODE																																												
		Set	Exit																																										

### 1) Recording Slow Signals over a Long Period of Time

	Highlight ROLL MODE.
	Set ROLL MODE.
	Exit.




Key:  →  →  →  → 






The roll mode function supplies a visual log of waveform activity and is especially useful when you measure lower frequency waveforms.

#### Note

ROLL MODE operates when the horizontal division is between 1s and 5s

### Selecting AC-Coupling for INPUT A

	Highlight <b>AC</b> for INPUT A.
	Accept <b>AC</b> -coupling for INPUT A.
	Exit.

Key:  →  →  →  → 


Use AC-coupling when you wish to observe a small AC signal that rides on a DC signal.



# 6. Triggering on a Waveform

Triggering tells the METER when to begin displaying the waveform. You can select which input signal should be used, on which edge this should occur and you can define the condition for a new update of the waveform.

The right-top line of the LCD identifies the trigger parameters being used. Trigger icons on the screen indicate the trigger level and slope.



Screen with all Trigger Information

- (1) Trigger Channel: Channel A or B
- (2) Slope: rising or falling
- (3) Trigger mode: Trigger setting mode (Auto or Normal)
- (4) Trigger Level indicator
- (5) Trigger Cursor
- (6) Command Menu: Trigger level
- (7) Command Menu: Single shot
- (8) Command Menu: Trigger mode (Setup)

## 6.1. Setting Trigger level (on NORmal trigger mode)

	Open the <b>Trigger</b> menu
	Adjust the Trigger Level continuously. Observe the trigger icon on the second time division line indicates the trigger level.
	Exit.

Key: → →

## 6.2. Making a single acquisition

To catch single events, you can perform a single shot. (One time screen update.) To set up the test tool for a single shot on the input A waveform, do following:

\* Connect the probe to the signal to be measured.

	Open the default Trigger menu
	Highlight Singl (SINGLE SHOT)
	Test tool performs a single shot. (One time screen update)
	Return to normal Trigger mode.

Key: → →

### 6.3. Setting Trigger mode (Tmode)

	Open the <b>Trigger</b> menu Tlvl  Singl   Tmode   Exit
	Open the <b>Trigger Setup</b> <b>TRIGGER SETUP</b> SOURCE: ■ CHA □ CHB □ EXT SLOPE: □ f ■ t TRIGGER MODE: □ AUTO ■ NOR Set   Exit
	Highlight the <b>ITEM</b> you want.
	Set the <b>ITEM</b> .
	Exit.

Key: → → → →





### 6.4. Setting AUTO Trigger Level






For quick operation, use the **AUTO trigger** mode to trigger on nearly all signals automatically. To optimize trigger slope manually, do the following:

	Open the <b>Trigger</b> menu Tlvl  Singl   Tmode   Exit
	Open the <b>Trigger Setup</b> <b>TRIGGER SETUP</b> SOURCE: ■ CHA □ CHB □ EXT SLOPE: □ f ■ t TRIGGER MODE: □ AUTO ■ NOR Set   Exit
	Highlight <b>AUTO</b> .
	Set <b>AUTO</b> .
	Exit.




Key: → → → →






## 6.5. Setting Normal Trigger mode

	Highlight <b>NOR</b> .
	Set <b>NOR</b> .
	Exit.
	Adjust the Trigger Level continuously. Observe the trigger icon on the second time division line indicates the trigger level.

Key:  →  →  →  → 

## 6.6. Setting Trigger Slope

	Highlight <b>f</b> or <b>l</b> .
	Set <b>f</b> or <b>l</b> .
	Exit.
<b>f</b> or <b>l</b> .	Trigger on either positive Slope or negative Slope of the chosen waveform.

Key:  →  →  →  → 

# 7. Storing and Recalling Screens

You can store setups and waveforms to memory and recall them again from memory. Eight (0-7) setup and waveform memories are available.


Store waveforms when you want to use the present waveform images for future reference.

Store setups when you need the present operating configuration for your future measurements.

\* Refer to Test Examples for Reference Waveform Setup.


## 7.1. Storing Screen

To store a screen, do the following:

<p>Default</p>					
<p>F3</p>	<p>Open the memory (Mem) menu</p> <table border="1" data-bbox="504 1301 1034 1339"> <tr> <td>Sto</td> <td>Rcl</td> <td>R/wfm</td> <td>Exit</td> </tr> </table>	Sto	Rcl	R/wfm	Exit
Sto	Rcl	R/wfm	Exit		
	<p>Memory field (<b>M;0</b>) appears at the top-right corner of the display area.</p>				
<p>Up/Down arrow keys</p>	<p>Select the memory address you want to store in.</p>				
<p>F1</p>	<p>Store the actual screen</p>				

## 7.2. Recalling Screen

To recall a screen, do the following:

<p>Default</p>									
<p>F3</p>	<p>Open the memory menu</p> <table border="1" data-bbox="502 940 1204 1030"> <tr> <td>Sto [Symbol]</td> <td>Rcl [Symbol]</td> <td>R/wfm</td> <td>Exit</td> </tr> <tr> <td>F1</td> <td>F2</td> <td>F3</td> <td>F4</td> </tr> </table>	Sto [Symbol]	Rcl [Symbol]	R/wfm	Exit	F1	F2	F3	F4
Sto [Symbol]	Rcl [Symbol]	R/wfm	Exit						
F1	F2	F3	F4						
<p>Memory field (M;0) appears at the top-right corner of the display area.</p>									
<p>↑ ↓</p>	<p>Select the memory address you want to recall from.</p>								
<p>F2</p>	<p>View the saved screen.</p>								

The image is presented as a picture that can no longer be changed.

## 8. Using RS232 Software

### 1) Hardware and Software requirement:

- (1) IBM PC/XT/AT or Compatible Computer.
- (2) The Windows XP/ME/2000/98/95/NT 4.0 operating system
- (3) Serial Port for Connection with Instrument.

### 2) Installation of supplied software

- (1) Insert the supplied diskette into the Drive A. (or B).
- (2) Click the mouse on "**MY COMPUTER**" or "**FILE MANAGER**" ICON, then Floppy Drive A icon
- (3) When the file names are displayed click on SETUP.EXE.
- (4) Monitor program is installed and create a new directory named "**Model No.**" automatically in Hard Disk.

### 3) Connection of PC and Instrument:

Connect the RS-232 cable to the built-in RS-232 connector in the Instrument and to the PC serial port.

### 4) Communication with PC

This section will help the user load the Meter software correctly.

- (1) Connect the RS232c cable between PC and equipment.  
Start the program by clicking the mouse on the icon.
- (3) Click on the Setup button to open the setup dialog. Then select appropriate Serial Port and Baud Rate and click on the OK button.
- (4) Click on the S TIME button and type in the appropriate sampling time.
- (5) Turn off the equipment.
- (6) Turn on the equipment.
- (7) Click the "**START**" button with mouse to start the program.

**Start:** Starts the program.

**Stop:** Stops the program.

# 9. Maintaining the test tool

## About this Chapter

This chapter covers basic maintenance procedures that can be performed by the user.

## Cleaning the Test Tool

Clean the test tool with a damp cloth and a mild soap to avoid abrasion of text on the test tool. Do not use abrasives, solvents, or alcohol.

## Storing the Test Tool

If you are storing the test tool for an extended period of time, charge the NI-MH battery pack before storing. It is not necessary to remove the battery pack.

## Replacing and Disposing of the NI-MH Battery Pack

### Warning

To avoid electrical shock, remove the test leads and probes before replacing the battery pack.


### Note

This instrument contains NI-MH battery pack. Do not dispose of this battery pack with other solid waste. Used batteries should be disposed of by a qualified recycler or hazardous materials handler.

Contact your authorized Service Center for recycling information.

To replace the battery pack, do the following:

1. Disconnect the test leads and probes both at the source and at the meter.
2. Loosen the screw with a screwdriver.
3. Lift the rear cover away from the test tool.
4. Take the battery pack out of the battery compartment.
5. Remove the battery plug from the connector.
6. Install a new battery pack.
7. Reinstall the rear cover and secure the screw.



Replacing the Battery

# 10. Automotive test setup



Engine

## 10.1. SENSOR function test

- ABS sensor
- O2 Sensor
- ECT Sensor
- FUEL PRESS
- IAT Sensor
- Knock Sensor
- TPS Sensor
- CKP Mag
- CKP LoRes
- CKP HiRes
- CMP Mag
- CMP LoRes
- CMP HiRes
- VSS Mag
- VSS Digital
- MAP Analog
- MAP Digital
- MAF Analog
- MAF HF Digital
- MAF LF Digital
- EGR PFE Sensor
- EGR DPFE Sensor





### 10.1.1. ABS sensor

Measures and compares the alternating current signal from magnetic wheel speed sensor used in Anti Lock Brake Systems.

Path: **FUNC** → **F2** → **F1** → **ABS Sensor**

ABS SENSOR

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal ABS Sensor waveform**



### 10.1.2. O2 Sensor

Measures and compares the oxygen sensor output voltage that is used to control the fuel system air and fuel ratio. The output varies depending on the oxygen level.

Path: **FUNC** → **F2** → **F1** → **O2 Sensor**

O2 SENSOR

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform varies depending on the oxygen level.

**Normal O2 Sensor waveform**



### 10.1.3. ECT Sensor

Measures and compares the signal from coolant temperature sensors.

Path: **FUNC** → **F2** → **F1** → **ECT Sensor**

ECT SENSOR

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform decreases as engine temperature increases.

**Normal ECT Sensor waveform**



### 10.1.4. Fuel Temp

Measures and compares the signal from the fuel temperature sensors.

Path: **FUNC** → **F2** → **F1** → **Fuel Temp**

FUEL PRES

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Check that the fuel temperature changes as the vehicle is operated.

**Normal Fuel Temp waveform**



### 10.1.5. IAT Sensor

Measures and compares the signal from air temperature sensors.

Path: **FUNC** → **F2** → **F1** → **IAT Sensor**

#### IAT SENSOR

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform decreases as the sensor heats up.

**Normal IAT Sensor waveform**



### 10.1.6. Knock Sensor

Measures and compares the alternating current signal from engine knock sensors.

Path: **FUNC** → **F2** → **F1** → **Knock Sensor**

#### KNOCK SENSOR

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Tapping on the engine block near the sensor makes the sensor to produce a voltage.

**Normal KNOCK Sensor waveform**



### 10.1.7. TP Sensor

Measures and compares the waveform of Throttle Position sensors.

Path: **FUNC** → **F2** → **F1** → **TP Sensor**

#### TP SENSOR

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Spikes in the slope of measured waveform indicate a worn TPS carbon track.

**Normal TP Sensor waveform**



### 10.1.8. CKP MAG

Measures and compares the Crankshaft magnetic sensor signal.

Path: **FUNC** → **F2** → **F1** → **CKP MAG**

#### CKP MAG

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal CKP Mag Sensor waveform**



### 10.1.9. CKP LoRes

Measures and compares the Crankshaft low accuracy sensor signal.

Path: **FUNC** → **F2** → **F1** → **CKP LoRes**

CKP LoRes

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal CKP LoRes Sensor waveform**



### 10.1.10. CKP HiRes

Measures and compares the Crankshaft high accuracy sensor signal.

Path: **FUNC** → **F2** → **F1** → **CKP HiRes**

CKP HiRes

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal CKP HiRes Sensor waveform**



### 10.1.11. CMP MAG

Measures and compares the Camshaft magnetic sensor signal.

Path: **FUNC** → **F2** → **F1** → **CMP MAG**

CMP MAG

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal CMP Mag Sensor waveform**



### 10.1.12. CMP LoRes

Measures and compares the Camshaft low accuracy sensor signal.

Path: **FUNC** → **F2** → **F1** → **CMP LoRes**

CMP LoRes

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal CMP LoRes Sensor waveform**





### 10.1.13. CMP HiRes

Measures and compares the Camshaft high accuracy sensor signal.

Path: **FUNC** → **F2** → **F1** → **CMP HiRes**

#### CMP HiRes

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal CMP HiRes Sensor waveform**



### 10.1.14. VSS MAG

Measures and compares vehicle speed sensor-magnetic signal.

Path: **FUNC** → **F2** → **F1** → **VSS MAG**

#### VSS MAG

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal VSS Mag Sensor waveform**



### 10.1.15. VSS Digital

Measures and compares Vehicle Speed Sensor signal - Digital.

Path: **FUNC** → **F2** → **F1** → **VSS Digital**

#### VSS DIGITAL

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal VSS Digital waveform**



### 10.1.16. MAP Analog

Measures and compares signals from MAP sensor with an analog continuous voltage output signal.

Path: **FUNC** → **F2** → **F1** → **MAP Analog**

#### MAP ANALOG

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform rises as the intake manifold absolute pressure rises.

**Normal Map Analog Sensor waveform**





### 10.1.17. MAP Digital

Measures and compares signals from MAP sensor with a digital voltage output signal.

Path: **FUNC** → **F2** → **F1** → **MAP Digital**

MAP DIGITAL

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

**Normal Map Digital Sensor waveform**



### 10.1.18. MAF Analog

Measures and compares the MAF sensors signal with an analog continuous voltage output.

Path: **FUNC** → **F2** → **F1** → **MAF Analog**

MAF Analog

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform rises as more air flows in the engine.

**Normal MAF Analog Sensor waveform**



### 10.1.19. MAF HF Digital

Measures and compares the MAF sensors signal with a high frequency digital output.

Path: **FUNC** → **F2** → **F1** → **MAF HF Digital**

MAF HF DIGITAL

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

Normal MAF HF Digital waveform



### 10.1.20. MAF LF Digital

Measures and compares the MAF sensors signal with a low frequency digital output.

Path: **FUNC** → **F2** → **F1** → **MAF LF Digital**

MAF LF DIGITAL

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Measured waveform should be stable.

Normal MAF LF Digital waveform



### 10.1.21. EGR PFE

Measures and compares an EGR PFE sensor signal used to control the Exhaust Gas Recirculation solenoid valves.

Path: FUNC → F2 → F1 → **EGR PFE**

EGR PFE

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Sensor voltage varies with different engine.

**Normal EGR PFE Sensor waveform**



### 10.1.22. EGR DPFE

Measures and compares EGR-DPFE sensor signals used to control the Exhaust Gas Recirculation solenoid valves.

Path: FUNC → F2 → F1 → **EGR DPFE**

EGR DPFE

BLACK TO SENSOR BODY OR ENGINE (CHASSIS)  
RED TO SENSOR OUTPUT



Sensor voltage varies with different engine.

**Normal EGR DPFE Sensor waveform**

## 10.2. ACTUATOR Function Test

---

- Injector C/LIM
- Injector N/LIM
- Injector PNP
- Mixture Control Sol.
- EGR Control Sol.
- ISC STEP Motor
- ISC Motor
- ISC solenoid
- Trans Shift Sol.
- Turbo Boost Sol.
- Glow Plug Amp.



### 10.2.1. Injector C/LIM

Measures and compares the signal from fuel injection systems that uses C/LIM type.

Path: **FUNC** → **F2** → **F2** → **Injector C/LIM**

INJECTOR C/LIM

BLACK TO NEGATIVE BATTERY TERMINAL  
RED TO NEGATIVE SIDE OF INJECTOR



Verify all injectors are similar.

**Normal Injector C/LIM waveform**



### 10.2.2. Injector N/LMT

Measures and compares the signal from fuel injection systems that uses N/LMT type.

Path: **FUNC** → **F2** → **F2** → **Injector N/LMT**

INJECTOR N/LMT

BLACK TO NEGATIVE BATTERY TERMINAL  
RED TO NEGATIVE SIDE OF INJECTOR



Verify all injectors are similar.

**Normal Injector N/LMT waveform**



### 10.2.3. Injector Positive Negative Positive

Measures and compares the signal from fuel injection systems that uses PNP type.

Path: **FUNC** → **F2** → **F2** → **Injector PNP**

INJECTOR PNP

BLACK TO ENGINE  
RED TO INJECTOR POSITIVE  
CONNECTION



Verify all injectors are similar.

Normal Injector PNP waveform



### 10.2.4. Mixture Solenoid

Measures and compares pulse-width-modulated signals that control fuel mixture solenoids.

Path: **FUNC** → **F2** → **F2** → **Mixture Solenoid**

MIXTURE SOLENOID

BLACK TO ENGINE CHASSIS  
RED TO SOLENOID



Normally duty cycle should be approximately 50%.

Normal Mixture Solenoid waveform



### 10.2.5. EGR Control Sol

Measures and compares Pulse Width Modulated signals that control exhaust gas re-circulation solenoid valves.

Path: **FUNC** → **F2** → **F2** → **EGR Control sol.**

EGR CONTROL SOL

BLACK TO ENGINE  
RED TO SOLENOID



Duty cycle changes with engine conditions.

Normal EGR Control sol. waveform



### 10.2.6. ISC Step Motor

Measures and compares an idle speed control step motor signal.

Path: **FUNC** → **F2** → **F2** → **ISC Step Motor**

ISC STEP MOTOR

BLACK TO ENGINE  
RED TO THE SIGNAL WIRE AT  
ISC CONNECTOR



Check for asynchronous waveform.

Normal ISC Motor waveform





### 10.2.7. ISC Motor

Measures and compares an idle speed control step motor signal.

Path: **FUNC** → **F2** → **F2** → **ISC Motor**

ISC MOTOR

BLACK TO ENGINE  
RED TO THE SIGNAL WIRE AT  
ISC CONNECTOR



Check for asynchronous waveform.

**Normal ISC Motor waveform**



### 10.2.8. ISC SOL

Measures and compare an idle speed control solenoid signal.

Path: **FUNC** → **F2** → **F2** → **ISC SOL**

ISC SOL

BLACK TO ENGINE (CHASSIS)  
RED TO SOLENOID



As the solenoid drive current increases, DC level decreases.

**Normal IAC SOL waveform**





### 10.2.9. Trans Sol

Measures and compares Pulse Width Modulated signals used to control the various pressure valve solenoids found in electronically controlled automatic transmissions.

Path: FUNC → F2 → F2 → **Trans Sol**

TRANS SOL.  
BLACK TO ENGINE  
RED TO SOLENOID



Measures PWM signals used to control the various pressure valve solenoid



**Normal Trans Sol waveform**

### 10.2.10. Turbo Boost Sol

Measures and compares the pulse width modulated signal that controls the solenoid regulating the boost pressure.

Path: FUNC → F2 → F2 → **Turbo Boost**

TURBO BOOST  
BLACK TO ENGINE  
RED TO SOLENOID



Measures PWM signal that controls the solenoid regulating the boost pressure.

**Normal Turbo Boost waveform**

## 10.2.11. Glow Plug Amp



Measures and compares the current draw from glow plugs when the ignition is turned on with a cold engine.

\* You need optional DC clamp adaptor to measure Glow Plug Amp.

Path: **FUNC** → **F2** → **F2** → **Glow Plug Amp.**

TURBO BOOST

CONNECT THE DC CLAMP ADAPTOR TO GLOW PLUG WIRE.



Glow Plug Current is an indicator of proper glow plug function.

**Normal Glow Plug Amp waveform**

## 10.3. IGNITION & ELECTRICAL Function Test

---

- PIP
- SPOUT
- DI Primary
- DI Secondary
- EI Primary
- EI Secondary
- Power Circuit
- VREF Circuit
- Ground Circuit
- Alt Output
- Alt Field VR
- Alt Diode Check



### 10.3.1. PIP

Measures and compares a Profile Ignition Pick-up signal.

Path: **FUNC** → **F2** → **F3** → **PIP**

PIP

BLACK TO ENGINE CHASSIS  
RED TO PIP SIGNAL



Check the timing relationship between reference waveform and measured waveform.

**Normal PIP waveform**



### 10.3.2. SPOUT

Measure and compare a Spark Out signal.

Path: **FUNC** → **F2** → **F3** → **SPOUT**

SPOUT

BLACK TO ENGINE CHASSIS  
RED TO SPOUT SIGNAL  
TEST: RUN THE ENGINE AT DIFFERENT RPM LEVELS OR UNDER LOAD.



Check the timing relationship between reference waveform and measured waveform.

**Normal SPOUT waveform**



### 10.3.3. DI Primary

Measures and compares the ignition waveforms for all cylinders on standard Distributor ignition systems.

Path: **FUNC** → **F2** → **F3** → **DI Primary**

#### DI PRIMARY

BLACK TO ENGINE CHASSIS  
RED TO NEGATIVE SIDE OF  
THE IGNITION COIL



Look for abnormally long or short dwell periods in the waveform.

**Normal DI Primary waveform**

### 10.3.4. DI Secondary



Measures and compares distributor ignition secondary waveforms.

\* You need optional capacitive pick-up to measure DI Secondary.

Path: **FUNC** → **F2** → **F3** → **DI Secondary**

#### DI SECONDARY

CONNECT THE CAPACITIVE  
PICKUP AND INDUCTIVE  
PICKUP



Compare measured waveform  
with reference waveform.

**Normal DI Secondary waveform**



### 10.3.5. EI Primary

Measures and compares electrical ignition primary waveforms.

Path: **FUNC** → **F2** → **F3** → **EI Primary**

#### EI PRIMARY

BLACK TO ENGINE CHASSIS  
RED TO NEGATIVE SIDE OF  
THE COIL PRIMARY



Look for abnormally long or short dwell periods in the waveform.

**Normal EI PRI waveform**

### 10.3.6. EI Secondary

Measures and compares electrical ignition secondary waveforms.



Measures and compares distributor ignition secondary waveforms.

\* You need optional capacitive pick-up to measure EI Secondary.

Path: **FUNC** → **F2** → **F3** → **EI Primary**

#### EI SECONDARY

CONNECT THE CAPACITIVE  
PICKUP AND INDUCTIVE  
PICKUP



Compare measured waveform with reference waveform.

**Normal EI Secondary waveform**



### 10.3.7. Power Circuit

Measures and compares the + 12V battery voltage of a device.

Path: **FUNC** → **F2** → **F3** → **Power Circuit**

#### POWER CIRCUIT

BLACK TO BATTERY -(NEG)  
RED TO POWER CONNECTION



Monitor the +12V battery voltage of a device.

Normal Power Circuit waveform



### 10.3.8. VREF Circuit

Measures and compares the reference voltage of a device.

Path: **FUNC** → **F2** → **F3** → **Vref Circuit**

#### VREF CIRCUIT

BLACK TO ENGINE CHASSIS  
RED TO TEST POINT



Level should not change more than 200 mV under the regular operation.

Normal Vref Circuit waveform





### 10.3.9. Ground Circuit

Measures and compares the ground connection voltage of a device.

Path: **FUNC** → **F2** → **F3** → **Ground Circuit**

#### GROUND CIRCUIT

BLACK TO BATTERY – (NEG).  
 RED TO GROUND  
 CONNECTOR OF THE  
 SENSOR OR TEST POINT.  
 TEST: RUN THE ENGINE.



Monitor the voltage drop that should be less than 0.1V.

Normal Ground Circuit waveform



### 10.3.10. Alt Output

Measures and compares the alternator output voltage with the engine running.

Path: **FUNC** → **F2** → **F3** → **Alt Output**

#### ALT OUTPUT

BLACK TO BATTERY – (NEG)  
 RED TO BATTERY + (POS)



Conduct this test with engine running and A/C off.

Normal Alt Out waveform





### 10.3.11. Alternator Field VR

Measures and compares the pulse width modulated field control signal used by the alternator to regulate the output.

Path: **FUNC** → **F2** → **F3** → **Alt Field VR**

ALT FIELD VR  
 BLACK TO ENGINE (CHASSIS)  
 RED TO FIELD TEST POINT



Measures PWM field control signal to regulate its output.



Normal Alt F/VR waveform

### 10.3.12. Alternator Diode

Measure and compares alternator diode waveforms  
 Alternator diode allows current to pass in one direction.

Path: **FUNC** → **F2** → **F3** → **Alt Field VR**

ALT DIODE  
 BLACK TO BATTERY – (NEG)  
 RED TO BATTERY +(POS)



If the diodes are defective, it produces high AC voltage.

Normal Alt Diode waveform

## 10.4. Automotive test setup table

#	Sensor tests	Actuator tests	Electrical & ignition
1	ABS Sensor	Injector C/LIM	PIP
2	O2 Sensor	Injector N/LIM	SPOUT
3	ECT Sensor	Injector PNP	DI Primary
4	FUEL TEMP	Mixture ctrl sol	DI Secondary
5	IAT Sensor	EGR CTRL sol	EI Primary
6	Knock Sensor	ISC Step Motor	EI Secondary
7	TPS Sensor	ISC Motor	Power Circuit
8	CKP Mag	ISC Solenoid	VREF Circuit
9	CKP LoRes	Trans shift Sol	Ground Circuit
10	CKP HiRes	Turbo boost sol	Alt Output
11	CMP Mag	Glow plug Amps	Alt Field VR
12	CMP LoRes		Alt Diode check
13	CMP HiRes		
14	Vss Mag		
15	Vss Digital		
16	MAP Analog		
17	MAP Digital		
18	MAF Analog		
19	MAF HF Digital		
20	MAF LF Digital		
21	EGR PFE Sensor		
22	EGR DPFE Sensor		
T	22	11	12

# 11. Appendices

## 11.1. Troubleshooting guide

---

If you experience trouble with your instrument, try these corrective actions before concluding that the instrument needs repair.

1. Make sure you are using fresh NI-MH battery pack or fully charged rechargeable battery pack. If you are using the AC/DC power adapter, make sure the adapter is plugged into an appropriate live power source.
2. If the buttons do not respond to your control or the contrast is set such that the display is unreadable, remove the power source while the instrument is on. Wait 15 minutes and then restore power and try operations.
3. If you still experience difficulty, check your connections and reread the usage instructions.
4. If meter is frozen while you control the trigger level:

If you set the trigger level to normal (NOR) mode, trigger level must be the same level of waveform. Meter does not trigger if trigger level set above or below waveform.

If you set the trigger level to Auto (AT) mode, you do not need to control the trigger level.

In rare cases, your instrument may require servicing. There are no user-serviceable parts inside the instrument. For service, return the instrument to your customer service center.

**MEMO**

