



TM MANUAL VACUUM BRAKE & FLUID EXTRACTOR

PUMP 6L

MODEL NO: **VS836**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instruction
manual



Wear eye
protection



Wear protective
clothing



Wear protective
gloves

1. SAFETY

- ✓ Keep this product in good working order and condition, take immediate action to repair or replace damaged parts.
- ✓ Use approved parts only. Unapproved parts may be dangerous and will invalidate the warranty.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ Keep work area clean and tidy and free from unrelated materials.
- ✓ Ensure the work area has adequate lighting.

IMPORTANT! Ensure that you wear protective clothing, gloves, goggles, face mask as appropriate for the fluid being extracted.

- ✓ **DO NOT** use to perform a task for which it is not designed.
- ✗ **DO NOT** allow untrained persons to use the pump.
- ✗ **DO NOT** use when tired or under the influence of drugs, alcohol or intoxicating medication.
- ✓ After use, clean equipment and store in a cool, dry, childproof area.
- ✓ Dispose of waste liquids in accordance with local authority regulations.
- ✓ Always read and comply with the warnings on the brake fluid container.
- ✓ Wear eye protection and keep skin contact to a minimum. If brake fluid enters eyes rinse with plenty of water and seek medical advice.
- ✓ If swallowed seek medical advice immediately.
- ✗ **DO NOT** pollute the environment by allowing uncontrolled discharge of fluids.
- **WARNING!** Brake fluid is flammable - keep away from sources of ignition, including hot surfaces e.g. exhaust manifold.
- **WARNING!** Brake fluid will damage paintwork. Any spillage should be flushed with water immediately.
- ✗ **DO NOT** use the unit to extract dangerous chemicals, poisons, acids, alkaline or solvents.
- ✗ The container is not designed for long term storage.
- ✗ **DO NOT** store the unit under extreme conditions.
- ✗ **DO NOT** turn the container upside-down when it is holding fluids.
- **WARNING! DO NOT** use with gasoline or other flammable liquids.


2. INTRODUCTION

Brake fluid extractors made from Composite construction ensures durability across automotive, marine and industrial use. Extracts brake fluid and low viscosity fluids including water. Ideal for bleeding or full replacement of brake fluid in the braking system. Does not require dedicated brake reservoir caps. Extraction pipe enables direct fluid removal without spills. Suitable for most brake bleed nipples and ABS systems on cars, vans and motorcycles.

3. SPECIFICATION

Model no VS836
Weight..... 1.322kg

4. CONTENTS (SEE RIGHT)



5. OPERATION

Numbers in brackets refer to Parts Information attached.

5.1. Always consult the vehicle manufacturer's handbook or workshop manual for the recommended procedures below.

5.2. OIL CHANGE SET UP

Screw: oil suction hose (6) onto fluid tank (2) push suction hose (8) into end.
Insert suction tube through dip stick tube until reaching the bottom of oil sump.
Connect suction tube to the main hose of the unit.

NOTE: DO NOT bend the suction tube during the inserting procedure.

Start pumping the handle and the unit will begin to evacuate oil from sump.

5.3. EVACUATE FLUID FROM RESERVOIR SET UP

The unit can be used to evacuate coolant or brake fluid in a reservoir.
Screw: oil suction hose (6) onto fluid tank (2) push suction hose (8) into end.
Open the cap/cover on top of the reservoir. Place suction hose (8) into reservoir.
Start pumping to evacuate fluid in the reservoir.

5.4. BLEED BRAKES SET UP

Screw: oil suction hose (6) onto fluid tank (2), push brake fluid suction hose (9) onto the end.

5.5. POURING OUT WASTE FLUID SET UP

Screw oil spout (7) onto fluid tank (2).
Dispose of fluids according to local regulations in force.

6. MAINTENANCE

- ✗ **DO NOT** store fluids in the fluid tank.
Keep extractor pump clean inside and out.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR
PURCHASE HERE

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • Email: sales@sealey.co.uk • Web: www.sealey.co.uk