

DUCTS MODEL No's: SL1D, SL2D, SL4D

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

1.1. GENERAL SAFETY

- WARNING! Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using these lockers.
- Locate locker in a suitable work area.
- Keep the work area clean, uncluttered and ensure there is adequate lighting.
- WARNING! Use locker on level and solid ground, preferably concrete.
- Keep the locker clean and tidy in accordance with good workshop practice
- Keep children and unauthorised persons away from the work area.
- DO NOT use the locker for any purpose other than that for which it is designed.
- DO NOT use the locker outdoors.
- DO NOT get the locker wet or use in damp or wet locations or areas where there is condensation.
- DO NOT clean the locker with any solvents which may damage the surfaces or the protective coating.

2. INTRODUCTION

2.1. Introduction:

A range of lockers suitable for a variety of commercial applications. Single and two door models fitted with a hanging bar, single door model also has single shelf. Doors on all models are ventilated and fitted with cylinder locks, 2 sets of keys supplied per lock. Supplied flat packed.


2.2. Dimensions:


Width: 380mm, Depth: 450mm, Height: 1850mm.




3. ASSEMBLY

3.1. Lay out the back panel and the two side panels (fig.1). The side panels have a cut-out at the front (fig.2). Fit the left hand side panel to the back panel, secure using the bottom and two middle screws only.







- 3.2. Fit the right hand side panel to the back panel, using the three lower screws only to secure (fig.3).
- Carefully stand the unit up, ensuring that the panels are not 3.3. twisted.




- 3.4. Fit the door frame panel into the unit from the inside locating the frame with the side panels at the top and bottom.
- 3.5. Fit the locker top from the inside with the two holes at the back lined up with the two holes in the back panel.
- 3.6. Bend the tabs in at the front of the top, making sure that they locate into the locking holes in the door frame (figs.4 & 5).







- 3.7. Place the bottom shelf into the locker with the two cut outs facing towards the door (fig.6), push it down into place.
- Carefully tip locker over backwards and lower to the floor. Secure the bottom shelf to the back panel using two screws (fig.7). Stand locker up.




- 3.9. SL1D: Place shelf (different design) onto locating brackets. SL2D and SL4D: All shelves are the same design as the bottom shelf with two cut-outs that face towards the door. Locate each one and push down into place. If required, drill holes and fix shelves in position with a retaining screw (fig.8).
- 3.10. Place hanging bar(s) in position, SL1D and SL2D only (fig.9).





3.11. Insert a lock into hole in each door and position correctly. Secure with nut. Position the lever at the correct angle and secure with screw and washer (fig.10).





NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.







