

H/JIG/8FT USA



trendTM
routing technology

Patent No.:
GB2285410

Dear Customer


Thank you for purchasing this Trend product, we hope you enjoy many years of creative and productive use.

Please remember to return your guarantee card within 28 days of purchase.


CONTENTS

TECHNICAL DATA _____ 1
SAFETY _____ 2-3
ITEMS ENCLOSED _____ 4
ITEMS REQUIRED _____ 4
DESCRIPTION OF PARTS _____ 5
ASSEMBLY _____ 6
 - Setting up the Plunge Router _____ 7
 - Fitting the Router Bit _____ 8
OPERATION
 - Setting the Jig for Hinge Recessing _____ 9-10
 - Routing Hinge Recesses in the Door _____ 11-12
 - Routing Hinge Recesses in the Frame _____ 13-14
 - Fitting the Door _____ 15
MAINTENANCE _____ 15
ENVIRONMENTAL PROTECTION _____ 16
GUARANTEE _____ 15
SPARE PARTS
 - Spare Parts Diagram _____ 16
 - Spare Parts List _____ 16
QUICK START INSTRUCTIONS _____ 1B

The hinge jig will cut apertures to suit the hinge shown. $\frac{3}{8}'' - 1 \frac{3}{8}''$



Example of hinge positions possible using a $4 \frac{1}{2}''$ hinge and a $7' 11''$ door and $8'$ frame.



TECHNICAL DATA

Guide bush diameter		$\frac{5}{8}''$
Hinge length	min.	$2 \frac{3}{4}''$
	max.	$5 \frac{1}{2}''$
Hinge width	min.	$\frac{3}{8}''$
	max.	$1 \frac{3}{8}''$ **
Door height	min.	$7' 11''$
	max.	$8' 0''$
Door thickness	min.	$\frac{5}{8}''$
	max.	$2''$
Weight		8.16 lbs

** A wide hinge can be accomodated if a $1/2''$ overhang offset is used.

The following symbols are used throughout this manual:



Denotes risk of personal injury, loss of life or damage to the tool in case of non-observance of the instructions in this manual.



Refer to the instruction manual of your power tool.

INTENDED USE

This jig allows hinge recesses to be routed in a door or frame with separate stops. It should be used with a portable plunge router with a suitable guide bush and router bit fitted.



If you require further technical information or spare parts, please call our technical support department or visit www.trend-usa.com



IMPORTANT!
Recommended for use with plunge routers only.



The jig will only work on door linings with separate stops or stops thinner than $1/2''$.

SAFETY



WARNING:

Observe the safety regulations in the instruction manual of the power tool to be used. Please read the following instructions carefully. Failure to do so could lead to serious injury. When using electric tools, basic safety precautions, including the following should always be followed to reduce the risk of fire, electric shock and personal injury. Also observe any applicable additional safety rules. Read the following safety instructions before attempting to operate this product.

PLEASE KEEP THESE INSTRUCTIONS IN A SAFE PLACE.

Users must be competent with woodworking equipment before using our products.

IMPORTANT NOTE:

Residual Risk. Although the safety instructions and operating manuals for our tools contain extensive instructions on safe working with power tools, every power tool involves a certain residual risk which cannot be completely excluded by safety mechanisms. Power tools must therefore always be operated with caution!

General

1. Disconnect power tool and attachment from power supply when not in use, before servicing, when making adjustments and when changing accessories such as bits. Ensure switch is in "off" position. Always ensure bit has stopped rotating.
2. Always mount the power tool, accessory or attachment in conformity with the instructions. Only use attachment and accessories specified in the power tool manual. The tool or attachment should not be modified or used for any application other than that for which it was designed. Do not force tool.
3. Keep children and visitors away. Do not let children or visitors touch the tool, accessory or attachment. Keep children and visitors away from work area. Make the workshop child proof with padlock and master switch.
4. Dress properly. Do not wear loose clothing or jewellery, they can be caught in moving parts. Rubber gloves and non-skid footwear is recommended when working outdoors. Wear protective hair covering to contain long hair.
5. Consider working environment. Do not use the product in the rain or in a damp environment. Keep work area well lit. Do not use power tools near gasoline or flammable liquids. Keep workshop at a comfortable

temperature so your hands are not cold. Connect machines that are used in the open via a residual current device (RCD) with an actuation current of 30 mA maximum. Use only extension cords that are approved for outdoor use.

6. The accessory or attachment must be kept level and stable at all times.
7. Keep work area clean. Cluttered workshops and benches can cause injuries. Ensure there is sufficient room to work safely.
8. Secure idle tools. When not in use, tools should be stored in a dry and high or locked up place, out of reach of children.
9. For best control and safety use both hands on the power tool and attachment. Keep both hands away from cutting area. Always wait for the spindle and bit to stop rotating before making any adjustments.
10. Always keep guards in place and in good working order.
11. Remove any nails, staples and other metal parts from the workpiece.
12. Maintain tools and bits with care. Keep bits sharp and clean for better and safer performance. Do not use damaged bits. Follow instructions for lubricating and changing accessories. Keep handles dry, clean and free from oil and grease.
13. Maintain accessories. Do not use damaged accessories. Only use accessories recommended by the manufacturer.
14. Check damaged parts. Before operation inspect the attachment, the power tool, the cord, extension cord and the plug carefully for signs of damage. Check for alignment of moving parts, binding, breakage, mounting and any other conditions that may affect its operation. Have any damage repaired by an Authorised Service Agent before using the tool or accessory. Protect tools from impact and shock.
15. Do not use tool if switch does not turn it on or off. Have defective switches replaced by an Authorised Service Agent
16. Don't over reach. Keep proper footing and balance at all times. Do not use awkward or uncomfortable hand positions.
17. Don't abuse the cord. Never carry power tool or accessory by cord or pull it to disconnect from the socket. Keep cord from heat, oil and sharp edges. Always trail the power cord away from the work area.

18. Connect dust extraction equipment. If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.
19. Check all fixing and fastening nuts, bolts and screws on power tool, attachment and cutting tools before use to ensure they are tight and secure. Periodically check when machining over long periods.
20. Stay alert. Watch what you are doing. Use common sense. Do not operate tools when you are tired, under the influence of drugs or alcohol.
21. Personal Protective Equipment (PPE) for eye, ear and respiratory protection must be worn. All PPE must meet current legislation.
22. Do not leave tools running unattended. Do not leave tool until it comes to a complete stop.
23. Always clamp workpiece being machined securely.
24. Only use cutting tools for woodworking that meet current safety standards, and any subsequent amendments.
25. Vibration levels. Hand held power tools produce different vibration levels. You should always refer to the specifications and relevant safety guidelines.

Routing Safety

1. Read and understand instructions supplied with power tool, attachment and bit.
2. Keep hands, hair and clothing clear of the bit.
3. Remove adjusting keys and wrenches. Check to see that keys and adjusting wrenches are removed from the router tool, bit and attachment before turning router on. Make sure bit can rotate freely.
4. Noise. Take appropriate measures for the protection of hearing if the sound pressure of 85dB(A) is exceeded. Routing sound pressure may exceed 85dB(A), so ear protection must be worn.
5. Eye protection. Always wear eye protection in the form of safety goggles, spectacles or visors to protect the eyes.
6. respiratory protection. Wear a face or dust mask, or powered AIR/PRO. Dust masks/filters should be changed regularly.
7. Do not switch router on with the bit touching the workpiece. At the end of the cut, release the router plunge and allow spindle to stop rotating. Never use the spindle lock as a brake.

8. The direction of routing must always be opposite to the bit's direction of rotation. Do not back-cut or climb-cut.
9. Check before cutting that there are no obstructions in the path of the router. Ensure there are no obstacles beneath workpiece when cutting full thickness, and that a sacrificial work surface is used.

Router Bit Safety

1. Cutting tools are sharp. Care should be taken when handling them. Do not drop bits or knock them against hard objects. Handle very small diameter bits with extra care. Always return bit to its packaging after use.
2. Always use bits with a shank diameter corresponding to the size of the collet installed in your tool.
3. The maximum speed (n.max) marked on the tool, or in instructions or on packaging shall not be exceeded. Where stated the speed range shall be adhered to. Recommended speeds are shown in the Trend Routing Catalogue and/or website.
4. Always use router bits in a router. Drill and boring bits must not be used in a router. Router bits must only be used for the material cutting application for which they are designed. Do not use on metal or masonry.
5. Never use bits with a diameter exceeding the maximum diameter indicated in the technical data of the power tool or attachment used.
6. Before each use check that the cutting tool is sharp and free from damage. Do not use the cutting tool if it is dull, broken or cracked or if in any other damage is noticeable or suspected.
7. Bits should be kept clean. Resin build up should be removed at regular intervals with Resin Cleaner®. The use of a PTFE dry lubricant will reduce resin build up. Do not use PTFE spray on plastic parts.
8. When using stacked tooling (multi-blade, block and groover etc.) on a spindle arbor, ensure that the cutting edges are staggered to each other to reduce the cutting impact.
9. Bit shanks should be inserted into the collet all the way to the line indicated on the shank. This ensures that at least ¾ of the shank length is held in the collet. Ensure clamping surfaces are cleaned to remove dirt, grease, oil and water.
10. Observe the correct assembly and fitting instructions in the router instruction manual for fitting the collet, nut and bit.
11. Tool and tool bodies shall be clamped

in such a way that they will not become loose during operation. Care shall be taken when mounting cutting tools to ensure that the clamping is by the shank of the cutting tool and that the cutting edges are not in contact with each other or with the clamping elements.

12. It is advisable to periodically check the collet and collet nut. A damaged, worn or distorted collet and nut can cause vibration and shank damage. Do not over-tighten the collet nut.
13. Do not take deep cuts in one pass; take several shallow or light passes to reduce the side load applied to the bit and router. Too deep a cut in one pass can stall the router.
14. In case of excessive vibrations whilst using the router stop immediately and have the eccentricity of the router, router bit and clamping system checked by competent personnel.
15. All fastening screws and nuts should be tightened using the appropriate wrench or key and to the torque value provided by the manufacturer.
16. Extension of the wrench or tightening using hammer blows shall not be permitted.
17. Clamping screws shall be tightened according to instructions provided by the manufacture. Where instructions are not provided, clamping screws shall be tightened in sequence from the centre outwards.

Using Routers In A Fixed Position

1. After work, release the router plunge to protect the bit.
2. Always use a push-stick or push-block when making any cut less than 12" in length or when feeding the last 12" of the cut.
3. The opening around the bit should be reduced to a minimum using suitably sized insert rings in the table and closing the back fence cheeks or fitting a false fence on the back fence.
4. Whenever possible use a work holding device or jig to secure component being machined. Ensure any attachment is securely fitted to the workbench, with table surface at approximately hip height.
5. Use a No-Volt Release Switch. Ensure it is fixed securely, easily accessible and used correctly.
6. In router table (inverted) mode, stand to the front right of the table. The bit will rotate counter-clockwise when viewed from top so the feed direction is from the right (against the rotation of the bit). In overhead mode, stand to the front left of the machine table and

the feed direction is from the left.

7. Do not reach underneath table or put your hands or fingers at any time in the cutting path while tool is connected to a power supply.
8. Never thickness timber between the back of the bit and the backfence.







Useful Advice When Routing

1. Judge your feed rate by the sound of the motor. Feed the router at a constant feed rate. Too slow a feed rate will result in burning.
2. Trial cuts should be made on waste material before starting any project.
3. When using some attachments e.g. a router table or dovetail jig, a fine height adjuster is recommended.
4. When using a template guide bush, ensure there is sufficient clearance between bit tip and inside edge of bush and that it cannot come into contact with collet and nut. Ensure bit and guide bush are concentric.

Router Bit Repair/Maintenance

1. Repair of tools is only allowed in accordance with the manufacturers instructions.
2. The design of composite (tipped) tools shall not be changed in process of repair. Composite tools shall be repaired by a competent person i.e. a person of training and experience, who has knowledge of the design requirements and understands the levels of safety to be achieved.
3. Repair shall therefore include, e.g. the use of spare parts which are in accordance with the specification of the original parts provided by the manufacturer.
4. Tolerances which ensure correct clamping shall be maintained.
5. Care shall be taken that regrinding of the cutting edge will not cause weakening of the body and the connection of the cutting edge to the body.

ITEMS ENCLOSED





ITEMS REQUIRED

- 1/4" collet plunge router
- Door clamping device
- Hand tools

DESCRIPTION OF PARTS

- (A) Jig body short (top)
- (B) Jig body short (middle)
- (C) Jig body long (bottom)
- (D) Aperture
- (E) Edge stop location slot
- (F) Swivel end plate
- (G) Bradawl hole
- (H) Euro style guide bush 5/8" with extra long spigot
- (I) Edge stop
- (J) Plastic spacer
- (K) Bradawl
- (L) Screw-on style guide bush 5/8" with extra long spigot.
- (M) T-handle hex key 3mm A/F
- (O) Engraved markings
- (P) Adjustment plate
- (Q) Hinge setting position slot
- (R) Connecting plate with keyhole slot




ASSEMBLY




The jig is in three separate pieces. It is assembled by the use of a one way keyhole slotted connecting plates.

Use the keyhole slot to capture the head of the screw and pull both parts together in the direction shown. Repeat for the third section. Tighten the screw to secure the jig together. A screwdriver will be needed to adjust screw tightness.

Assemble the four pairs of edge stops onto the jigs if not done so already. These should be fitted into the four slots within the jig.



- Put two plastic spacers onto each bradawl blade. Take care of the sharp point. When using bradawls always ensure the two spacers are fitted.




Setting up the Plunge Router

Screw-on Style Guide Bush

This fits directly to a suitable router using the 1-3/16" diameter thread and knurled nut. The accessory sub-base Ref. GB/5/US has been designed to allow the screw-on style guide bush to be used with routers which do not have this fitting as standard. The Ref. GB/5/US can be re-drilled by the user. Please see our website for details.


- Fit the screw-on style guide bush to the base of the router using the knurled nut to secure it.



Euro Style Guide Bush

This fits directly to certain European plunge type routers including Trend and smaller Dewalt machines. To fit the guide bush to other makes and models, a universal sub-base Ref. UNIBASE or circular sub-base Ref. GB/5 can be used. The Ref. UNIBASE is designed to suit the most popular plunge type routers (please see our website for compatibility). The Ref. GB/5 can be re-drilled by the user. The Ref. GB/5/M is designed for Porter Cable routers.

- Fit the guide bush to the base of the router using the screws supplied with the router.
- The Ref. UNIBASE Universal Sub-base has a central recess to allow fitting of the special guide bush Ref. GB160. The sub-base is supplied drilled to fit the most popular makes of routers.



If there is any doubt about the concentricity of the bit relative to the guide bush, then a false sub-base should be used in order to ensure an accurate fit of hinges. For all other makes of router, the sub-base to suit your router will need to be purchased.


Fitting the Router Bit



- The recommended router bit for use with the jig is Ref. C019AX1/4TC.
- The bit must have a 15/32" diameter and a minimum overall length of 2-3/4".
- Unplug router from mains, insert 1" of the shank of the bit into collet and gently tighten collet nut.




The guide bush must be concentric to the router collet assembly and router bit. Please ensure the router bit does not come into contact with the inside of the guide bush before use.



Template Guide Bush Principle

- The cross-section below shows the bit being guided by the guide bush around one of the apertures.



OPERATION




Setting the Jig for Hinge Recessing

The jig has four sets of adjustments which require setting depending on the door size and thickness, as well as the size and positions of the hinges. These are all carried out with the hex key provided with the jig, and with one hinge.

The following setting up operation will only need to be carried out once for a set of doors having the same height dimensions and hinge sizes.


Set up the Width of the Recess for Standard Hinges

- Loosen the edge stop using the hex key.
- Place the knuckle of the hinge in the slot as shown in the diagram, and push in the direction shown.
- Move the edge stop so it butts up against the edge of the hinge.
- Tighten the edge stop by turning hex key clockwise.
- Repeat this sequence for all four edge stops.




For Wide Hinges

For wide hinges ignore the slot and simply place knuckle of the hinge on the edge of the jig to give overhang, move edge stop to hinge and tighten screw.



Setting up the Hinge Length

- The aperture length can be set using the engraved markings and a hinge.
- Loosen the screw so that the adjustment plate is free to slide.
- Align the leaf of the hinge with '0' as shown.
- Slide the adjustment plate so that it touches the edge of the hinge. Tighten the screw with the hex key to secure the adjustment plate in place.
- Repeat this operation for the other hinge apertures as required.



If the length set-up has been done correctly the length of the hinge aperture on the jig should be 5/32" longer than than the length of the actual hinge.

Setting the Depth of the Recess

The depth of the recess must be the same thickness as the hinge or slightly deeper. Most routers are fitted with a depth stop to limit the depth of plunge of the router. Refer to your router's instruction manual for particular details on using the depth stop. The depth of the recess for the hinge is set as follows:

- Release depth gauge on the router.
- Place jig onto the edge of the door.
- Place router onto jig and locate guide bush into one of the apertures of the jig.
- Gently plunge bit through aperture until it touches the edge of the door.
- Lock the router's carriage in this position.
- Move depth gauge up by the thickness of the hinge by:
 1. Either using the depth gauge measurement/dial
or
 2. Placing a leaf of the hinge between the depth gauge and the stop.
- Lock off depth stop and remove hinge.

- Check the depth of the bit is correct by first fully plunging the router and locking the plunge mechanism. Invert the router and place the jig over the guide bush, now check that the bit protrudes past the template the same distance as the thickness of the hinge.

Double check all settings, ensure all screws are tight. Setting up is complete.



Routing Hinge Recesses in the Door



- The door should be laid on its edge with the hanging edge of the door facing upwards. Use the conventional block and wedge to keep the door securely in this position or the Trend door stand Ref. D/STAND/A.
- Place the jig onto the edge of the door. Ensure that the jig is placed the correct way round so that the edge stops are on the knuckle edge of the door. The swivel end plate should be at the top of the door.
- Rotate the swivel end plate through 90° and slide the jig down the door until the swivel end plate touches the top of the door.
- Push the jig up to the door so that the edge stops touch the opening face of the door.
- Without letting the jig move, locate the bradawls into the bradawl holes.
- Hammer the bradawls carefully into the edge of the door until the nylon spacers fitted to the bradawls touch the face of the jig.
- Now plug in the router and place the router with bit and guide bush fitted into the first aperture of the jig.




Check two plastic spacers are on each bradawl before use.



The swivel end plate fixing screw may need to be loosened slightly so that it can swivel.



- Position the guide bush in the corner of the aperture, switch router on and plunge the bit until correct depth is reached. Lock the carriage of the router in this position. Rout around the aperture in a clockwise direction, then remove the waste from the centre of the aperture. See drawings below for direction of cut to prevent breakout.




- Release the carriage of the router and repeat the procedure for the remaining apertures.
- Switch off router and remove jig from door by pulling out bradawls with a twisting action.
- Square off rounded corners of hinge recess with a corner chisel Ref. C/CHISEL and hammer.

**Routing Hinge Recesses
in the Frame**



- No adjustments are necessary to the jig or the router.
- Swivel the end plate through 90°.
- Using the opposite side of the jig, butt the top of the jig into the head of the frame and up against the hanging jamb until the edge stops touch the opening edge of the frame.
- Without letting the jig move, locate the bradawls into the bradawl holes.
- Hammer the bradawls carefully into the door frame until the nylon spacers fitted to the bradawls touch the face of the jig.
- Now plug in the router and place the router with the bit and guide bush fitted, into the first aperture of the jig.




Extra care must be taken when routing top hinge, due to height. Please use safety steps.



Check two plastic spaces are in each bradawl before use.

- Position the guide bush in any corner of an aperture, switch router on and plunge the bit into frame until depth, set by depth stop, is reached. Lock the carriage of the router in this position. Immediately start routing around the aperture in a clockwise direction. Then remove the waste from the centre of the aperture.



- Release the carriage of the router and repeat the procedure for the remaining apertures.
- Switch off router and remove jig from frame by pulling out bradawls with a twisting action.
- Square off rounded corners of hinge recess with a corner chisel Ref. C/CHISEL and hammer.



Release the plunge action on the router after each hinge, as not doing so could result in cutting into the edge of the jig and causing damage. If you damage the jig, an epoxy resin can be used to fill the gap and if rubbed smooth will provide a continuous edge on which the guide bush can follow.

Fitting the Door

- Fit hinges to door and raise upright.
- Use a jack to raise door until hinges align with recess.
- Screw leaves to frame.

Providing procedure is carried out correctly and that the frame/lining is plumb and parallel, then no adjustment should be necessary due to the identical mirror image positioning of the recesses in both the door and the frame.

Other Points

If a larger gap is required to accommodate smoke seal or draft excluder, a packing piece can be temporarily glued or stuck to the swivel end plate in order to utilise the jig in the same technique and achieve accurate results.

Finishing the Frames

The holes left by the bradawls are on both closing edges of the door and frame and are very unobtrusive. These can be easily filled with a matching coloured filler.



MAINTENANCE

This jig has been designed to operate over a long period of time with a minimum of maintenance. Continual satisfactory operation depends upon proper tool care and regular cleaning.

Cleaning

- Regularly clean the jig and remove resin build-up on all threads.

Lubrication

- Your jig requires no additional lubrication.

ENVIRONMENTAL PROTECTION

Recycle raw materials instead of disposing as waste.

Packaging should be sorted for environmental-friendly recycling.


The product and its accessories at the end of its life should be sorted for environmental-friendly recycling.

GUARANTEE

The jig carries a manufacturers guarantee in accordance with the conditions of the enclosed guarantee card.

H/JIG/8FT - SPARE PARTS DIAGRAM

V1.0 09/2009



H/JIG/8FT - SPARE PARTS LIST			V1.0 09/2009
No.	Qty.	Desc.	Ref.
1	1	Jig Body Short (Top) 26"	WP-HJ/8/01
2	1	Jig Body Short (Middle) 26"	WP-HJ/8/02
3	1	Jig Body Long (Bottom) 39"	WP-HJ/8/03
4	1	Swivel Plate	WP-HJ/8/04
5	4	Edge Stop Complete	WP-HJ/8/05
6	4	Machine Screw Countersink M5 x 10mm for Adjustment Plate	WP-HJ/8/06
7	4	Machine Screw Dome M5 x 8mm for Connecting Plate	WP-HJ/8/07
8	1	Connecting Plate	WP-HJ/8/08
9	1	Adjustment Plate	WP-HJ/8/09
10	1	T-Handle Hex Key 3mm A/F	HK/T/03
11	1	Guide Bush Screw-on Style 5/8" Dia.	GB/US/160
12	1	Router Bit 15/32" Dia. Long Shank	C019AX1/4TC
13	1	Guide Bush Euro 5/8" Dia.	GB160
14	8	Plastic Spacer	WP-HJ/08
15	4	Bradawl	WP-HJ/09
16	1	Nut Square M5	WP-NUT/07
17	1	Machine Screw Csk M5 x 16mm Pozij®	WP-SCW/11
18	1	Carry Case	CASE/HJ/A
19	1	Manual	MANU/HJ/8FT

QUICK START INSTRUCTIONS

These instructions are provided for those who are confident with the router and are already familiar with the Hinge Jig.

Setting Up

1. Fit router bit and guide bush to router.
2. Position door with hanging edge uppermost.
3. Adjust two edge stops to width of hinge.

Routing the Door

1. Place hinge jig on hanging edge of door.
2. Rotate the end plate at 90° to jig.
3. Ensure end plate touches end of door.
4. Ensure edge-stops touch opening face of door.
5. Secure jig to door using the two bradawls.
6. Adjust top blocks to position of hinges.
7. Adjust bottom blocks to length of hinges.
8. Adjust depth stop on router to thickness of hinge.
9. Switch router on and locate guide bush into aperture.
10. Plunge down router and rout clockwise.
11. Repeat routing operation for each hinge recess.
12. Chisel corners square by hand to receive hinges or use corner chisel. Ref. C/CHISEL.

Routing the Frame

1. Rotate the end plate until flush with jig.
2. Butt the end plate into the head of frame.
3. Ensure edge-stops touch edge of frame.
4. Secure jig to door frame using the two bradawls.
5. Locate guide bush into aperture and switch router on.
6. Plunge down router and rout clockwise.
7. Repeat routing operation for each hinge recess.
8. Chisel corners square by hand to receive hinges or use a corner chisel Ref. C/CHISEL.



CAUTION

Carefully read through the entire instruction Manual and the entire router Operator's Manual before using the product. Pay close attention to the Safety section and the Safety Symbols. If you use the product properly and only for what is intended, you will enjoy years of safe, reliable service.



WARNING

The safety points should be read and understood and used in conjunction with the instruction manual supplied with the product.



The operation of any router can result in foreign objects being thrown into your eyes, which can result in severe eye damage. Before beginning power tool operation, always wear safety glasses with side shields and a full face shield when needed. We recommend Wide Vision Safety Mask for use over eyeglasses or standard safety glasses with side shields or the Trend Airshield face shield. Always wear eye protection.

MANU/HJ/8FT USA V1



RECYCLABLE

Trend Routing Technology Inc.
Tel: 0044(0)1923 249911
technical@trend-usa.com
www.trend-usa.com