

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT

PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS, AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE, FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY.


1. SAFETY INSTRUCTIONS

- WARNING!** Ensure Health and Safety, local authority and general workshop practice regulations are adhered to when using tools and equipment.
- DO NOT** use the Lever Dial Gauge if damaged.
- Maintain the gauge in good and clean condition for best and safest performance.
- Keep the work area clean, uncluttered and ensure there is adequate lighting.
- Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- Remove ill fitting clothing. Remove ties, watches, rings and other loose jewelry. Contain or tie back long hair.
- Keep children and unauthorised persons away from the work area.

2. INTRODUCTION & SPECIFICATION

Ø31mm Lever dial gauge with rotating zero bezel. The gauge reads 0-40-0 in metric graduations. Includes Ø6 and Ø8mm mounting pins. Supplied in a storage case.

- 1: Dial Face
- 2: Connecting block
- 3: Connecting rod
- 4: Case
- 5: Contact point (lever).



Range: Graduations: Accuracy:

Metric (mm): 0 - 0.8 0.01 0.008

Imperial (in): 0 - 0.03 0.0005 0.0004

3. OPERATION

- WARNING!** Ensure that you have read and understood Section 1 safety instructions before commencing.
- DO NOT** use the gauge if damaged.
- DO NOT** use the gauge for any purpose other than for which it is designed.
- DO NOT** get gauge wet or use in damp or wet locations, or areas where there is condensation. Keep micrometer clean using a dry cotton cloth only.
- DO NOT** dip or submerge the gauge in any type of liquid.
- DO NOT** dis-assemble gauge. The device must be checked by qualified service personnel only.
- DO NOT** apply any voltage to the gauge i.e. with an electric marker pen.
- The gauge is a precision instrument, treat with care, do not subject to knocks or shocks.
- Use gauge in reasonably constant temperature conditions of approximately 20°C
- When not in use, store gauge in a safe, dry, childproof location.
- 3.1 Mount the gauge as required using the connecting blocks/rods if necessary. The connecting blocks simply "slide" onto the edge of the case, along the runners provided. The connecting rods are then rotated clockwise to fix them in position.
- 3.2 If necessary, the lever can be moved through a range of 180° to suit a particular application, but the lever must be parallel to the workpiece ($\pm 5^\circ$).

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including your postcode.

