



INSTRUCTIONS FOR

WET & DRY VACUUM CLEANER 12V

MODEL NO: **CPV100**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
Instruction
Manual

1. SAFETY

- WARNING!** Ensure that Health and Safety, local authority and general workshop practice regulations are adhered to when using this vacuum.
- Never leave the vacuum running unattended. Turn the power off when not in use.
- DO NOT** use the vacuum to pick up the following materials:
 - Burning objects (lit cigarettes, charcoal)
 - Sharp fragments (broken glass)
 - Corrosive solvents
 - Combustable or explosive liquids (petrol or alcohol)
- This vacuum is maintenance free and sealed at the time of manufacture, attempting to open it may cause damage to it.
- DO NOT** pull or carry the vacuum by the cord or the hose.
- DO NOT** operate the vacuum outdoors when it is raining or in wet conditions.
- To prolong the service life of the vacuum allow it to cool down for 30 minutes after each continuous running time of 20 minutes.
- The vacuum must only be operated on a 12V power supply from the accessory socket in the vehicle. **NEVER** connect the vacuum to an AC power source or other DC power supply, it may cause damage to the vacuum or personal injury.
- DO NOT** put the vacuum into water and keep it away from heat sources or direct sunshine.
- After vacuuming water or if the filter has been washed, the water must be removed and the filter screen must be dried.


NOTE: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

2. INTRODUCTION

12V Wet & Dry vacuum cleaner ideal for cleaning vehicles. Unit is powered from a vehicle's cigarette lighter socket and is supplied with brush nozzle, crevice tool and multi-purpose nozzle. Fitted with LED light for cleaning in dark places such as vehicle foot wells and under seats. Innovative design allows this unit to be emptied by the use of one button and the 0.4ltr capacity can be checked using the sight window. Unit is fitted with a removable HEPA filter. Features a 1.5mtr stretchable hose and 3.6mtr power cord, allowing freedom of movement around the vehicle. Supplied with storage bag.


3. SPECIFICATION

Model No:.....**CPV100**
 Supply:.....12V
 Motor power:.....100W
 Capacity:.....0.4ltr
 Weight:.....2.1kg
 Fuse rating:.....10amp




4. OPERATION


- 4.1. Remove vacuum from box and uncoil power cord.
- 4.2. Choose and attach desired suction nozzle: Multipurpose nozzle for general cleaning; Dusting brush for the seats and carpet; Angled nozzle for hard to reach places. The LED light will come on as soon as each nozzle is attached.
- 4.3. Insert the plug into the 12V accessory socket.
- 4.4. Turn on the power switch.
- 4.5. Hold the carrying handle with one hand and the nozzle with the other.
- 4.6. When finished turn the vacuum off, pull the plug out of the accessory socket. Stow the retractable hose. The LED will go out when the suction nozzle is removed from the hose.
- 4.7. **LED Light Cell Replacement**




1. Open cell cover




2. Pull cells out



3. Note their orientation




4. Insert new cells




5. Close cell cover

4.8. Cleaning the filter elements


- 4.8.1. When suction power is weakened or after the vacuum has been used for a long time, the filter screen and the filter element should be cleaned to get the vacuum performance back.




1. Open the filter cover



2. Turn the filter screen clockwise to undo




3. Take out the filter screen




4. Pull the filter element out



5. Clean both the filter screen and element



6. Dry the element and push it straight back on



7. Dry the filter screen and push it back on anticlockwise



8. Close the filter cover

5. MAINTENANCE

- 5.1. Disconnect from power supply before carrying out maintenance.
- 5.2. Empty dustbin periodically to avoid vacuum cleaner failure.
- 5.3. Clean the vacuum with water or mild detergent (wring the wash cloth out before cleaning to prevent water from entering the vacuum).
- 5.4. The vacuum is completely sealed at the time of manufacture. Attempting to open it may result in damage to the unit.
- 5.5. If any repair is required return to your Sealey Dealer.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum cleaner does not work.	Plug is not connected to the power supply or the plug has a poor contact with the Accessory socket.	Check vehicle power supply or plug in again.
	Power switch is not on.	Check and make sure switch is on.
	Blown fuse.	Replace 10A fuse located in front end of plug.
Suction power is low.	Too much dust in filter and dustbin.	Empty dustbin, clean filter refer to section 4.8.
	Low battery power.	Charge or replace car battery.



Environmental Protection



Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain off any fluids (if applicable) into approved containers and dispose of the product and the fluids according to local regulations.

WEEE Regulations



Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Battery Removal



Refer to section 4.7

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.

Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or telephone 01284 757500.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Sole UK Distributor, Sealey Group.
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk.
IP32 7AR



01284 757500



01284 703534



www.sealey.co.uk



sales@sealey.co.uk