

RECHARGEABLE TYRE INFLATOR & POWER BANK WITH WORKLIGHT

MODEL NO: CTI130

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to

1. SAFETY

- WARNING! Read operation instructions before use.
- **DO NOT** leave the unit unattended while in operation.
- Check capacity and maximum inflation pressure of inflatable before commencing inflation.
- ✓ Monitor the pressure gauge while in operation.
- ✓ The gauge should be used as an indication of pressure only. We recommend the use of a dial pressure gauge for definitive reading.
- **WARNING!** This compressor is capable of producing a high pressure.
- **DO NOT** inflate any item beyond its maximum capacity.
- **DO NOT** direct inflation hose connector head at yourself, others or animals.
- **DO NOT** carry by the hose, or yank the hose from an inflation valve.
- DO NOT pull the power cable from the vehicle accessory socket by the power lead.
- **DO NOT** get the compressor wet or use in the rain.
- **DO NOT** use the compressor for a task it was not designed to perform.
- DO NOT operate the compressor if any parts are missing as this may cause failure or possible personal injury.
- DO NOT open the unit.
- ✓ Keep children and non essential persons away from the inflation area.
- ✓ Keep the compressor clean and in good condition.
- ✓ Avoid bending the hose during inflation.
- ✓ Turn off the pump immediately if overheating or any abnormality is observed during operation.
- ✓ If no preset pressure value, DO NOT leave the pump unattended during inflation to prevent the air pressure getting too high.
- ✓ Keep the pump away from any flammable or combustible objects during operation, since the built-in DC motor may generate sparks during operation.
- ✓ Keep the pump away from moisture, sand and shock.
- DO NOT store the pump in extremely cold or hot places. That will shorten product life, damage battery, or deform the structural.
- ✓ Avoid using strong chemicals or detergents to clean the product.
- DO NOT disassemble the product. DO NOT throw the product into fire or household waste.
- **DO NOT** let children use the product.
- DO NOT insert the hose into mouth, ears, or eyes of humans or animals. It must not be used as a toy.
- This compressor is not designed for continuous use. Operation over an extended period of time will overheat the unit and damage the compressor. It should not be used continuously for more than 30 minutes. After 30 minutes, turn it off and let it cool for 15 minutes before resuming operation.

2. INTRODUCTION


Rechargeable unit for portability and quick inflation anywhere. Power bank with USB output 5V 1A ideal for charging mobile phones and portable devices. Suitable for inflating tyres on cars, vans, 4x4s, motorcycles and bicycles. Maximum pressure 120psi. Pressure units psi, kPa, kg/cm² and bar. Auto stop feature. Airflow 0.68CFM 19L/MIN with an inflation time 0-30psi in 342sec (175/70/R13). Backlit LCD digital display. 1W SMD LED work light with strobe and SOS light. The accessory kit includes a 150mm extension tube with Schrader connection, Presta type adaptor, ball spike, inflatables adaptor and a USB charging cable.

3. SPECIFICATION


| Model No: | CTI130 |
|----------------------|--------------------------------|
| Airflow: | 0.68CFM 19L/MIN |
| Battery: | 2000mAh |
| Battery Charge Time: | 3 hours |
| Battery Run Time: | 20 Minutes |
| Hose Length: | 150mm |
| Inflation Time: | 0-30psi in 342sec (175/70/R13) |
| Maximum Air Supply: | 120psi |

| Maximum Current: | 6A | |
|------------------|---------------------------|--|
| Nett Weight: | 0.50kg | |
| Pressure Units: | PSI, kPa, kg/cm² and bar. | |


4. FEATURES / CONTENTS







| 1 | Air hose |
|---|------------------------|
| 2 | Heat resistant hose |
| 3 | Pressure display |
| 4 | Operation button |
| 5 | LED light |
| 6 | USB charging point |
| 7 | Type -C charging point |




5. OPERATION


Press and hold the M button to change the pressure unit, Press: + or - increase or decrease the target pressure (numbers will flash). When you reach the disired pressure push the M button and the numbers will stop flashing. Press M button to start inflation, when disired pressure is reached the machine will stop automatically.

BATTERY DISPLAY


Digital display screen has three battery modes. First battery display: Between 70% and 100%. Second battery display: Between 40% and 70%. Third batterydisplay: Between 10% and 40%




1. Connect air hose to the inflator




2. Screw the air hose to the valve




3. Press and hold for three seconds to turn on the power switch



4. Press to () wake up the screen.




5.Press M button to change the four different modes.




6.Long press M button to change the the pressure unit.



7. Press the + or - to increase or decrease the target pressure..



8. Short press \circlearrowleft to start inflating



9. When pressure reaches target, the unit will stop automatically. To stop inflation at any time press \bullet .Switch off power after use

6. TROUBLESHOOTING

| Problem | Cause | Solution |
|---|--|---|
| Slow inflation | Low battery. Air leakage | Fully charge and try again. Check joints. |
| Inflation failure | Low battery Pressure value higher than preset. | Fully recharge and try again. Set inflator to applicable mode. |
| Unchangeable preset pressure Value | Value set has reached limit for mode set. | Change mode and retry. |
| Pressure valve reads "zero". | Pressure value of the balloons,toy balls etc,could be lower than dectable range. | |
| Battery level indicator not lighting Up when charging | Improper adaptor or cable. | Replace adaptorand recharge with original charging cable. |



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

01284 757500 01284 703534 sales@sealey.co.uk www.sealey.co.uk