

# baridi

---

## **Baridi 15L Mini Fridge Cooler & Warmer 12V/230V Perfect for Car Bedroom, Camping**



### **Model No.s - DH94 (White), DH95 (Black)**

Thank you for purchasing a Baridi product from the Dellonda range. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

DH94, DH95 Issue:1 27/01/22

## Important Information

Please read these instructions carefully and note any safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.



Refer to  
instruction  
manual



Keep unit dry

## About the Product

15L mini fridge/warmer is perfect for road trips and for the home. Ideal for storing cans, food, makeup, cosmetics. Can be used for cooling and warming. Features carry handle making it easy and convenient to move around. Supplied with an AC to DC adaptor, giving you the option to use at home as well in your vehicle with a 12V battery.

## SAFETY INSTRUCTIONS

### • ELECTRICAL SAFETY

- **WARNING!** It is the user's responsibility to check the following:
  - Check all electrical equipment and appliances to ensure that they are safe before using. Inspect power supply leads, plugs and all electrical connections for wear and damage. Dellonda recommend that an RCD (Residual Current Device) is used with all electrical products. You may obtain an RCD by contacting your local domestic stockist. If the product is used in the course of business duties, it must be maintained in a safe condition and should be routinely PAT (Portable Appliance Test) tested.
  - Electrical safety information: It is important that the following information is read and understood.
  - Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
  - Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that they are secure.
  - Important: Ensure that the voltage rating on

the appliance suits the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating in these instructions.

- **DO NOT** pull or carry the appliance by the power cable.
- **DO NOT** pull the plug from the socket by the cable.
- **DO NOT** use worn or damaged cables, plugs or connectors.
- Ensure that any faulty item is repaired or replaced immediately by a qualified electrician.
- This product is fitted with a **BS1363/A** 13 Amp 3 pin plug.
- If the cable or plug is damaged during use, switch off the electricity supply and remove from use.
- Replace a damaged plug with a BS1363/A 13 Amp 3 pin plug. If in doubt contact a qualified electrician.
- Class II products are wired with live (brown) and neutral (blue) only, and are marked with the Class II symbol.



A) Connect the BROWN live wire to the live terminal 'L'.


B) Connect the BLUE neutral wire to the neutral terminal 'N'.

C) Check that there are no bare wires and ensure that all wires are correctly connected.

Ensure that cable outer sheath extends inside the cable restraint and that the restraint is tight

**DO NOT** connect either wire to the earth terminal.

- Baridi recommend that repairs are carried out by a qualified electrician.
- Modern vehicles contain extensive electronic systems. You are required to check with the vehicle manufacturer, for any specific



instructions regarding the use of this type of equipment on each vehicle. No liability will be accepted for damage/injury, where this product is not used in accordance with all instructions.

**• GENERAL SAFETY**

- Leave the unit to stand on a level surface for 6 hours after unpacking and before first switch-on.
- Keep the unit horizontal while it is running.
- Allow 10cm side and 20cm rear space for ventilation.
- Keep the unit dry and away from any heat source.

**• SPECIFICATION**

- Model no's.:.....DH94 (White) DH95 (Black)
- Capacity.....15L
- Power Consumption.....93kWh
- Dimensions (w x d x h).....330 x 260 x 420mm
- Noise Power/Pressure.....53dB



**• OPERATION**

**• COOLING FUNCTION**

The cooler's regulated chiller function lets you chill food and drink. For the best results, It is recommended that items placed in the cooler be pre-chilled to assist the cooler reaching the lowest temperature as quickly as possible. These will hold their temperature. This function is ideal when switching on the appliance and when the outside temperature is warm.

In **ECO** mode, the cooler will automatically regulate the temperature, so as to consume as little electricity as possible. This function is ideal for when the appliance is cold on the inside or the temperature outside is cool. Cooler will continue to operate as long as power is supplied. Contents will stay cool for some time after unit is disconnected or turned off. However, temperature will rise to that of the surrounding air over time. Exercise normal cautions that you would for any food in a

cooling device.

- **DO NOT** put ice or icepacks in the cooler. It will take about 30 minutes to reach the maximum cooling temperature of 15°C below that of ambient (minimum 10°C).

**• HEATING FUNCTION**

The cooler's regulated heater function lets you heat food and drink. This function is ideal when the outside temperature is cold. In **ECO** mode, the cooler will automatically regulate the temperature, so as to consume as little electricity as possible.

This function is ideal when the outside temperature is not very cold.

It is recommended that items placed in the warmer be pre-heated to assist the warmer reaching the highest temperature as quickly as possible. Warmer will continue to operate as long as power is supplied. It will take about 30 minutes to reach the maximum warming temperature of approximately 60°C.

- **NOTE:** The warmer is intended to maintain the temperature of pre-heated food and beverages only. It is not designed to heat up cold items or for storing open containers or liquids.
- **DO NOT** eat or drink perishable items that may have become spoiled without proper temperature control. Move selector switch to the **OFF** position and unplug after use. Empty contents, clean and store in a cool, dry place.
- **DO NOT** switch unit between Cooler and Warmer modes. Turn unit off and wait at least 30 minutes before changing modes.
- **OPERATING THE UNIT 220V** (see fig.1)
- Plug the 220V power cord into the rear of your cooler if using mains power..
- Plug the **AC** 220V plug into the supply.
- Move the switch into the positions for the desired function: **HOT** or **COLD**, and **ECO** mode or **MAX** mode.
- **NOTE:** **ECO** mode is only available when using **AC** power mode.
- The **LED** indicator light, green for cooling red for heating, will illuminate to show the unit is working.
- Place items inside the storage compartment and close the lid.
- **OPERATING THE UNIT 12V** (see fig.1)
- Plug the 12V power cord on rear of your cooler if using accessory socket.
- Plug the 12V **DC** plug into the 12V **DC** socket in your vehicle or other 12V **DC** power supply.
- Move the switch into the position of the

desired function, **HOT** or **COLD**, and **MAX**

- The **LED** indicator light is green for cooling and red for heating. They will illuminate to show the unit is working and which mode it is in.
- Place items inside the storage compartment and close the lid.
- **MAINTENANCE**
- Remove the power plug from the unit when performing cleaning or maintenance.
- **DO NOT** use abrasive or chemical cleaning materials on any surface of the unit.
- Wipe interior and exterior surfaces with a damp cloth and dry thoroughly with a clean dry cloth.
- For more soiled surfaces use a neutral detergent, wipe down with a clean damp cloth and dry thoroughly with a clean dry cloth.
- Wipe the internals dry using a clean, dry cloth to absorb any remaining liquid.



## Environment Protection, Waste Electrical and Waste Electronic Equipment Regulations (WEEE)



Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of its useful life, please dispose of in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.

## Dellonda Limited, Sole UK Distributor of Baridi

Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757575



support@dellonda.co.uk



www.dellonda.co.uk