



# DIGITAL FOOT PUMPS

MODEL NO: FP8D, FP9D

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to  
instructions



Wear eye  
protection



Battery in  
product

## **BATTERY WARNING**

**KEEP OUT OF REACH OF CHILDREN**  
Swallowing can lead to chemical burns, perforating of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.



## 1. SAFETY

### 1.1. BEFORE YOU BEGIN

The device is designed for pumping objects such as tyres, inflatable boats, air beds or balls. It is **NOT** intended for commercial use. Generally acknowledged accident prevention regulations and enclosed safety instructions must be observed. Only perform work described in these instructions for use. Any other use is improper. The manufacturer will not assume responsibility for damage resulting from such use.

**What are the meanings of the symbols used?**



**DANGER! Direct danger to life and risk of injury!** Directly dangerous situation that may lead to death or severe injuries.



**CAUTION! Possible risk of injury!** Dangerous situation that may lead to injuries.

### 1.2. GENERAL SAFETY INSTRUCTIONS

- ✓ To operate this device safely, the user must have read and understood these instructions for use before using the device for the first time.
- ✓ Observe all safety instructions. Failure to do so may cause harm to you and others.
- ✓ Retain all instructions for use, and safety instructions for future reference.
- ✓ If you sell or pass the device on, you must also hand over these operating instructions.
- ✓ The device must only be used when it functions properly.
- ✓ If the product or part of the product is defective, it must be taken out of operation and disposed of correctly.
- ✓ Keep the device out of the way of children and other unauthorised persons.
- ✗ **DO NOT** overload the device.
- ✗ **DO NOT** use the device for purposes for which it is not intended.
- ✓ Exercise caution and only work when in good condition. **DO NOT** use if you are tired, ill, ingested alcohol, medication or drugs.
- ✗ This product is **NOT** intended to be used by persons (including children) or who are limited in their physical, sensory or mental capacities or who lack experience and/or knowledge of the product unless they are supervised, or have been instructed on how to use the product, by a person responsible for their safety.
- ✓ Always comply with all applicable domestic and international safety, health, and working regulations.

### 1.3. DEVICE-SPECIFIC SAFETY INSTRUCTIONS

- ✓ When using for safety-relevant items, for example, car tyres, check the pressure using a calibrated device.
- ✓ For the maximum permitted pressure, observe the manufacturer's guidelines for the item to be pumped.
- ✓ Make sure you are positioned firmly and with a natural stance when working with the device.
- ✓ Only work with good light and visibility.
- ✓ Children should be supervised to ensure that they **DO NOT** play with the device.
- ✗ **DO NOT** remove or cover symbols affixed to the tool.
- ✓ Information on the device that is no longer legible must be replaced immediately.



**DANGER! Risk of injury!** This device may only be put into operation if there are no defects. If a part is defective it must be replaced before the device is used again. Check to make sure the device is in a safe operating condition. Check for visible defects and make sure all components are correctly mounted.



**DANGER! Risk of injury!** When operating the device, ensure both the user and device are balanced comfortably.





**CAUTION! Risk of injury!** Only operate the device with your feet, not with your hands. There is a risk of crushing. A jumping pump may cause injuries. A working pump may generate heat. **DO NOT** touch with bare hands.



## 2. INTRODUCTION

Aluminium framed foot pumps with Ø54 x 116mm barrels. Digital gauge calibrated in psi, bar and kPa. Large LCD screen with easy-to-read display. Fitted with flexible hose length with locking connector. Anti-slip rubber feet for control and safety locks for security.

## 3. SPECIFICATION

		
<b>MODEL NO:</b>	<b>FP8D</b>	<b>FP9D</b>
Accuracy:	±0.8%	±0.8%
Battery Run Time:	Continuous working time: 20 hours	Continuous working time: 20 hours
Battery:	CR2032 (Supplied)	CR2032 (Supplied)
Max. Output Pressure:	140psi	73psi
Nett Weight:	1.54kg	1.92kg
Pressure Units:	Bar, psi, kpa	Bar, psi, kpa

## 4. OPERATION



- 4.1. Insert the supplied battery on the top of the unit, ensuring correct polarity (see fig.2 & 3).
- 4.2. Place the foot pump on a level, stable surface.
- 4.3. Push the foot pad down whilst releasing the safety hooks. Allow the foot pad to slowly rise.
- 4.4. Insert an appropriate adaptor (Schrader/Presta) into the hose connection and lock by applying the locking lever (fig.1).
- 4.5. Connect the foot pump to the tyre valve.
- 4.6. Use the On/Off button (Fig.2) to turn on the digital gauge.
- 4.7. Use the On/Off button to select the display unit (psi, bar, kPa).
- 4.8. Activate the pump evenly with moderate force and allow it to slowly return. Inflate until desire pressure is reached.
- 4.9. Use the safety hook to compress the foot pump after use.
- 4.10. **CHANGING THE BATTERY**  
Slide the battery tray out to install/change the battery. Ensure you insert the battery the correct way up (fig.3).

## 5. MAINTENANCE

- ✓ Replace the battery when the display no longer functions.
- ✓ Dispose of old batteries in accordance to local regulations.
- ✓ Transport in original packaging.
- ✓ Keep the tyre pump clean by wiping with a damp cloth.
- ✗ **DO NOT** allow water ingress into the tyre pump.
- ✗ **DO NOT** use solvents to clean the tyre pump.
- ✓ Store the tyre pump in a well ventilated and dry childproof area.

### 5.1. LIFE TIME OF THE MACHINE/DISPOSAL

Through years of normal wear, the tyre pump will eventually become unserviceable. When this happens ensure that it is disposed of in accordance with local authority regulations.

## 6. BATTERY SAFETY

- 6.1. **SYMPTOMS THAT MAY ARISE FROM BATTERY INGESTION** : No obvious symptoms.  
Unfortunately, it is not obvious when a button or coin battery is stuck in a child's oesophagus (food pipe).  
There are no specific symptoms associated with this. The child might:
  - cough, gag or drool a lot;
  - appear to have a stomach upset or a virus;
  - be sick;

- point to their throat or stomach;
- have a pain in their abdomen, chest or throat;
- be tired or lethargic;
- be quieter or more clingy than usual or otherwise “not themselves”;
- lose their appetite or have a reduced appetite; and
- not want to eat solid food/ be unable to eat solid food.

These sorts of symptoms vary or fluctuate, with the pain increasing and then subsiding.

A specific symptom to button and coin battery ingestion is vomiting fresh (bright red) blood. If the child does this seek immediate medical help.

The lack of clear symptoms is why it is important to be vigilant with “flat” or spare button or coin batteries in the home and the products that contain them.



#### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR  
PURCHASE HERE

#### BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd Batteries Producer Registration Number (BPRN) is BPRN00705.



#### WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

**Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR**



**01284 757500**



**sales@sealey.co.uk**



**www.sealey.co.uk**