



TM

3-IN-1 FOLDING FLOODLIGHT 20W COB LED

MODEL NO: LED15WFL.V2

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instructions

1. SAFETY

1.1. ELECTRICAL SAFETY

USE ONLY THE SUPPLIED USB CABLE FOR CONNECTING FLOODLIGHT TO THE POWER SUPPLY.

GENERAL

- ✓ It is important to ensure that the lamp is fully charged before initial use.
- ✗ **DO NOT** turn the lamp on when it is being charged.
- ✗ **DO NOT** shine directly into your, another person's or an animal's eyes.
- ✗ **DO NOT** allow children to use the lamp.
- ✗ **DO NOT** leave battery in a discharged state. Recharge battery immediately.
- ✓ Recharge the battery at least once every six months of non-use.
- ☐ **WARNING!** Ensure Health and Safety, local authority and general workshop practice regulations are adhered to when using this light. Account for all tools being used and **DO NOT** leave them in or near the engine.

1.2. BATTERY SAFETY

- ☐ **WARNING!** To reduce the risk of burns or fire:
- ✗ **DO NOT** attempt to open, disassemble, modify or service the battery pack.
- ✗ **DO NOT** crush, puncture, short external contacts or dispose of in fire or water.
- ✗ **DO NOT** expose to temperatures above 60°C (140°).

2. INTRODUCTION

Super bright 20W COB LED produces 1100 lumens with a wide spread of light. Built-in M6 thread can be used to mount the worklight on a tripod, perfect for use with the Sealey TRI01 1.5m Telescopic Tripod. Light panels can fold back to back to illuminate the entire work area or opens out to provide focused light in one direction. Features swivel handles on each end with magnets that can be used to attach the light to metal surfaces at any angle required. Also features a fold out hook for hanging the floodlight, for easy hands-free operation. Floodlight can switch between both light panels turned on, or a single panel turned on to best direct light as required. High quality 3.7V 4000mAh lithium-ion battery with up to 4hrs operating time. Easy-to-read charge indicator displays battery level while charging. Charges via a USB Type-C cable (supplied).

3. SPECIFICATION

Model No	LED15WFL.V2
Battery	3.7V Li-ion 4Ah
Charging Time	5-6hr
Colour Temperature	6500K
IP Rating	IP44
LED Type	20W COB LED
Lumen Output	1100lm
Nett Weight	0.370kg
Operating Time	Both Lights/Single Light: 2/4hr

The battery fitted to this lamp is considered to be a consumable item and its ability to accept a charge will reduce over time. We will provide warranty against mechanical and electrical defect for a period of one year - this does not cover fair wear and tear. If the battery is not properly charged before first use, or regularly conditioned, its capacity will diminish. Under these circumstances we will not replace the battery regardless of whether it is less than one year old.

4. OPERATION

- ❑ **WARNING!** Ensure that you read, and fully understand the safety instructions before use.

NOTE: Before initial use, fully charge the unit.

4.1. BATTERY CHARGING

4.1.1. Ensure the floodlight is turned off before charging (fig.1).

4.1.2. Battery charge level is indicated by the LED display (fig.1). During the charging process, individual blue LEDs will activate sequentially, corresponding to the increasing charge levels. Upon reaching full charge, all LEDs will illuminate simultaneously, indicating completion.

4.1.3. When full charge has been reached, unplug the charger cable from the power supply.

4.2. USING THE FLOODLIGHT

4.2.1. Turn floodlight on and off using the mode switch (fig.1) on the main body.

4.2.2. The floodlight has three working modes selected by use of the Mode Selector switch (fig.1).

4.3. LIGHTING MODES

4.3.1. First press: Both lights turn on.

4.3.2. Second press: Only the light opposite the charging port illuminates.

4.3.3. Third press: Only the light on the charging port side turns on.

4.3.4. Fourth press: All lights switch off.

4.3.5. Adjust the position of the light using the ratchet effect built into the joints of the frame.

4.3.6. The light assembly has magnetic feet and a sprung hook see fig.1.

5. MAINTENANCE

- ❑ **WARNING!** Ensure that you read, understand and apply the safety instructions relating to the battery before charging it.

5.1. Ensure the floodlight is turned 'Off' before attempting to charge the battery.

5.2. Wipe down dirty surfaces with damp cloth. **DO NOT** use abrasive or caustic cleaning materials.

5.3. Dispose of broken unit in accordance with local authority battery regulations. **DO NOT** dispose of with regular refuse.


5.4. STORAGE

5.4.1. Store the charger in a safe, dry location.

NOTES:

DO NOT fully discharge the batteries before recharging.

DO NOT leave batteries in a discharged state, recharge batteries immediately. If the floodlight is not in use, recharge the batteries every three months.



Full Upright position. Top or bottom or be all can be illuminated.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR
PURCHASE HERE



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



Li-ion

BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk