

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

1.1. GENERAL

- ✓ Ensure the light is correctly charged before initial use.
- ✗ **DO NOT** turn the light on when it is being re-charged.
- ✗ **DO NOT** shine directly into your, other person's or animal's eyes.
- ✗ **DO NOT** allow children to use the light.
- ✗ **DO NOT** handle or move the light whilst it is being charged.
- ✗ **DO NOT** use the light if you suspect that the battery or the light casing is damaged.
- ✗ **DO NOT** leave battery in a discharged state, recharge battery immediately. If the light is not in use, recharge the battery every month.

1.3. ELECTRICAL SAFETY FOR USE OF CHARGER.

USE ONLY THE SUPPLIED CHARGER PLUG FOR CONNECTING LIGHT TO THE POWER SUPPLY.

- WARNING!** It is the user's responsibility to read, understand and comply with the following electrical instructions:

You must ensure the risk of electric shock is minimised by the installation of appropriate safety devices. An RCCB (Residual Current Circuit Breaker) should be incorporated in the main distribution board. We also recommend that an RCD (Residual Current Device) is used with all electrical products, particularly portable equipment which is plugged into an electrical supply not protected by an RCCB.

You must also read and understand the following instructions concerning electrical safety.

1.3.1. The Electricity At Work Act 1989 requires all portable electrical appliances, if used on business premises, to be tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.

1.3.2. The Health & Safety at Work Act 1974 makes owners of electrical appliances responsible for the safe condition of the appliance and the safety of the appliance operator. **If in any doubt about electrical safety, contact a qualified electrician.**

1.3.3. You must ensure that you:

- ✓ Inspect the charger plug, cable and connector for wear and damage to ensure items are safe before connecting to the mains power supply. If worn or damaged **DO NOT** use.
- ✓ Important: Check that the voltage marked on the charger plug is the same as the power supply to be used.
- ✓ Uncoil the cable between charger and the light.
- ✗ **DO NOT** pull the charger plug from the mains socket by the lead.
- ✗ **DO NOT** use any other type of charger with this product.

- ✗ **DO NOT** try to take the charger plug apart.
- ✗ **DO NOT** use the charger plug to charge or power any other electrical item.
- ✗ **DO NOT** get the charger wet, or use in wet, damp conditions (for indoor use only).
- WARNING! NEVER** substitute a standard 13amp 3 pin plug, or any other type of plug, for the charger plug.

2. INTRODUCTION

Robust ABS housing featuring 28 super bright Osram LEDs, rubber grip for added comfort when holding the light. Folding hanging hook for hands-free operation and On/Off rocker switch. Ideal for use in engine bays, under-body inspection and low-light work areas. 2 LED charging indicators. Supplied with mains docking charger and 12V in-car charger.

Charge Time - 5Hrs

Operating Time - 8Hrs

3. CHARGING

IMPORTANT WARRANTY INFORMATION:

The battery pack fitted to this cordless tool is considered to be a consumable item and its ability to accept charge will reduce over time. We will warranty it against mechanical and electrical defect for a period of one year - this does not cover fair wear and tear. If the battery is not properly charged before first use, or regularly conditioned, its capacity will diminish. Under these circumstances we will not replace the battery pack even if it is less than one year old.

3.1 MAINS: Make sure the light is switched off before commencing charging.

- 3.1.1 Insert the light in the base charger or insert the charger lead directly into the base of the light.
- 3.1.2 Plug the transformer plug into the mains supply.

- 3.1.3 Whilst the light is charging in the base charger the red and yellow LED will be on. The green LED will illuminate when the light is fully charged. If the light is not in the charger the red LED will be lit constantly. When plugging the charger lead directly into the light the red LED will be on. The green LED will illuminate when the light is fully charged.

- 3.1.4 When charged unplug the charger from the mains supply. Remove the light from the base charger or Unplug the charging lead from the light.


3.2 VEHICLE PLUG:

- 3.2.1 Ensure light is turned off and then plug the 12 volt vehicle plug adaptor into the jack inlet on the light or the base charger.
- 3.2.2 Insert 12V adaptor into vehicle accessory socket.
- 3.2.3 When fully charged, unplug the adaptor from the vehicle socket and from the light before turning on.

NOTE: Charging the light from a 12 volt vehicle socket will drain the vehicle battery.

NOTE: Some vehicles require the ignition to be on to provide power to the vehicle accessory socket.

NOTE: To maintain battery, charge monthly if light is not in use.



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

4. OPERATION

- 4.1 Switch the light ON & OFF using the rocker switch on back of light. Direct the lens away from your eyes before switching on.
- 4.2 To suspend the light, unfold the hanging hook from behind the top of the light and hinge it upwards.

NOTE: LED arrays are designed to allow individual LEDs to cease functioning without causing the entire array to fail. This could be as a result of shock or impact. Shock or impact will invalidate warranty.

Environmental Protection

Recycle unwanted materials instead of disposing of them as waste.



All tools, accessories and packaging should be sorted, taken to a recycle centre and disposed of in a manner which is compatible with the environment.



When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Battery Removal



WARNING! To avoid electric shock, ensure the battery is fully discharged before removing.

1. Remove the screws from the casing then split the casing in two.
2. Release the battery from the inside of the casing and cut the wire to the battery.

Dispose of batteries according to local authority guidelines.

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme.

Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705

