

200MM AIR BLOW GUN WITH 1/4"BSP AIR INLET MODEL NO: SA919

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.





Refer to instructions

Wear eye Wear protective protection gloves

1. SAFETY

- □ WARNING! Disconnect blow gun from the air supply before changing accessories, servicing or performing any maintenance. De-pressurise the blow gun before removing air hose from the gun.
- ✓ Maintain the blow gun in good condition (use an authorised service agent).
- Replace or repair damaged parts. Use genuine parts only. Non genuine parts may be dangerous and will invalidate the warranty.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- \checkmark Only use the blow gun for the purpose of blowing compressed air.
- □ WARNING! Always wear approved eye or face protection when operating the blow gun. Use a face or dust mask if dust is generated. Wear appropriate protective clothing.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non slip shoes.
- ✓ Remove ill fitting clothes, ties, watches, rings, other loose jewellery, and contain/tie back long hair.
- Keep children and unauthorised persons away from the working area.
- ✓ Secure non stable work piece with a clamp, vice or other adequate holding device.
- Avoid unintentional starting.
- □ WARNING! air pressure should not exceed 110psi.
- Keep air hose away from heat, oil and sharp edges. Check air hose for wear before each use, and ensure that all connections are secure.
- * DO NOT use the blow gun for any purpose other than for which it is designed.
- × DO NOT operate blow gun if any parts are damaged or missing as may cause failure or personal injury.
- DO NOT carry the blow gun by the hose, or yank the hose from the air supply.
- DO NOT allow untrained persons to operate the blow gun.
- × DO NOT operate blow gun when you are tired, under influence of alcohol, drugs or intoxicating medication.
- **× DO NOT** leave the blow gun operating whilst unattended.
- * DO NOT direct air from the blow gun at yourself, others or animals
- ✓ When not in use disconnect from the blow supply and store in a safe, dry, child proof area.

2. INTRODUCTION

Die-cast metal body with moulded handle and hanging point. Maximum operating pressure 110psi.

3. SPECIFICATION

Lance length:	. 200mm
Inlet size:	.1/4"BSP

4. OPERATION

- 4.1. Connect to air supply.
- 4.2. Take the unpressurised air hose and connect it to the blow gun inlet.
- 4.3. Turn the air supply on, depress the gun trigger to release the flow of compressed air.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR