

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

**IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.**

### 1. SAFETY INSTRUCTIONS

- ✓ Familiarise yourself with the application, limitations, and hazards of the kit.
- ❑ **WARNING!** Disconnect the cleaning gun from the air supply before changing accessories, servicing or performing any maintenance.
- ✓ Maintain the cleaning gun in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. *Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.*
- ✓ Locate the cleaning gun in a suitable work area. Keep area clean and tidy and free from unrelated materials and ensure that there is adequate ventilation and lighting.
- ✓ Keep the cleaning gun clean for best and safest performance.
- ✓ Ensure the air system has sufficient output for the cleaning gun air consumption (see specification).
- ✓ Wear approved respiratory protection, safety eye goggles and skin protection.
- ✓ Remove ill fitting clothing. Remove ties, watches, rings and other loose jewellery and tie back long hair.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ When gun is not in use ensure the air supply is disconnected.
- ✓ Avoid unintentional operation.
- ✗ **DO NOT** point cleaning gun at yourself or at other persons or animals.
- ✗ **DO NOT** carry the gun by the air hose, or yank the hose from the air supply.
- ✗ **DO NOT** use the cleaning gun for any purpose other than for which it is designed.
- ✗ **DO NOT** allow untrained persons to operate the cleaning gun.
- ✗ **DO NOT** operate gun if any parts are missing or damaged as this may cause failure and/or personal injury.
- ✗ **DO NOT** direct air from the air hose at yourself or others.
- ✓ When not in use disconnect from the air supply.



Parts Issue No: 1  
 Issue Date: 110304

### 2. SPECIFICATION


Air powered, suction spray cleaner for engine, engine bay and other similar applications. Supplied with standard and long aluminium nozzles. 750ml Container suitable for use with all cleaning agents including Sealey Multi-Purpose Degreasing Solvent, Model No. AK25.

Nominal Operating Air Pressure: ..... 75 - 120psi  
 Nominal Air Consumption: ..... 5.5cfm  
 Bottle Capacity: ..... 0.75ltr  
 Air Connection: ..... 1/4"BSP

### 3. AIR SUPPLY

For recommended hook-up, see diagram.

- 3.1. Ensure the variable trigger is in the "off" position before connecting to the air supply.
- 3.2. You will require an air pressure of approximately 75 - 120psi and an air volume of more than 5.5cfm to operate the gun.
- 3.3. ❑ **WARNING! Ensure the air supply is clean does not exceed 170psi. Too high an air pressure and/or unclean air will shorten the life of the gun due to excessive wear and may be dangerous, causing damage and/or personal injury.**
- 3.4. Drain the air supply tank daily and clean the compressor air inlet filter weekly.
- 3.5. Line pressure should be increased to compensate for unusually long air hoses (over 8 metres). The minimum hose diameter should be 10mm I.D. and fittings must have the same inside dimensions.
- 3.6. Keep hose away from heat, oil and sharp edges. Check hoses for wear, and make certain that all connections are secure.



#### Parts List:

Item	Part No:	Description	Item	Part No:	Description
1	VS018/1	BODY	7	VS018/7	COVER
2	VS018/2	O-RING	8	VS018/8	SEAL & BOLT
3	VS018/3	BOLT	9	VS018/9	SUCTION TUBE
4	VS018/4	BOLT & NUT	10	VS018/10	BOTTLE
5	VS018/5	ADAPTOR	11	VS018/11	SHORT NOZZLE
6	VS018/6	LONG NOZZLE			