

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS, AND CAUTIONS. USE THIS PRODUCT CORRECTLY, AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY.

1. SAFETY INSTRUCTIONS

- WARNING!** Ensure that Health and Safety, local authority and general workshop practice regulations are adhered to when using tools.
- DO NOT** use tools if damaged.
- DO NOT** use the kit to perform a task for which it is not designed.
- DO NOT** allow untrained persons to use the kit.
- DO NOT** use when tired or under the influence of drugs, alcohol or intoxicating medication.
- ✓ Maintain tools in a good and clean condition for the best and safest performance.
- ✓ Ensure that the ignition key is removed, to prevent inadvertent engine cranking.
- ✓ If the vehicle to be worked on is raised, ensure that it is adequately supported with axle stands or ramps and chocks.
- ✓ Wear approved eye protection. A full range of personal safety equipment is available from your Sealey dealer.
- ✓ Wear suitable clothing to avoid snagging. Do not wear jewellery and tie back long hair.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ Keep work area clean and tidy and free from unrelated materials.
- ✓ Ensure the work area has adequate lighting.
- ✓ Account for all tools being used and do not leave them on or in the vehicle.
- Brake Fluid Precautions**
- ✓ Always read and comply with the warnings on the brake fluid container.
- ✓ Wear eye protection and keep skin contact to a minimum. If brake fluid enters eyes rinse with plenty of water and seek medical advice. If swallowed seek medical advice immediately.
- ✓ Brake fluid is flammable - keep away from sources of ignition, including hot surfaces e.g. exhaust manifold.
- ✓ Brake fluid will damage paintwork. Any spillage should be flushed with water immediately.
- ✓ Always read and comply with the warnings on the brake fluid container.
- WARNING! DO NOT** pollute the environment by allowing uncontrolled discharge of fluids. Dispose of waste liquids in accordance with local authority regulations.
- WARNING!** Brake fluid is flammable - keep away from sources of ignition, including hot surfaces e.g. exhaust manifold.
- WARNING!** Brake fluid will damage paintwork. Any spillage should be flushed with water immediately.
- ✓ After use, clean equipment and store in a cool, dry, childproof area.

2. INTRODUCTION

VS820UA is used to connect VS820.V2 Bleeding System to the vehicle master cylinder reservoir and is compatible with a wide range of reservoir designs.

3. OPERATION

- 3.1. Insert the two J-bolts through the holes in the adaptor cap and fit the tightening knobs provided.
- 3.2. Remove the brake fluid reservoir cap and fit the adaptor cap centrally over the reservoir filler neck.
- 3.3. Attach one end of the chain to the hooked end of one of the J-bolts, run the chain under the master cylinder and attach to the second J-bolt.
- 3.4. Tighten the two knobs evenly to clamp the adaptor cap onto the reservoir.
- 3.5. Disconnect the threaded cap from the end of the outlet tube on VS820.V2 and connect the adaptor cap tube in its place. Follow the Bleeding System operating instructions, as normal.



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

